

DOOGEE DOOGEE Blade GT

DOOGEE Blade GT User Manual

Model: DOOGEE Blade GT

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your DOOGEE Blade GT 5G outdoor mobile phone. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.



Figure 1.1: Front and back view of the DOOGEE Blade GT, highlighting its storage capacity and LED notification feature.

2. SETUP

2.1 SIM Card and MicroSD Card Installation

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray to open it.
3. Place your Nano-SIM card(s) and/or MicroSD card into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully push the tray back into the device until it clicks into place.

2.2 Initial Power On

Press and hold the Power button located on the side of the device until the DOOGEE logo appears on the screen. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

2.3 Charging the Device

Connect the USB Type-C cable to the charging port at the bottom of the phone and the other end to a compatible 18W power adapter. Plug the adapter into a power outlet. The battery indicator on the screen will show the charging status. For optimal battery life, use the original charger and cable.

3. OPERATING YOUR DEVICE

3.1 Display and Navigation

The DOOGEE Blade GT features a 6.72-inch FHD+ display with a 120Hz dynamic refresh rate, providing a smooth visual experience. Navigate the device using touch gestures: tap to select, swipe to scroll, pinch to zoom. The physical buttons control power, volume, and can be customized for quick access to certain functions.



Figure 3.1: The 6.72-inch FHD+ display with 120Hz refresh rate, offering clear and fluid visuals.

3.2 Camera Usage

The device is equipped with a 48MP AI main camera, a 5MP wide-angle camera, and a 20MP front camera. To open the camera application, tap the camera icon on the home screen or app drawer. Select different modes (e.g., Photo, Video, Portrait) by swiping across the screen. Tap the shutter button to capture images or start/stop video recording.



Figure 3.2: Overview of the DOOGEE Blade GT's camera system, including the 48MP main sensor.

3.3 Connectivity

The DOOGEE Blade GT supports 5G cellular networks, Wi-Fi 6, Bluetooth, NFC for contactless payments, OTG for connecting USB devices, GPS for navigation, and FM radio. Access these settings via the Quick Settings panel (swipe down from the top of the screen) or the Settings app.

4. MAINTENANCE

4.1 Battery Care

The device is powered by a 5500mAh battery. To maximize battery life, avoid extreme temperatures, do not fully discharge the battery regularly, and unplug the charger once the battery is full. The phone supports 18W fast charging.



Figure 4.1: Illustration of the 5500mAh battery and its estimated usage times for standby, music, calls, web browsing, and video watching.

4.2 Cleaning and Durability

The DOOGEE Blade GT is designed to be rugged, with IP68/IP69K water and dust resistance, and MIL-STD-810H compliance for drop protection. To clean the device, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. Ensure all ports are closed before exposing the device to water or dust.



Figure 4.2: Visual representation of the DOOGEE Blade GT's ruggedness, including its waterproof, dust-proof, and drop-proof capabilities.

5. TROUBLESHOOTING

- **Battery Drains Quickly:** Check for background apps consuming power. Reduce screen brightness or disable unnecessary features like GPS, Wi-Fi, or Bluetooth when not in use. Consider performing a factory reset if the issue persists after checking app usage.
- **Speaker Noise/Unclear Sound:** Ensure the speaker grille is clean and free of debris. Adjust volume settings. If the issue persists, it may indicate a hardware problem requiring professional service.
- **Device Not Responding:** Press and hold the Power button for approximately 10-15 seconds to force a restart.
- **Connectivity Issues (Wi-Fi/Bluetooth/Cellular):** Toggle the respective connection off and on. Restart the device. For cellular issues, ensure your SIM card is properly inserted and your plan is active.
- **Apps Crashing/Freezing:** Clear the cache and data for the problematic app in Settings > Apps. If the issue continues, uninstall and reinstall the app.

6. SPECIFICATIONS

Feature	Description
Model Name	DOOGEE Blade GT
Processor	MTK Dimensity 7050 Octa-core (6nm)
RAM	12GB (expandable to 32GB with 20GB virtual RAM)
Internal Storage	256GB ROM
Display	6.72-inch FHD+ (2400 x 1080) IPS, 120Hz Refresh Rate
Rear Camera	48MP AI Main Camera + 5MP Wide Angle Camera
Front Camera	20MP
Battery	5500mAh, 18W Fast Charging
Operating System	Android 14
Durability	IP68/IP69K Waterproof & Dustproof, MIL-STD-810H Drop-proof
Dimensions	10.5mm thickness, 260g weight
Connectivity	5G, Wi-Fi 6, Bluetooth, NFC, OTG, GPS, FM, USB Type-C

6.72" Eye-catching and Eye-protecting Display

6.72inch
Fullview Display

FHD+
Ultra-clear Resolution

16.7 Million
Colors Display

86%
Screen-to-Body Ratio

1400:1
Contrast Ratio



Figure 6.1: Diagram illustrating the MediaTek D7050 6nm processor, central to the phone's performance.

Slimmest Phone, Easiest Life

Incomparable Portable Phone

260g

Weight

10.5MM

Thickness



Figure 6.2: Visual representation of the phone's slim profile (10.5mm) and light weight (260g).

7. WARRANTY AND SUPPORT

Your DOOGEE Blade GT is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official DOOGEE website. For technical support, product inquiries, or service requests, please contact DOOGEE customer service through their official channels.