

## Think Academy TalPad T100

# Think Academy TalPad T100 Wireless Keyboard with Touchpad Case User Manual

## 1. INTRODUCTION

This manual provides instructions for the Think Academy TalPad T100 Wireless Keyboard with Touchpad Case. This accessory is designed to enhance the functionality and protection of your compatible tablet, offering a tactile keyboard, integrated touchpad, and a protective shell with a stand function.

Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.

## 2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- Think Academy TalPad T100 Wireless Keyboard with Touchpad
- Integrated Protective Case
- Charging Cable (USB-C)
- User Manual (this document)



Image: The Think Academy TalPad T100 Wireless Keyboard and its integrated protective case, shown separated.

### 3. SETUP

### 3.1 Installing Your Tablet

1. Carefully align your compatible tablet (e.g., Amazon Fire 7 12th Gen, Fire HD 10 13th Gen, Fire HD 8 12th Gen) with the protective case.
2. Gently press the tablet into the case, ensuring all edges are securely fitted.
3. Confirm that all ports and buttons on your tablet are accessible and unobstructed by the case.



Image: A tablet being carefully placed into the protective keyboard case.

### 3.2 Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the provided USB-C charging cable to the keyboard's charging port and to a standard USB power adapter (not included). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 4 hours and provides over 180 hours of continuous use or over 550 days of standby time.

### 3.3 Bluetooth Pairing

To connect the keyboard to your tablet:

1. Ensure the keyboard is charged and powered on.
2. On your tablet, navigate to the Bluetooth settings.
3. Enable Bluetooth.
4. The tablet will search for available devices. Select "Bluetooth Keyboard" or a similar name from the list.
5. Follow any on-screen prompts to complete the pairing process. A successful connection will be indicated on your tablet.

Video: This video demonstrates the process of pairing a Bluetooth keyboard with a device. It shows how to access Bluetooth settings and select the keyboard for connection.

## 4. OPERATING INSTRUCTIONS

### 4.1 Keyboard and Touchpad Usage

Once paired, the keyboard and touchpad function similarly to a standard laptop. Use the keys for typing and the touchpad for navigation, including tapping for clicks, two-finger scrolling, and other multi-touch gestures supported by your tablet's operating system.

### 4.2 Using the Integrated Stand

The protective case features an inherent stand function. Fold the case to prop your tablet at a comfortable viewing angle. This is ideal for typing, watching videos, or participating in video calls.



Image: A tablet securely placed in the keyboard case, with the case folded to create a stable stand for viewing.



Image: A rear perspective of the tablet within its keyboard case, highlighting the integrated stand mechanism.

Video: This video provides an overview of the Think Academy TalPad T100 AI Learning Tablet for Kids, showcasing its

features and how it integrates with the keyboard case for an enhanced learning experience.

## 5. MAINTENANCE

### 5.1 Cleaning

To clean the keyboard and case, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the surface. Ensure the keyboard is powered off and disconnected from any power source before cleaning.

### 5.2 Battery Care

To prolong battery life, avoid exposing the device to extreme temperatures. If the keyboard will not be used for an extended period, charge it to approximately 50% before storing.

## 6. TROUBLESHOOTING

### 6.1 Keyboard Not Responding

- Ensure the keyboard is powered on and fully charged.
- Check Bluetooth connection: Go to your tablet's Bluetooth settings and confirm the keyboard is connected. If not, attempt to re-pair.
- Restart both the keyboard and your tablet.

### 6.2 Touchpad Not Working

- Verify the keyboard is connected via Bluetooth.
- Ensure the touchpad is not accidentally disabled (some keyboards have a function key to toggle the touchpad).
- Clean the touchpad surface to remove any debris.

### 6.3 Charging Issues

- Confirm the charging cable is securely connected to both the keyboard and the power source.
- Try a different USB-C cable and power adapter to rule out faulty accessories.
- Ensure the charging port on the keyboard is free of dust or debris.

## 7. SPECIFICATIONS

Feature	Specification
Brand	Think Academy
Model Name	Bluetooth Keyboard for T100
Connectivity Technology	Bluetooth
Compatible Devices	Tablet (Amazon Fire 7 12th Generation, Amazon Fire HD 10 13th Generation, Amazon Fire HD 8 12th Generation)
Special Feature	Trackpad, Integrated Protective Case
Battery Capacity	500mAh Lithium

Usage Time	Over 180 hours
Standby Time	Over 550 days
Charge Time	Less than 4 hours
Keyboard Layout	QWERTY
Number of Keys	64
Keying Life	Over 3 million strokes
Product Dimensions	6.85"L x 0.83"W x 10.28"H
Material	Plastic

## **8. WARRANTY AND SUPPORT**

### **8.1 Warranty Information**

This Think Academy TalPad T100 Wireless Keyboard with Touchpad Case is covered by a 1-Year Manufacturer's Warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

### **8.2 Customer Support**

For technical assistance, warranty claims, or further inquiries, please contact Think Academy customer support through the retailer's platform or the official Think Academy website. Please have your product model and purchase information ready when contacting support.