

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ALLIMITY](#) /

› [ALLIMITY Remote Control Instruction Manual for Strong TV Models SRT 50UC6203, SRT 40FB5203, and Others](#)

## ALLIMITY SRT-50UC6203

# ALLIMITY Remote Control Instruction Manual

Compatible with Strong TV Models: SRT 50UC6203, SRT 40FB5203, SRT 49UA6203, SRT 65UA6203, SRT 32HB5203, SRT 43UA6203, SRT 55UA6203, SRT 32HC4432, SRT 43UB6203

## INTRODUCTION

---

This manual provides instructions for the ALLIMITY replacement remote control, designed for various Strong TV models. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance. This remote control is designed to be fully functional without the need for programming or complex installation.

## SETUP

---

### 1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





**Figure 1:** Rear view of the remote control with the battery compartment open, indicating where to insert AAA batteries according to polarity markings.

## 2. Initial Use

This ALLIMITY remote control is designed for immediate use with compatible Strong TV models. No programming or complex setup is required. Once batteries are installed, point the remote control towards your Strong TV and begin operation.

## OPERATING INSTRUCTIONS

The remote control features a standard layout for easy navigation and control of your Strong TV. Below is a guide to the main functions:





Figure 2: Front and side views of the ALLIMITY remote control, illustrating its ergonomic design and button layout. Dimensions are approximately 23 cm (9.06 in) in length and 5.3 cm (2.09 in) in width.

## Button Functions Overview

- **POWER (●):** Turns the TV on or off.
- **Mute (⏸):** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly select TV channels.
- **SUBTITLE:** Activates or deactivates subtitles.
- **YouTube:** Direct access to the YouTube application.
- **VOL (+/-):** Adjusts the volume level.
- **CH (▲/▼):** Changes TV channels up or down.
- **TV:** Switches to TV mode.
- **SOURCE:** Selects input sources (HDMI, AV, etc.).
- **USB:** Accesses media from a connected USB device.
- **Menu (☰):** Opens the main menu.
- **Info (i):** Displays information about the current program.
- **ECO:** Activates or deactivates energy-saving mode.
- **Home (⌂):** Returns to the home screen or smart TV interface.
- **Settings (⚙):** Opens the TV settings menu.
- **Navigation Buttons (▲ ▼ ◀▶):** Navigate through menus and options.
- **OK:** Confirms selections.
- **Back (↶):** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **NETFLIX:** Direct access to the Netflix application.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and context (e.g., teletext, interactive services).
- **SLEEP:** Sets a sleep timer for the TV.
- **ZOOM (+/-):** Adjusts the screen zoom level.
- **CH LIST:** Displays the channel list.

- **TEXT:** Activates or deactivates teletext.
- **GUIDE:** Opens the electronic program guide (EPG).
- **PRE-CH:** Switches to the previously viewed channel.
- **FAV:** Accesses favorite channels.
- **Media Control Buttons (Rewind, Play/Pause, Fast Forward, Previous, Stop, Next):** Controls media playback.
- **CDLANG:** Changes the audio language or track during media playback.





**Figure 3:** Two angled views of the ALLIMITY remote control, providing a clear perspective of all buttons and their labels for easy identification during operation.

## MAINTENANCE

---

### Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

### Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

## Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not working.	<ul style="list-style-type: none"><li>• Dead or incorrectly installed batteries.</li><li>• Obstruction between remote and TV.</li><li>• Remote control is out of range.</li></ul>	<ul style="list-style-type: none"><li>• Replace batteries with new ones, ensuring correct polarity.</li><li>• Remove any objects blocking the line of sight to the TV's IR receiver.</li><li>• Ensure you are within 10 meters (33 feet) of the TV.</li></ul>
Specific buttons not responding.	<ul style="list-style-type: none"><li>• Button stuck or dirty.</li><li>• Compatibility issue with a specific TV function.</li></ul>	<ul style="list-style-type: none"><li>• Clean around the button.</li><li>• Verify your TV model is listed as compatible. While this remote is designed to cover all functions, some specific smart TV features might vary.</li></ul>
Remote control feels sluggish.	Low battery power.	Replace batteries.

**Compatible TV Models:** This remote control is compatible with the following Strong TV models: SRT 50UC6203, SRT 40FB5203, SRT 49UA6203, SRT 65UA6203, SRT 32HB5203, SRT 43UA6203, SRT 55UA6203, SRT 32HC4432, SRT 43UB6203, SRT 55UB6203.

## SPECIFICATIONS

- **Brand:** ALLIMITY
- **Color:** Black
- **Connectivity Technology:** Infrared (IR)
- **Special Feature:** Ergonomic design
- **Compatible Devices:** Strong TV models: SRT 50UC6203, SRT 40FB5203, SRT 49UA6203, SRT 65UA6203, SRT 32HB5203, SRT 43UA6203, SRT 55UA6203, SRT 32HC4432, SRT 43UB6203, SRT 55UB6203
- **Model Name:** SRT-50UC6203 (reference model)
- **Maximum Range:** 10 Meters (approximately 33 feet)
- **Number of Buttons:** 25
- **Controller Type:** Infrared

## WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct manufacturer support for this ALLIMITY remote control is not available in the provided product data. For any issues or inquiries, please refer to the retailer's return policy or contact the seller directly through your purchase platform.



ALLIMITY Remote Control Instruction Manual. All rights reserved.