

[Manuals.plus](#) /

› [NWIASS](#) /

› NWIASS 72-inch Gold Ceiling Fan with Light and Remote User Manual

NWIASS 72 inch gold ceiling fan with light

NWIASS 72-inch Gold Ceiling Fan with Light and Remote User Manual

Model: 72 inch gold ceiling fan with light

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your NWIASS 72-inch Gold Ceiling Fan with Light and Remote. This fan features natural solid wood blades, a quiet DC motor, 3-CCT dimmable LED lighting, and is suitable for both indoor and covered outdoor use. Please read all instructions carefully before proceeding with installation or operation.

SAFETY INFORMATION

- Always disconnect power at the circuit breaker before installing, cleaning, or servicing the fan.
- All electrical wiring must comply with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Ensure the installation site can support the fan's weight.
- Do not operate the fan with damaged components. Inspect all parts before assembly.
- Keep hands, clothing, and other objects clear of the fan blades during operation.
- This fan is damp-rated, suitable for covered outdoor areas but not directly exposed to water.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 5 x Solid wood fan blades
- 3 x Down rods (5", 10", 24")
- 1 x DC motor assembly
- 1 x Lampshade
- 1 x Set of remote control and receiver
- 1 x English user manual (this document)

- 1 x Canopy
- 1 x Pack of screws and hardware



Figure 1: Included downrods and key features of the NWIASS 72-inch Gold Ceiling Fan.

PRODUCT FEATURES

- **Natural Solid Wood Blades:** Crafted from wood grown for over 10 years, featuring clear texture and a smooth finish.
- **Remote Control:** FCC certified remote for 6-speed fan control, light adjustment, 1/4/8-hour timer, and natural air mode. Includes a wall mount.
- **3-CCT Dimmable LED Light:** Integrated LED light with memory function, adjustable brightness (10%-100%), and three color temperatures (3000K Warm White, 4000K Natural White, 5000K Cool White).
- **72-inch Diameter:** Designed for medium to large rooms, including kitchens, bedrooms, living rooms, and covered outdoor spaces.
- **Reversible DC Motor:** Delivers powerful airflow with quiet performance, 75% more energy-efficient than

traditional AC motors. Reversible function for summer cooling and winter air circulation.

- **Damp Rated:** Suitable for indoor and covered outdoor environments like patios, porches, gazebos, and pergolas.
- **Multiple Downrod Options:** Includes 5", 10", and 24" downrods to accommodate various ceiling heights and sloped ceilings (up to 20°).



Figure 2: NWIASS 72-inch Gold Ceiling Fan in an outdoor setting, highlighting energy efficiency.

SETUP AND INSTALLATION

The NWIASS 72-inch Gold Ceiling Fan is designed for straightforward installation. Most assembly procedures are pre-completed. Refer to the included detailed installation instructions and videos for a step-by-step guide.

Mounting Options

This fan supports both downrod mount and sloped ceiling mount (for slopes less than 20°). Choose the appropriate downrod (5", 10", or 24") based on your ceiling height to maximize air efficiency.



Figure 3: Example installation of the NWIASS 72-inch Gold Ceiling Fan in a covered outdoor patio.

Installation Video

Your browser does not support the video tag.

Video 1: This video demonstrates the features and installation process of the NWIASS 72-inch Gold Ceiling Fan, including its sleek design and light functions.

OPERATING INSTRUCTIONS

Your NWIASS ceiling fan is controlled by the included FCC certified remote control. Ensure the remote has fresh batteries and is paired with the fan receiver according to the detailed instructions in the separate remote control guide.

Fan Control

- **Power On/Off:** Press the fan power button to turn the fan on or off.
- **Speed Adjustment:** Use the speed buttons (1-6) to select your desired fan speed.
- **Reversible Function:** Activate the reversible motor for downward airflow in summer (cooling) or upward airflow

in winter (air circulation).

- **Timer:** Set the fan to turn off automatically after 1, 4, or 8 hours.
- **Natural Air Mode:** Engages a varying fan speed to simulate a natural breeze.

Light Control

- **Light On/Off:** Press the light power button to turn the light on or off.
- **Color Temperature Adjustment:** Cycle through 3000K (Warm White), 4000K (Natural White), and 5000K (Cool White) settings.
- **Brightness Dimming:** Adjust the light brightness from 10% to 100%. The light has a memory function, retaining the last setting.



Figure 4: Remote control for the NWIASS 72-inch Gold Ceiling Fan, with wall mount.

CEILING FAN WITH DIMMABLE LED LIGHTS



Figure 5: Dimmable LED light with 3 color temperature options.

Operation Video

Your browser does not support the video tag.

Video 2: This video showcases the versatile features of the NWIASS Gold Ceiling Fan, including its solid wood blades, reversible DC motor for air circulation, and adjustable light settings.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents. Ensure the fan is turned off and power is disconnected before cleaning.
- **Blade Inspection:** Periodically check the fan blades for any signs of damage or warping. Ensure all blade screws are securely tightened.
- **Electrical Connections:** Annually inspect all electrical connections for tightness and wear.
- **Light Cover:** Ensure the light cover is securely attached. If it becomes loose, reattach it firmly to prevent

vibration and detachment.

TROUBLESHOOTING

If you encounter issues with your NWIASS ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power, loose wiring, remote not paired, dead remote batteries.	Check circuit breaker. Verify all wiring connections. Replace remote batteries. Re-pair remote with receiver (refer to remote guide).
Light flickers or does not turn off completely	Loose connection, faulty LED driver, remote signal interference.	Ensure all light connections are secure. If flickering persists, contact customer support. Ensure the remote is fully turning off the light; if a faint glow remains, ensure the wall switch is also off.
Fan makes excessive noise	Loose blades, mounting hardware, or motor housing.	Tighten all blade screws and mounting hardware. Ensure the canopy is secure.
Remote control not responding	Dead batteries, remote not paired, obstruction.	Replace remote batteries. Re-pair remote with receiver. Ensure no obstructions between remote and fan.
Light cover falls off	Improperly secured light cover, vibration.	Ensure the light cover is firmly and correctly attached according to installation instructions. Check for excessive fan wobble.

SPECIFICATIONS

Feature	Detail
Brand	NWIASS
Model Name	Modern Farmhouse Ceiling Fan with Light
Model Number	72 inch gold ceiling fan with light
Color	Brown and Gold
Product Dimensions	72"D x 72"W x 19"H
Power Source	DC
Number of Blades	5
Blade Material	Natural Solid Wood
Motor Type	DC Frequency Conversion Copper Motor
Number of Speeds	6
Light Type	Dimmable 3 Color Temperature LED
Color Temperature	3000K, 4000K, 5000K
Brightness	10%-100% Dimmable

Feature	Detail
Air Flow Capacity	6800 Cubic Feet Per Minute
Noise Level	30 Decibels
Wattage	40 watts
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor, Covered Outdoor
Mounting Type	Ceiling Mount, Downrod Mount, Sloped Ceiling (<20°)
Certifications	ETL, FCC

WARRANTY AND SUPPORT

NWIASS provides a **2-year warranty** for this ceiling fan. This warranty covers free replacement of accessories and parts for lost or damaged components. For any questions, concerns, or to claim warranty service, please contact NWIASS Ceiling Fan Factory Shop through your order details. We offer 24-hour after-sales support.