Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY PTV32GH-5023C

ALLIMITY Voice Remote Control User Manual

Model: PTV32GH-5023C

Introduction

This manual provides essential information for the proper use and maintenance of your ALLIMITY Voice Remote Control. This remote is designed to be fully functional and compatible with various PEAQ LED TV models, offering a seamless replacement for your original remote without requiring complex programming.






Image: Front view of the ALLIMITY Voice Remote Control, showcasing its full button layout including number pad, navigation, volume, channel, and dedicated app buttons.

Compatibility

This ALLIMITY Voice Remote Control is compatible with the following PEAQ LED TV models. Please ensure your TV model matches one of the listed models for full functionality.

- PIV24GH-5024C
- PIV32GH-5023C
- PTV32GF-5024C
- PTV32GH-5023C-B, PTV32GH-5023C-BL, PTV32GH-5023C-W
- PTV32GH-5024C, PTV32GH-5024C-B, PTV32GH-5024C-BL, PTV32GH-5024C-W
- PTV32GQF-5024C
- PTV40GF-5024C

- PTV43AQU-5023C
- PTV50AQU-5023C
- PTV50GQU-5024C
- PTV65GQU-5024C

Note: If you are unsure of your TV's model number, it can usually be found on a label on the back of the device or in your TV's original user manual.

Key Features

- **Easy to Use:** No programming or complex installation is required. Simply insert batteries and begin using the remote.
- **Fully Functional:** Designed to replicate all the functions of your original PEAQ LED TV remote control.
- **Ergonomic Design:** Lightweight and comfortable to hold, ensuring ease of use during extended periods.
- **Stable Performance:** Offers a reliable and consistent transmission distance for stable remote control operation.
- **Voice Control Capability:** Features a dedicated button for voice commands, allowing for hands-free control of your TV (if supported by your TV model).

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two (2) AA Alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover securely.


Note: Batteries are not included with the remote control. Always use new, high-quality alkaline batteries for optimal performance.

Operating Instructions

Once batteries are installed, the remote control is ready for immediate use with compatible PEAQ LED TV models. Point the remote directly at your television's infrared receiver.

Key Functions Overview

Button	Function
Power ( )	Turns the TV On or Off.

Button	Function
Number Pad (0-9)	Direct channel selection.
Voice Control (🎤)	Activates voice command feature for compatible TVs. Press and hold to speak your command.  Image: The ALLIMITY remote control with a prominent microphone icon next to it, indicating the voice control feature.
Navigation (Up/Down/Left/Right/OK)	Navigates menus and confirms selections.
Volume (+/-)	Adjusts the TV volume.
Channel (P+/P-)	Changes TV channels.
Home (⌂)	Returns to the TV's home screen or smart TV interface.
Netflix, YouTube, Prime Video, Google Play, USB	Dedicated buttons for quick access to streaming services and USB input.
Exit	Exits current menu or application.
Settings (⚙)	Accesses TV settings menu.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

Problem	Possible Solution
Remote is not responding.	◦ Check if batteries are inserted correctly with correct polarity. ◦ Replace old batteries with new ones. ◦ Ensure there are no obstructions between the remote and the TV's infrared receiver. ◦ Make sure you are within the effective range (up to 10 meters).
Voice control is not working.	◦ Ensure your PEAQ LED TV model supports voice control. ◦ Press and hold the voice control button while speaking your command clearly. ◦ Check TV settings for voice control activation or pairing instructions.
Some buttons are not working.	◦ Clean the remote's surface, especially around the non-working buttons, to remove any dirt or debris. ◦ Ensure the remote is compatible with your specific TV model.

Specifications

Feature	Detail
Brand	ALLIMITY
Model	PTV32GH-5023C

Feature	Detail
Dimensions (L x W x H)	Approx. 21.5 x 4.2 x 1 cm (8.46 x 1.65 x 0.39 inches)  Image: The ALLIMITY remote control shown with its length (21.5 cm / 8.46 in) and width (4.2 cm / 1.65 in) measurements indicated.
Weight	59 grams (0.13 lbs)
Battery Type	2 x AA Alkaline (not included)
Connectivity Technology	Infrared (IR)

Feature	Detail
Maximum Range	10 meters (33 feet)
Controller Type	Button Control
Additional Features	Ergonomic design

Warranty and Support

For any issues or inquiries regarding your ALLIMITY Voice Remote Control, please contact your retailer or the point of purchase. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 ALLIMITY. All rights reserved.
Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRD4PX6K

More documents and user manuals: **https://manuals.plus/**