**Wellsle B0DRD5GLWG**

# Wellsle 34 Pint Dehumidifier Instruction Manual

Model: B0DRD5GLWG

## 1. Introduction

Thank you for choosing the Wellsle 34 Pint Dehumidifier. This appliance is designed to efficiently remove excess moisture from your indoor environment, creating a more comfortable and healthier living space. It features powerful dehumidification, versatile operating modes, quiet performance, and convenient drainage options. Please read this manual thoroughly before operation to ensure safe and optimal use.

## 2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the unit is placed on a stable, level surface.
- Do not operate the unit with a damaged power cord or plug.
- Keep the unit away from water and other liquids.
- Do not block air inlets or outlets.
- Unplug the unit before cleaning or maintenance.
- This appliance is equipped with automatic safety features including full tank protection with automatic shut-off, compressor overload protection, and automatic defrosting.
- The child lock feature helps prevent accidental adjustments, making it ideal for homes with children and pets.

## 3. Product Overview and Components

Familiarize yourself with the main parts of your Wellsle Dehumidifier.




**Image:** Front view of the Wellsle 34 Pint Dehumidifier, showing its compact white design suitable for various room settings.

## Control Panel




**Image:** Close-up of the dehumidifier's control panel, displaying various settings such as DEHU mode, Dry mode, CONT mode, fan speed, timer, and child lock. The digital display shows the current humidity level.

## Drainage System




**Image:** Illustration of the two drainage options: a removable water tank for manual emptying and a continuous drain hose connection for automatic drainage.

## Mobility Features




**Image:** Diagram highlighting the dehumidifier's mobility features, including an ergonomic handle, a carry handle, 360° rotatable wheels, and a visual water tank level indicator.

## 4. Setup Guide

1. **Unpacking:** Carefully remove the dehumidifier from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the unit upright on a stable, level surface. Ensure there is at least 20-30 cm (8-12 inches) of space around the unit for proper airflow. For optimal performance, allow the unit to stand upright for 24 hours before initial use.
3. **Power Connection:** Plug the power cord into a grounded electrical outlet.
4. **Drainage Options:**
    - **Manual Drainage:** The unit comes with a 1.7-litre (0.66-gallon) water tank. When the tank is full, the unit will automatically shut off and an indicator will light up. Empty the tank and reinsert it to resume operation.

- **Continuous Drainage:** For extended use without manual emptying, attach the included 1.8m (6.56ft) drain hose to the continuous drainage port at the back of the unit. Ensure the hose is sloped downwards to allow water to drain into a suitable floor drain or large container.

Your browser does not support the video tag.

**Video:** This video demonstrates the initial setup and drainage options for a CHIVALZ dehumidifier, including how to install the continuous drain hose. Note: The video features a CHIVALZ brand dehumidifier, but the setup principles for drainage are similar.

## 5. Operating Instructions

### Power On/Off

Press the **Power** button on the control panel to turn the unit on or off.

### Setting Desired Humidity

Use the **Humidity Adjustment** buttons (INC/DEC or Up/Down arrows) to set your desired humidity level between 30% and 80%. The unit will operate until the set humidity is reached, then cycle on and off to maintain it.

### Operating Modes

Press the **Mode** button to cycle through the available operating modes:

- **DEHU Mode:** Provides precise moisture management based on your set humidity level.
- **Drying Mode:** Dries clothes quickly, ideal for laundry rooms or during rainy seasons.
- **CONT Mode:** Operates continuously to reduce humidity in very damp rooms, regardless of the set humidity level.

### Fan Speed

Press the **Speed** button to adjust the fan speed (Low or High).

### 24-Hour Timer

Use the **Timer** button to set a 1-24 hour timer for scheduled operation. The unit will turn on or off after the set time.

### Child Lock

Activate the **Child Lock** feature to prevent accidental changes to settings. Refer to the control panel diagram for the specific button combination or icon.

Your browser does not support the video tag.

**Video:** This video demonstrates the various features and controls of a dehumidifier, including setting humidity levels, fan speeds, and operating modes. Note: The video features an LXT brand dehumidifier, but the control panel functions are similar.

## 6. Maintenance

### Emptying the Water Tank

When the water tank is full, the unit will automatically shut off and an indicator light will illuminate. Carefully pull out the water tank, empty the collected water, and then securely reinsert the tank into the unit. Ensure the tank is properly seated

to resume operation.

## Cleaning the Washable Filter

The dehumidifier is equipped with an easy-to-disassemble, washable filter panel that prevents dust and dirt from entering the unit, ensuring clean air output. It is recommended to clean the filter every two weeks or more frequently depending on usage and air quality.

1. Turn off and unplug the dehumidifier.
2. Remove the filter panel from the back of the unit.
3. Wash the filter with clean water. Air dry completely before reinserting. Do not tumble dry.
4. Once dry, reattach the filter panel securely.




**Image:** A hand removing the easy-to-disassemble washable filter panel from the back of the dehumidifier, illustrating the maintenance process.

## 7. Troubleshooting

If your dehumidifier is not operating as expected, please check the following common issues before contacting support:

- **Unit does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the water tank is full and properly inserted.
- **No water collected:** Verify that the humidity setting is lower than the current room humidity. Check if the filter is clean and not blocked. Ensure the unit is not in defrost mode.
- **Unit is noisy:** Ensure the unit is on a stable, level surface. Check for any obstructions in the air inlets or outlets.
- **Water leakage:** Ensure the water tank is correctly positioned and not damaged. If using continuous drainage, check that the hose connection is secure and the hose is not kinked or blocked.

## 8. Specifications

| Feature | Detail |
|---|---|
| **Brand** | Wellsle |
| **Model** | B0DRD5GLWG |
| **Dehumidification Capacity** | Up to 34 litres (34 Pints) per day |
| **Coverage Area** | Up to 2000 sq. ft. (in ideal conditions) |
| **Water Tank Capacity** | 1.7 litres (0.66 gallons) |
| **Noise Level** | 40-45 dB |
| **Humidity Range** | 30% to 80% (adjustable) |
| **Operating Modes** | DEHU, Drying, CONT |
| **Timer** | 24-hour programmable |
| **Drainage Options** | Manual (tank) or Continuous (1.8m drain hose included) |
| **Safety Features** | Full tank auto shut-off, compressor overload protection, automatic defrosting, child lock |
| **Color** | White |

## 9. Warranty and Support

Wellsle provides advanced technology and reliable customer service with a one-year warranty and lifetime technical service.

- **Extended Warranty:** Contact Wellsle to register your product for an additional one-year warranty.
- **Customer Support:** If you have any questions or problems, please contact Wellsle customer service via phone, email, or their official platform. Wellsle is committed to ensuring peace of mind with every purchase.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question