

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lisowod](#) /

› [Lisowod L62Pro Projector User Manual](#)

Lisowod L62Pro

Lisowod L62Pro Projector User Manual

Model: L62Pro | Brand: Lisowod

1. PRODUCT OVERVIEW

The Lisowod L62Pro is a compact and versatile home projector designed to deliver a high-quality viewing experience. Featuring Android TV 14 and Whale OS, it provides access to a vast library of applications. With 1000 ANSI lumens brightness and support for 4K resolution, it ensures clear and vibrant images. Advanced image correction features like automatic vertical keystone, 4D/4P keystone, and electric focus simplify setup, while Wi-Fi 6 and bidirectional Bluetooth 5.4 offer seamless connectivity for streaming and audio.

Android TV 14.0



Figure 1: The Lisowod L62Pro Projector showcasing its Android TV 14.0 interface.

Key Features:

- **Whale OS & Android TV 14:** Access to over 10,000 applications for direct streaming.
- **True Full HD 1080P & 4K Support:** Delivers sharp and detailed images.
- **1000 ANSI Lumens:** Bright projection suitable for various lighting conditions.
- **Automatic & Manual Keystone Correction:** Includes auto vertical keystone and 4D/4P manual correction for flexible placement.
- **Electric Focus & 50-100% Zoom:** Easy image adjustment without moving the projector.
- **Wi-Fi 6 & Bidirectional Bluetooth 5.4:** High-speed, zero-latency wireless connectivity for streaming and audio.
- **Quiet Operation:** Operates at a low noise level of 30dB.
- **Long Lifespan:** Light source rated for 90,000 hours of use.
- **Wide Compatibility:** Connects to various devices via HDMI, USB, AV, and 3.5mm audio jack.

2. SETUP GUIDE

2.1 Unpacking and Placement

Carefully remove the projector and all accessories from the packaging. Place the projector on a stable, flat surface or mount it according to your preference (tabletop, stand, or ceiling projection are supported).



Figure 2: Flexible projection methods including tabletop, stand, and ceiling mounting.

2.2 Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a suitable electrical outlet.
3. The projector will typically enter standby mode, indicated by a power indicator light.

2.3 Initial Power On

Press the power button on the projector or the remote control to turn on the device. The projector will boot up and display the Android TV interface.

2.4 Image Adjustment

The L62Pro features automatic and electric adjustments for optimal image display:

- **Automatic Vertical Keystone Correction:** The projector will automatically detect and correct vertical image distortion when moved.
- **4D/4P Keystone Correction:** Use the remote control to manually adjust horizontal and corner distortions for a perfectly rectangular image from any angle.
- **Electric Focus:** Press the focus button on the remote control to achieve a clear image. This adjustment takes approximately 3 seconds.
- **Zoom Function:** Adjust the image size from 50% to 100% using the remote control without physically moving the projector.

全方位インテリジェント台形補正

自動垂直台形補正+電動4D/4P台形補正:どんな設置位置でも傾いた画面を補正



Figure 3: Visual representation of automatic keystone correction, electric focus, and zoom capabilities.

2.5 Connecting External Devices

The L62Pro offers multiple connectivity options:

- **HDMI:** Connect gaming consoles (PS4, Switch), PCs, or other HDMI-enabled devices.
- **USB:** Plug in USB drives for media playback.
- **AV:** Connect older devices using an AV cable.
- **3.5mm Audio Jack:** Connect wired headphones or external speakers.



Figure 4: Multi-functional compatibility with various devices via different input ports.

3. OPERATING INSTRUCTIONS

3.1 Navigating Android TV 14 & Whale OS

Use the provided remote control to navigate the user interface. The home screen displays various applications and content recommendations. You can directly launch streaming services like Netflix, YouTube, and Disney+ without needing a separate browser.

Whale OS搭載&10000+アプリ

ブラウザ不要で、お気に入りのアプリがページに直接表示される。

【Netflix/YouTube/Prime Videoなどに対応】



Figure 5: The projector's Whale OS interface with direct access to numerous applications.

3.2 Wi-Fi Connectivity (Wi-Fi 6)

The projector supports Wi-Fi 6 for high-speed, zero-latency internet connectivity. To connect:

1. Go to Settings on the home screen.
2. Select Network & Internet.
3. Choose your Wi-Fi network and enter the password.

3.3 Bluetooth Audio (Bidirectional Bluetooth 5.4)

The L62Pro features bidirectional Bluetooth 5.4, allowing it to function in two ways:

- **Projector Mode:** Connect Bluetooth headphones or external speakers to the projector for enhanced audio.
- **Speaker Mode:** Connect your smartphone or other devices to the projector via Bluetooth to use the projector's built-in HiFi speakers as a standalone audio system.

WIFI6 & 双方向Bluetooth 5.4

ゼロ遅延、即時接続



Figure 6: Bidirectional Bluetooth 5.4 enables versatile audio connections.

4. MAINTENANCE

4.1 Cleaning the Lens

To maintain optimal image clarity, regularly clean the projector lens using a soft, lint-free cloth specifically designed for optical lenses. Avoid using abrasive materials or harsh chemicals.

4.2 Ventilation

Ensure that the projector's ventilation openings are not blocked to prevent overheating. Adequate airflow is crucial for the projector's performance and longevity.

4.3 Light Source Lifespan

The L62Pro features a durable light source with an impressive lifespan of 90,000 hours, significantly reducing the need for

frequent replacements compared to traditional projectors.

4.4 Software Updates (OTA)

The projector supports Over-The-Air (OTA) updates, ensuring that your device always runs on the latest system version with improved features and performance. Connect to the internet to receive automatic updates.

5. TROUBLESHOOTING

If you encounter any issues with your Lisowod L62Pro projector, please refer to the following common troubleshooting steps:

- **No Image Displayed:**

- Ensure the projector is powered on and the power indicator light is active.
- Check all cable connections (HDMI, USB) are secure.
- Verify the correct input source is selected on the projector.
- If using screen mirroring, ensure your device is properly connected and mirroring is enabled.

- **Image is Blurry:**

- Use the electric focus function on the remote control to adjust clarity.
- Ensure the projector lens is clean and free of dust or smudges.
- Check that the projection surface is flat and smooth.

- **No Sound:**

- Adjust the volume on both the projector and the connected source device.
- If using external speakers or headphones, ensure they are properly connected via Bluetooth or the 3.5mm audio jack.
- Check audio settings on the projector to ensure output is directed correctly.

- **Connectivity Issues (Wi-Fi/Bluetooth):**

- Ensure Wi-Fi or Bluetooth is enabled on the projector and the device you are trying to connect.
- Check Wi-Fi network password if connection fails.
- Move closer to the Wi-Fi router or Bluetooth device to improve signal strength.
- Restart the projector and your connected device.

- **Remote Control Not Responding:**

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the projector's IR receiver.
- Point the remote directly at the projector.

6. SPECIFICATIONS

Brand	Lisowod
Model Number	L62Pro

Product Dimensions	20 x 15 x 5 cm
Item Weight	1.57 Kilograms
Resolution	1920 x 1080 (Full HD), 4K Supported
Brightness	1000 ANSI Lumens
Connectivity Technology	Bluetooth 5.4, Wi-Fi 6, HDMI, USB, 3.5mm Audio Jack, AV
Wattage	60 W
Light Source Lifespan	90,000 hours
Noise Level	30dB
Keystone Correction	Automatic Vertical, 4D/4P Manual
Focus	Electric Focus
Zoom Function	50-100% Optical Zoom
Recommended Use	Versatile for entertainment, business, and educational purposes.

7. WARRANTY AND SUPPORT

Lisowod stands behind the quality of the L62Pro projector. We offer a **36-month unconditional exchange or refund service** from the date of purchase. Additionally, comprehensive technical support is available to assist you with any questions or issues you may encounter.

For warranty claims or technical assistance, please contact our support team through the contact information provided in your product packaging or on the official Lisowod website. Our specialized team is ready to provide prompt and reliable support.