

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FANGOR](#) /

› [FANGOR Uhale 32-Inch Digital Picture Frame 320KZ User Manual](#)

## FANGOR 320KZ

# FANGOR Uhale 32-Inch Digital Picture Frame (Model 320KZ) User Manual

Your comprehensive guide to setting up and operating your digital picture frame.

## 1. INTRODUCTION

The FANGOR Uhale 32-inch Digital Picture Frame (Model 320KZ) allows you to display your cherished photos and videos with ease. Featuring a 1920x1080 Full HD IPS display, 64GB of internal storage, and Wi-Fi connectivity, this frame offers multiple ways to share and enjoy your memories. This manual provides detailed instructions for setup, operation, and maintenance.



Image: The Uhale 32-inch Digital Picture Frame, remote control, and smartphone app.

## 2. WHAT'S IN THE BOX

Ensure all components are present upon unboxing:

- FANGOR Uhale 32-inch WiFi Digital Picture Frame
- Power Adapter
- Remote Control + Batteries
- Table Stand
- Wall Mount Kit
- User Manual




Image: Included components of the Uhale 32-inch Digital Picture Frame.

## 3. SETUP

### 3.1 Initial Power-On and Language Selection

1. Connect the digital frame to the power supply using the provided adapter. The frame will power on automatically.
2. Use the remote control to select your preferred language from the on-screen options.

### 3.2 Wi-Fi Connection

1. Navigate to the Wi-Fi settings using the remote control.
2. Select your desired 2.4G or 5G Wi-Fi network.
3. Enter the Wi-Fi password using the on-screen keyboard and confirm.

### 3.3 Date and Time Setting

The frame can automatically sync date and time via the network. If manual adjustment is needed, use the remote control to set the time zone, date, and time.

### 3.4 Naming Your Frame

You can assign a custom name and location to your digital frame for easy identification, especially when managing multiple frames through the app.

Your browser does not support the video tag.

Video: Step-by-step guide on how to set up the Uhale 32-inch digital photo frame, including initial power-on, language selection, Wi-Fi connection, and basic settings.

### 3.5 App Download and Frame Binding

The Uhale app (available for Android and iOS) is essential for sharing photos and videos wirelessly.

1. Download the "Uhale" app from your device's app store.
2. Open the app and register an account or proceed as a visitor.
3. On the digital frame, navigate to the "Add friend" or "Settings" section to find the QR code or pairing ID.
4. Use the Uhale app on your smartphone to scan the QR code or enter the ID to bind your phone to the frame. The code is valid for 12 hours.




Image: Uhale App setup process.

### 3.6 Adding Friends/Users

You can invite family and friends to share photos and videos to your frame:

1. Share the frame's QR code or pairing code with your desired contacts.
2. Once they bind their app to your frame, they can send photos and videos directly.




Image: Unlimited user connections for sharing.

### 3.7 Uploading Photos and Videos



There are multiple methods to transfer your media:

- **Uhale App:** Select photos/videos from your phone, choose the recipient frame, add a caption, and send. The app supports uploading up to 100 photos at once and videos up to 120 seconds.
- **PC Web:** Log in to the Uhale website on your computer, add your frame, select photos, and upload. This method supports uploading up to 500 photos at once.
- **SD Card/USB Drive:** Insert an SD card (Max 128GB) or USB drive (Max 128GB) into the frame. The frame supports FAT32 format. You can import media or play directly from the storage device. Video uploads via SD card/USB have no time limit.



Image: Multiple ways to transfer pictures and videos.

### 3.8 Placement and Wall Mounting

The frame can be placed on a tabletop using the included stand or wall-mounted. It supports auto-rotation for both landscape and portrait orientations.

1. **Tabletop:** Attach the provided stand to the back of the frame.
2. **Wall Mounting:** Use the included wall mount kit. Mark the positions for drilling based on the wall mounting stand's holes. Drill holes, insert expanding plastic screws, and then screw the wall mounting stand into place. Attach the digital picture frame to the wall mounting stand and secure it with the long screws. Ensure the power adapter is inserted before fully securing the frame.

Your browser does not support the video tag.

Video: Instructions on how to install the Uhale 32-inch digital photo frame on a wall.




Image: Wall-mounted and auto-rotate feature.

## 4. OPERATING INSTRUCTIONS

### 4.1 Remote Control Functions

The remote control provides easy navigation and management of your frame's features:

- **Power Button:** Short press to turn the screen on/off. Long press to power off or restart.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate menus and select options.
- **Menu Button:** Access settings and options.
- **Return Button:** Go back to the previous screen.
- **Volume Buttons:** Adjust video playback volume.
- **Slideshow Control:** Customize slideshow speed and transition effects.
- **Brightness Adjustment:** Easily adjust screen brightness from 0% to 100%.




Image: Remote control functions for managing visual memories.

### 4.2 Slideshow and Video Playback

The frame supports dynamic slideshows and Full HD 1080P video playback with sound.

- **Dynamic Slideshow:** Customize display settings to enhance your viewing experience.
- **Video Playback:** Play vibrant videos, music MVs, and movies. The frame includes built-in speakers for clear audio.

## HD Video Player with Sound

### Dynamic Slideshow Display

Custom slide show display, enhancing your viewing experience.

### Video Playback

Play vibrant videos, music MVs, movies, and more! This digital can user as a simple video player.

### Built-in Speakers

With built-in integrated speakers, enjoy clear audio playback.

(Tips: There is no time limit for the video uploads via SD card and USB flash driver; The Uhale APP allows you to upload videos up to 2 minutes long.)




Image: HD Video Player with Sound.

## 4.3 Sleep Mode

Customize the sleep mode settings. Even in sleep mode, the digital photo frame can still receive photos and videos.

### Sleep Mode

Customizable sleep mode. Even in sleep mode, the digital photo frame can still receive photos and videos.



🌙 23:30 PM

☀️ 08:30 AM

Image: Sleep Mode functionality.

## 4.4 Sending Blessings/Captions

Send personalized messages and greeting cards to the frame for special occasions. Built-in blessing templates are available.



## Send Blessings Anytime, Anywhere

Send your warmest wishes to friends and family on special holidays with greeting cards. (featuring various module options)



Image: Send blessings anytime, anywhere.

## 4.5 Managing Photos and Videos

The frame offers various options for managing your media:

- **Favorite:** Mark photos as favorites for quick access.
- **Lock:** Prevent accidental deletion of important photos.
- **Hide:** Temporarily remove photos from the slideshow without deleting them.
- **Delete:** Permanently remove unwanted photos/videos.
- **Adjust Photo:** Fine-tune display settings for individual photos.
- **Rotate Photo:** Manually adjust photo orientation if auto-rotate is not desired.

## 5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and frame. Avoid abrasive cleaners or solvents.
- **Software Updates:** The Uhale app provides free software upgrade features, ensuring your frame stays up-to-date with the latest functionalities.
- **Storage Management:** Regularly review and delete unwanted photos/videos to manage the 64GB internal storage. Utilize SD cards or USB drives for additional storage.

## 6. TROUBLESHOOTING

- **Frame not powering on:** Ensure the power adapter is securely connected to both the frame and a working power outlet.
- **Cannot connect to Wi-Fi:** Verify the Wi-Fi password is correct. Ensure the frame is within range of your Wi-Fi router. Try restarting the frame and your router.
- **Photos not appearing on frame:** Check the Uhale app's transfer history to confirm successful uploads. Ensure the frame is connected to Wi-Fi. Verify the frame is bound correctly to your app.
- **SD Card/USB Drive not recognized:** Ensure the storage device is formatted to FAT32. Check that the device is inserted correctly into the slot.

- **Remote control not working:** Ensure batteries are correctly inserted and have sufficient charge. Point the remote directly at the frame's receiving point.

## 7. SPECIFICATIONS

Feature	Detail
Brand	FANGOR
Model Number	320KZ
Screen Size	32 Inches
Resolution	1920 x 1080 (Full HD)
Display Type	IPS Display with 178° Wide Viewing Angle
Internal Memory	64GB (stores up to 160,000 photos)
External Storage	Supports SD Card (Max 128GB) and USB Drive (Max 128GB), FAT32 format
Connectivity	2.4G+5G Dual Wi-Fi
Supported Formats	JPG, JPEG, BMP, PNG, MP4 videos
Control Method	Remote Control, Uhale App
Mounting Options	Tabletop Stand, Wall Mountable
Product Dimensions	16 x 25 x 0.99 inches
Item Weight	19 pounds

### Premium Picture Display

Keep every frame of the picture without distortion.



32 Inch  
large Size



1920 x 1080  
Resolution



FHD-IPS  
Screen



16:9  
Aspect Ratio



178°  
Wide View



Superior  
Color Fidelity




Image: Premium Picture Display details.



## 178° Wide-Angle Field of View FHD IPS Screen

Excellent display effect even at extreme viewing angles



178°

Image: 178° Wide-Angle Field of View.

## 8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided in the product packaging or visit the official FANGOR website. The Uhale app developer is committed to user privacy and does not collect data from the app. The app is GDPR and CCPA compliant.

### Securely & Privately

- The Uhale developer promises not to collect any data from the Uhale APP.
- Uhale APP participates in the IAB Europe Transparency & Consent Framework and complies with its Specifications and Policies. use the Consent Management Platform with the identification number 300.
- Uhale APP uses encryption to keep your data private in transit; Unauthorized users cannot access your frame.



Image: Secure and Private App Usage.

© 2024 FANGOR. All rights reserved.

Related Documents - 320KZ



[FANGOR F-206 Multimedia Projector Instruction Manual](#)

Comprehensive instruction manual for the FANGOR F-206 multimedia projector, covering setup, operation, connectivity, features, specifications, and troubleshooting. Learn how to connect various devices via HDMI, VGA, AV, USB, and SD card, and utilize wireless casting features like iOS Cast and Miracast.

[FANGOR F-601 WiFi Projector Quick Guide: iOS and Android Connection](#)

A quick guide on how to connect iOS and Android devices to the FANGOR F-601 WiFi projector using WiFi or USB cables for screen mirroring.

iOS/Android WiFi/USB Cable Connection

### iOS Connection with WIFI

1. Press "SOURCE" on remote control or push  on projector, choose "Screen Mirroring." Loading time 5-10 seconds.



2. You can find the DDO and PDK on the screen



3. Connect the SSD to your iOS phone.



4. Open the Screen Mirroring, and choose the correct SSD name.



5. Connected



### iOS Connection with lightning Cable

1. Press "SOURCE" on remote control or push  on projector, choose "Screen Mirroring." Loading time 5-10 seconds.



3. Click "Trust" and input your screen lock password. If no password, ignore it.



4. Connected



### Andriod Connection with WIFI

1. Press "SOURCE" on remote control or push  on projector, choose "Screen Mirroring." Loading time 5-10 seconds.



3. Open the "Multi-screen / Miracast" function on the Android device.  
Different brands of mobile phones have different projection names.



4. Connect the device "Outlast.exe" if there is two device with different icon. Choose the one with the Will logo.



5. Connected



HD Wi-Fi Multimedia Projector  
INSTRUCTION MANUAL



3. Choose **File Transfer Method (Transfer files)** and open **File debugging**.



- Re-plug the USB **TORE** to activate the prompt TORE:
- File: Bluetooth name: P-J-BT.



5. Connected



This instruction manual provides detailed information on the FANGOR F-402 HD Wi-Fi Multimedia Projector, covering setup, operation, connectivity, and troubleshooting.

A comprehensive quick guide for connecting your FANGOR S20 sound bar to various devices using HDMI ARC, SPDIF, or Bluetooth, including essential setup tips and troubleshooting advice.