

## Xiaomi Xiaomi Redmi Note 14 4G

# Xiaomi Redmi Note 14 4G LTE User Manual

Model: Xiaomi Redmi Note 14 4G

## INTRODUCTION

The Xiaomi Redmi Note 14 4G LTE is a versatile smartphone designed for global use, featuring advanced camera capabilities, a durable display, and efficient performance. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and user experience.

## WHAT'S IN THE BOX

Upon unboxing your Xiaomi Redmi Note 14 4G LTE, verify that the following items are included:

- Xiaomi Redmi Note 14 4G LTE Smartphone (with included battery)
- USB Cable
- Wall Adapter
- SIM Tray Ejector

## DEVICE OVERVIEW

Familiarize yourself with the physical components of your Redmi Note 14 4G LTE.



**Figure 1:** Front and Rear View of the Xiaomi Redmi Note 14 4G LTE. This image displays the phone's sleek design, including the display on the front and the camera module and Redmi branding on the back.



**Figure 2:** Side Views of the Xiaomi Redmi Note 14 4G LTE. This image highlights the phone's slim profile, showing the power button, volume rocker, USB-C port, speaker grille, and 3.5mm audio jack.

- **Front Display:** 6.67-inch AMOLED display with a punch-hole camera.
- **Rear Camera Module:** Houses the 108MP main camera, 2MP depth camera, and 2MP macro camera.
- **Power Button:** Located on the right side, used to power on/off and lock/unlock the screen.
- **Volume Buttons:** Located above the power button, used to adjust media and call volume.
- **USB-C Port:** Located at the bottom, for charging and data transfer.
- **3.5mm Audio Jack:** Located at the top, for connecting wired headphones.
- **SIM Tray:** Located on the side, for inserting SIM and microSD cards.

## SETUP

### 1. Inserting SIM and MicroSD Cards

1. Locate the SIM tray on the side of the device.
2. Insert the SIM tray ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray. Ensure the gold

contacts face downwards.

4. Carefully reinsert the tray into the phone until it clicks into place.

## 2. Initial Power On and Setup

1. Press and hold the Power button until the Xiaomi logo appears.
2. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account sign-in, and security settings.

## 3. Charging the Device

Before first use, it is recommended to fully charge your device.



**Figure 3:** Illustration of the Xiaomi Redmi Note 14 4G LTE's 33W fast charging capability and 5500mAh battery. This image shows the phone's internal components and highlights charging times: 40 minutes to 55% and 77 minutes to 100%.

- Connect the USB cable to the USB-C port on your phone.
- Connect the other end of the USB cable to the provided wall adapter.
- Plug the wall adapter into a power outlet.
- The device supports 33W fast charging and features a large 5500mAh battery for extended use.

## OPERATING YOUR DEVICE

## Basic Navigation

The Redmi Note 14 4G LTE operates on Hyper OS based on Android 14, offering intuitive touch and gesture controls.

- **Tap:** Select items or open applications.
- **Swipe:** Navigate through screens, menus, or content.
- **Pinch-to-Zoom:** Enlarge or reduce content on the screen.
- **Long Press:** Access contextual menus or move icons.

## Display Features

The 6.67-inch AMOLED display offers vibrant visuals and smooth interactions.

- **Refresh Rate:** Up to 120Hz for fluid scrolling and gaming.
- **Brightness:** Up to 1800 nits peak brightness for clear visibility even in direct sunlight.
- **Reading Mode:** Reduces blue light to protect your eyes during prolonged reading.
- **Wet Finger Touch:** The screen maintains accurate touch recognition even with oil, water, or foam on the surface.

## Camera Usage

Capture stunning photos and videos with the advanced triple camera system.



**Figure 4:** Flagship-level camera setup of the Xiaomi Redmi Note 14 4G LTE. This image details the 108MP main camera, 2MP depth camera, and 2MP macro camera, highlighting the phone's photographic capabilities.

- **108MP Main Camera:** For high-resolution photos with exceptional detail, featuring 3x lossless zoom and Super Resolution algorithms.
- **2MP Depth Camera:** Enhances portrait mode with natural background blur.
- **2MP Macro Camera:** Allows for close-up shots of small objects.
- **RAW Domain Algorithm:** Improves night photography by retaining more image details in low-light conditions.
- **Front Camera:** 20MP sensor for clear selfies and video calls.
- **Video Recording:** Supports 1080p at 60fps and 30fps, and 720p at 30fps.

## Connectivity

The device offers comprehensive connectivity options.

- **Network:** Supports 2G, 3G, and 4G LTE bands. Compatible with T-Mobile, Mint, Tello, and other GSM carriers globally.
- **Wi-Fi:** 802.11a/b/g/n/ac, supporting 2.4GHz and 5GHz Wi-Fi.
- **Bluetooth:** Version 5.3 for wireless accessory connection.
- **GPS:** L1, A-GPS, GLONASS, BDS, Galileo E1 for accurate positioning.

## AI-Powered Features

The Redmi Note 14 Series integrates AI for enhanced user experience.

- **Gemini Overlay:** Provides quick access to Gemini and context-aware help based on your screen content. (Requires internet connection and compatible accounts).

## MAINTENANCE

---

### Battery Care

To maximize battery lifespan and performance:



## Smart charging engine

### Healthy charging for a more durable battery

**4 years**  
Ultra-durable\*

The smart battery management system learns your daily charging habits and adjusts the voltage and current in real time to slow down battery degradation. The battery capacity remains above 80% even after 4 years and 1600 cycles, ensuring worry-free use over extended periods.



#### Boost charging

Remove current limitations to increase charging speed at low battery levels.



#### Power on within seconds

Power on instantly when connected to a charger, even from a completely drained state.



#### Battery Health 3.0

Dynamically adjust battery charging logic to delay battery ageing.

**Figure 5:** Smart charging engine for healthy and durable battery life. This image illustrates features like Boost charging, Power on within seconds, and Battery Health 3.0, designed to optimize battery performance and longevity over 4 years.

- Avoid extreme temperatures.
- Use the provided charger and cable.
- The smart battery management system adjusts charging habits to slow down degradation, aiming to retain over 80% capacity after 4 years and 1600 cycles.
- Features like "Boost charging" and "Battery Health 3.0" are integrated to optimize charging and prolong battery life.

### Screen Care

The device features Corning® Gorilla® Glass 5 for enhanced durability.



# All-Star Durability

## Corning® Gorilla® Glass 5 Scratch-resistant and durable

Ultra-hard glass front for enhanced screen protection.



**Figure 6:** All-Star Durability with Corning® Gorilla® Glass 5. This image emphasizes the scratch-resistant and durable ultra-hard glass front designed for enhanced screen protection.

- Clean the screen with a soft, lint-free cloth.
- Avoid harsh chemicals or abrasive materials.
- While durable, avoid dropping the device or exposing it to sharp objects.

### Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements.

- Go to *Settings > About phone > System update*.
- Ensure you have a stable internet connection and sufficient battery life before starting an update.

### TROUBLESHOOTING

This section addresses common issues you might encounter with your device.

Problem	Possible Solution
Device not powering on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
Poor network signal	Check SIM card insertion. Move to an area with better network coverage. Restart the device. Verify compatibility with your carrier's bands.



Problem	Possible Solution
Apps crashing or freezing	Clear app cache/data ( <i>Settings &gt; Apps</i> ). Update the app or the device's operating system.
Battery drains quickly	Reduce screen brightness. Close background apps. Disable unnecessary features like GPS or Bluetooth when not in use. Check battery usage in <i>Settings</i> .
Touchscreen unresponsive	Restart the device. Ensure the screen is clean and dry. Remove any screen protectors that might interfere.

## SPECIFICATIONS

Detailed technical specifications for the Xiaomi Redmi Note 14 4G LTE.

Feature	Detail
Model Name	Note 14 4G
Display	6.67 Inches AMOLED, 2400 x 1080 Resolution, 120Hz Refresh Rate, 1800 nits Peak Brightness, Corning Gorilla Glass 5
Processor	Helio G99-Ultra (Octa-core, up to 2.2GHz)
RAM	8 GB
Storage	256 GB
Rear Camera	108MP Main (f/1.7), 2MP Depth (f/2.4), 2MP Macro (f/2.4)
Front Camera	20MP (f/2.2)
Battery	5500 mAh Lithium Polymer (Included)
Charging	33W Fast Charging
Operating System	Hyper OS Based on Android 14
Connectivity	2G, 3G, 4G LTE, Wi-Fi (802.11a/b/g/n/ac), Bluetooth 5.3, GPS
Audio Jack	3.5 mm
SIM Support	Dual SIM (SIM1 + Hybrid* SIM or MicroSD)
Dimensions	7.01 x 3.58 x 1.46 inches (Package)
Weight	13 ounces

## Compact and lightweight Sleek feel

### Elegant, rounded design

Features seamless, rounded edges for a refined aesthetic



### Compact and lightweight

Thick  
**8.16mm**

Lightweight  
**196.5g**



### A perfect fit in your hand



Slimmer and designed to  
fit the curve of your  
palm for a comfortable  
grip

**Figure 7:** Compact and lightweight design of the Xiaomi Redmi Note 14 4G LTE. This image illustrates the phone's thickness (8.16mm) and weight (196.5g), emphasizing its sleek feel and comfortable grip.

## WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official Xiaomi website or contact their customer service. Keep your proof of purchase for warranty claims.

No official product videos were available for embedding in this manual.