

[Manuals.plus](#) /

› [SakerPlus](#) /

› SakerPlus VAC716 4-in-1 Hand Held Car Vacuum Cordless Instruction Manual

SakerPlus VAC716

SakerPlus VAC716 4-in-1 Hand Held Car Vacuum Cordless Instruction Manual

Model: VAC716

1. INTRODUCTION

Thank you for choosing the SakerPlus VAC716 4-in-1 Hand Held Car Vacuum Cordless. This versatile device is designed for efficient cleaning and utility, offering vacuuming, blowing, inflating, and air extraction functions. Please read this manual thoroughly before use to ensure proper operation, maintenance, and safety.

2. PRODUCT FEATURES

2.1. 4-in-1 Versatility

The SakerPlus VAC716 combines four essential functions:

- **Vacuuming:** For cleaning dust, crumbs, and debris from various surfaces.
- **Blowing:** Ideal for dusting keyboards, car vents, and other hard-to-reach areas.
- **Inflating:** Use for small inflatables like swimming rings.
- **Air Extraction:** Compresses items for space-saving storage.



Vacuum Cleaner



Air Duster

4-IN-1 VERSATILE VACUUM CLEANER



Air Pump



Air Extractor

Image: The SakerPlus VAC716 showcasing its four primary functions: vacuuming, air dusting, air pumping, and air extraction.

2.2. Adjustable Suction Levels

The device features three adjustable suction levels to suit different cleaning needs:

- **Low:** 10000PA
- **Mid:** 15000PA
- **High:** 20000PA

These levels are easily controlled via the touchscreen display.

3-SUCTION LEVEL TOUCHSCREEN ADJUSTMENT

Low

10000PA

MID

15000PA

High

20000PA

Powerful Brushless Motor

✓ Max 20000PA Suction

✓ Max 680L/Min Air Volume

✓ Efficient Cleaning

OTHERS Common Motor

✗ 9000PA Suction

✗ Max 360L/Min Air Volume

✗ Low Efficiency

Image: Visual representation of the three suction levels and touchscreen adjustment.

2.3. Advanced Dual Filtration System

Equipped with a 2-layer filtration system:

- A front filter for larger debris.
- A HEPA filter for fine particles and dust.

Both filters are washable and reusable, extending their lifespan and protecting the motor. Two additional HEPA filters are included.

2.4. Battery & Touchscreen Control

The device features a 7800mAh rechargeable battery, providing up to 40 minutes of runtime on a full charge. Charging is convenient via USB Type-C. The integrated touchscreen display shows real-time battery life and allows for easy suction level adjustments.

2.5. Lightweight & Compact Design

Weighing just 1.12 lbs and measuring 10.6 x 7.5 x 2.6 inches, the vacuum is easy to carry and store, making it suitable for cars, homes, and offices.



Image: The compact size of the SakerPlus VAC716, shown next to a smartphone for scale.

3. PACKAGE CONTENTS

Please check the package for the following items:



Image: All accessories included with the SakerPlus VAC716, clearly labeled.

1. Vacuum Portable Cordless
2. Storage Bag
3. HEPA Filter (2 additional included)
4. Air Extraction Nozzle
5. Floor Brush
6. Long Blowing Pipe with Brush
7. 2-in-1 Flat Nozzle and Brush
8. Long Blowing Pipe
9. Telescopic Hose
10. Floor Brush (additional)
11. Large Inflator Nozzle
12. Middle Blowing Pipe
13. Small Inflator Nozzle
14. Blowing Pipe Adapter
15. Long Blowing Pipe (additional)
16. USB Charging Cable

4. SETUP

4.1. Initial Charging

Before first use, fully charge the vacuum cleaner. Connect the USB Type-C charging cable to the device and a suitable power source (e.g., Type-C charger, power bank, car charger, PC). The LED display will indicate charging status. A full charge takes approximately 4 hours.

TYPE-C FAST CHARGING & TOUCHSCREEN CONTROL



Image: The SakerPlus VAC716 being charged via USB Type-C, illustrating various compatible power sources.

4.2. Attaching Accessories

Select the appropriate nozzle or attachment for your task. Attach it firmly to the vacuum's intake or exhaust port depending on the desired function (vacuuming or blowing/inflating/air extraction).

5. OPERATING INSTRUCTIONS

5.1. Power On/Off and Suction Adjustment

To power on the device, press and hold the power button for 2 seconds. The LED display will illuminate. Tap the power button to cycle through the three suction levels (10000PA, 15000PA, 20000PA). To power off, press and hold the power button again for 2 seconds.

5.2. Vacuuming Mode

Attach the desired vacuuming nozzle (e.g., 2-in-1 flat nozzle with brush, floor brush, or telescopic hose with brush) to the intake port. Select the appropriate suction level and move the nozzle over the area to be cleaned. This mode is effective for car interiors,

carpets, and tight spaces.



Image: Using the vacuum with an extendable hose for cleaning car seat gaps.



Image: Vacuuming car floor with the hose attachment.

5.3. Blowing Mode (Air Duster)

Attach the long blowing pipe with brush or other blowing nozzles to the exhaust port. Use this mode to dislodge dust from delicate electronics, car vents, or other surfaces where vacuuming is not suitable.



Image: Using the device as an air duster to clean a keyboard.

5.4. Inflating Mode (Air Pump)

Attach the appropriate inflator nozzle (small or large) to the exhaust port. Use this to inflate small items such as swimming rings or air cushions.



Image: Inflating a swimming ring using the air pump function.

5.5. Air Extraction Mode

Attach the air extraction nozzle to the exhaust port. This mode is useful for compressing vacuum storage bags to save space.



Image: Using the air extraction function to compress items in a storage bag.

5.6. Important Note

DO NOT ABSORB WATER OR LIQUIDS with this device. It is designed for dry use only.

6. CHARGING

The SakerPlus VAC716 is equipped with a 7800mAh battery. To charge, connect the provided USB Type-C cable to the charging port on the device and a compatible USB power adapter. The touchscreen display will show the battery level during charging. A full charge takes approximately 4 hours and provides up to 40 minutes of continuous operation, depending on the suction level used.



Image: The SakerPlus VAC716 being charged in a car.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your SakerPlus VAC716.

7.1. Emptying the Dust Cup

The 200ml dust cup features a one-click emptying mechanism for hassle-free cleaning. Ensure the vacuum is powered off before emptying. Press the release button to open the dust cup and empty its contents into a trash bin.



Image: One-click dust cup emptying process.

7.2. Cleaning the Filters

The front filter and HEPA filter are washable and reusable. Follow these steps:

1. Ensure the vacuum cleaner is powered off.
2. Use the one-click dust dumping to empty the container.
3. Take out the filter carefully.
4. Brush off dust, wash the HEPA filter with water if needed.
5. Wash the dust cup.
6. Let the filter and dust cup dry completely before reassembling.

The HEPA filter has a lifespan of up to 10 washes before replacement. Two additional HEPA filters are provided with your

purchase.



Image: Detailed steps for cleaning the dust cup and HEPA filter.

8. TROUBLESHOOTING

If you encounter issues with your SakerPlus VAC716, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Power button not held long enough.	Charge the device fully; Press and hold the power button for 2 seconds.
Low suction power.	Dust cup full; Filters clogged; Attachment not properly sealed.	Empty the dust cup; Clean or replace filters; Ensure attachments are securely fitted.
Short battery runtime.	Battery not fully charged; Using high suction level continuously.	Ensure device is fully charged (4 hours); Use lower suction levels when possible.
Blowing/Inflating/Air Extraction not effective.	Nozzle not properly attached to exhaust port; Obstruction in exhaust.	Ensure nozzle is securely attached to the exhaust port; Check for and remove any obstructions.

9. SPECIFICATIONS

Feature	Specification
Brand	SakerPlus
Model Name	VAC716
Special Feature	Cordless
Filter Type	HEPA Filter
Maximum Suction	20000 PA
Battery Capacity	7800mAh
Battery Life	Up to 40 minutes
Charging Time	Approx. 4 hours (USB Type-C)

Feature	Specification
Dust Cup Capacity	200ml
Item Weight	1.12 pounds
Product Dimensions	10.7"L x 7.59"W x 2.65"H
Number of Speeds/Power Levels	3
Indoor/Outdoor Usage	Indoor
Power Source	Cordless Electric

10. SAFETY INFORMATION

Please observe the following safety precautions:

- Do not use the device to vacuum water or any liquids.
- Keep the device away from children and pets.
- Do not block the air intake or exhaust ports during operation.
- Ensure filters are clean and dry before reassembly to prevent motor damage.
- Do not expose the device to extreme temperatures or direct sunlight.
- Use only the provided charging cable or a compatible USB Type-C cable.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if needed.
- Dispose of the battery and device according to local regulations.

11. PRODUCT VIDEO

Watch the official product video for a visual guide on the SakerPlus VAC716's features and usage.

Your browser does not support the video tag.

Video: An overview of the SakerPlus VAC716 Hand Held Car Vacuum Cordless, demonstrating its various functions and accessories.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question