Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bealife 3.35 x 3.35 m Pop-Up Gazebo

Bealife 3.35 x 3.35 m Pop-Up Gazebo with Adjustable Height

Instruction Manual

Introduction

Thank you for choosing the Bealife 3.35 x 3.35 m Pop-Up Gazebo. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your gazebo. Please read all instructions carefully before use and retain this manual for future reference.

This gazebo is designed for temporary outdoor use, providing shade and protection from light rain and insects. It features a robust steel frame, a water-repellent polyester roof with UV protection, and integrated mosquito nets.



Image: The Bealife Pop-Up Gazebo providing a comfortable outdoor living space in a garden setting.

Safety Information

- **Assembly:** Always assemble the gazebo with at least two people. Ensure all parts are securely connected before use.
- **Weather Conditions:** This gazebo is designed for fair weather conditions. Do not use in strong winds, heavy rain, or snow. Disassemble and store the gazebo during adverse weather to prevent damage and ensure safety.
- **Anchoring:** Always use the provided sandbags, stakes, and ropes to secure the gazebo to the ground. Failure to do so may result in the gazebo being lifted by wind, causing damage or injury.
- **Fire Safety:** Keep all flame and heat sources away from the gazebo fabric. The fabric is not fireproof.
- **Children:** Keep children away from the gazebo during assembly and disassembly. Do not allow children to play unsupervised around the gazebo.
- **Maintenance:** Regularly inspect the frame and fabric for any signs of wear or damage. Do not use if damaged.

Package Contents

Please verify that all components listed below are present in your package before beginning assembly. If any parts are missing or damaged, please contact customer support.



Image: All components included in the Bealife Pop-Up Gazebo package.

- 1 x Canopy Frame
- 1 x Top Cover Cloth (Main Canopy)
- 1 x Small Cover Cloth (Upper Vent Canopy)
- 4 x Mosquito Net Walls (with zippers)
- 4 x Sandbags
- 8 x Stakes
- 4 x Ropes
- 1 x Wheeled Storage Bag

Setup Instructions

Follow these steps for quick and easy assembly. Two people are required for safe setup.



Image: Visual guide for the four main steps of gazebo assembly.

1. **Step 1: Unfold the Tent Frame Ajar**
   With a partner, gently pull the gazebo frame outwards from opposite corners until it is partially open. Do not fully extend yet.
2. **Step 2: Attach the Canopy Top**
   Place the main canopy fabric (Top Cover Cloth) over the partially opened frame. Ensure the corners are aligned and the fabric is centered. Secure the small cover cloth (upper vent canopy) to the top of the frame.
3. **Step 3: Unfold the Tent Frame Fully**
   Continue to pull the frame outwards until it is fully extended and locked into place. Use the push-button latches on the legs to adjust the height to your desired level (2.65m, 2.75m, or 2.85m). Ensure all four legs are locked at the same height.

4. **Step 4: Attach the Mosquito Net**
   Attach the four mosquito net walls to the gazebo frame using the integrated fasteners. Zip them together at the corners to create an enclosed space.
5. **Step 5: Secure the Gazebo**
   Fill the four sandbags with sand or other heavy material and attach them to the gazebo legs. Use the provided stakes and ropes to anchor the gazebo securely to the ground, especially in windy conditions.

Operating Instructions

Adjusting Height

The gazebo features three adjustable height positions: 2.65m, 2.75m, and 2.85m. To adjust the height, locate the push-button latches on each leg. Press the button and slide the inner leg up or down to the desired position. Ensure the button clicks into place securely at all four legs for stability.



Image: Close-up of the securing button for height adjustment on the gazebo leg.

Using Mosquito Nets

The gazebo includes four zip-up mosquito net walls. These can be zipped together to create a fully enclosed space, protecting against insects while maintaining ventilation. When not needed, the nets can be rolled up and secured to the gazebo legs using the attached ties.




Image: The gazebo demonstrating both good ventilation and anti-mosquito functionality with its nets.

Maintenance

Cleaning

- **Fabric:** Clean the canopy and mosquito nets with a mild soap and water solution. Do not use harsh detergents or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Frame:** Wipe the steel frame with a damp cloth to remove dirt and debris. Ensure the frame is dry to prevent rust.

Storage

When not in use, especially during off-season or adverse weather, disassemble the gazebo and store it in the provided wheeled storage bag. Store in a cool, dry place away from direct sunlight to prolong the life of the fabric and frame.

Troubleshooting

- **Gazebo difficult to open/close:** Ensure all locking mechanisms are disengaged. Apply a silicone-based lubricant to moving parts if necessary. Do not force the frame.
- **Water pooling on canopy:** Ensure the canopy is taut and properly secured to the frame. Adjust the height evenly on all legs.
- **Gazebo unstable:** Verify that all legs are locked at the same height and that the frame is fully extended. Ensure sandbags are filled and attached, and stakes/ropes are used to anchor the gazebo firmly to the ground.
- **Mosquito nets not closing properly:** Check for any obstructions in the zippers. Ensure the nets are correctly attached to the frame.

Specifications




Image: Detailed dimensions of the Bealife Pop-Up Gazebo, including height adjustments and packed size.

Feature	Detail
Brand	Bealife
Model	3.35 x 3.35 m Pop-Up Gazebo
Product Dimensions (L x W x H)	3.35 m x 3.35 m x (2.65m / 2.75m / 2.85m)
Adjustable Height Positions	2.65m, 2.75m, 2.85m
Material	Polyester (canopy), Steel (frame)
Water Resistance Level	Water Repellent
Ultraviolet Light Protection	Yes (Silver coated PU coating)
Occupancy	7-10 people (11.2 m² area)
Item Weight	23 Kilograms
Assembly Required	Yes

Warranty and Support

Bealife stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or contact Bealife customer support directly. If you encounter any issues or have questions regarding your gazebo, please reach out to our customer service team for assistance.
Customer Support: For assistance, please visit the Bealife store on Amazon or refer to the contact information provided in your product packaging.

© 2026 Bealife. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRFZ48ZB

More documents and user manuals: **https://manuals.plus/**