

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BN-LINK](#) /

› [BN-LINK BNC-60/U203R Outdoor Power Stake with Timer and Remote Control - User Manual](#)

## BN-LINK BNC-60/U203R

# BN-LINK BNC-60/U203R Outdoor Power Stake with Timer and Remote Control

Model: BNC-60/U203R

## INTRODUCTION

The BN-LINK BNC-60/U203R Outdoor Power Stake is designed to provide convenient and reliable power for your outdoor electrical devices. This unit features 6 grounded outlets, a 25-foot extension cord, and a 100-foot remote control, along with a waterproof dusk-to-dawn light timer. It is ideal for powering patio lights, holiday decorations, garden tools, and other outdoor equipment in various weather conditions.

## SAFETY INFORMATION

**WARNING: Read all instructions before use. Failure to follow these instructions may result in fire, electric shock, serious injury, or property damage.**

- Do not immerse the unit in water.
- Ensure all connections are secure and protected from moisture.
- Do not exceed the maximum electrical ratings: 15A/1875W Resistive, 10A/1250W Tungsten, or 1/2 Horsepower.
- Do not use with extension cords to connect the timer to a power source.
- Do not use the unit to control anything with heating elements.
- Keep children and pets away from the unit during operation.
- Place the power stake in an area where the light sensor is not obstructed by artificial light sources or dense foliage to ensure proper dusk-to-dawn functionality.

## PACKAGE CONTENTS

- BN-LINK Outdoor Power Stake with 6 Outlets and 25ft Extension Cord
- Ground Stake
- Wireless Remote Control (with battery)
- Instruction Manual

## PRODUCT FEATURES

- **25FT Outdoor Range:** Long extension cord for flexible placement.
- **6 Grounded Outlets:** Expand a single outlet to six for multiple devices.
- **Timer Control Options:** Includes Always On, Dusk-to-Dawn, and customizable 2/4/6/8-hour modes.
- **100FT Wireless Remote Control:** Adjust settings from a distance with the RF remote.
- **Quick-Ground Stake:** Securely install the unit in your lawn or garden.
- **Weatherproof Design:** Durable construction to withstand rain, sun, and dirt.
- **Overload Protection Switch:** For enhanced safety.

## SPECIFICATIONS

<b>Brand</b>	BN-LINK
<b>Model</b>	BNC-60/U203R
<b>Part Number</b>	203R 25ft
<b>Voltage</b>	125 Volts
<b>Wattage</b>	1875 watts
<b>Amperage</b>	15 Amps
<b>Number of Outlets</b>	6
<b>Cord Length</b>	25 feet
<b>Remote Control Range</b>	100 feet (RF)
<b>Material Type</b>	Plastic
<b>Color</b>	Green
<b>Compatible Devices</b>	Lights, pool pumps, fountains, holiday decorations

## SETUP AND INSTALLATION

Follow these steps to set up your BN-LINK Outdoor Power Stake:

1. **Assemble the Stake:** Securely attach the ground stake to the bottom of the power stake unit. Ensure it is firmly connected.
2. **Position the Unit:** Choose a suitable outdoor location for the power stake. Insert the ground stake firmly into the soil, ensuring the unit is stable and at least 1 foot above ground level to prevent waterlogging. Position the unit so the light sensor (if using dusk-to-dawn mode) is not obstructed by artificial light sources or dense foliage.
3. **Connect to Power:** Plug the 25ft extension cord of the power stake into a grounded outdoor electrical outlet.
4. **Plug in Devices:** Open the protective covers of the desired outlets and plug in your outdoor devices (e.g., lights, pumps). Ensure plugs are fully inserted and covers are closed when not in use to maintain weather resistance.

# Product Dimensions



Image: Product dimensions and components of the BN-LINK Outdoor Power Stake.

Video: Demonstrates the unboxing, assembly, and initial setup of the BN-LINK Outdoor Power Stake.

## OPERATING INSTRUCTIONS

The power stake offers multiple operating modes, which can be selected using the dial on the unit or the remote control.

### Timer Modes (Dial on Unit)

1. **OFF:** Power is off to all attached devices.
2. **ON:** Power is continuously supplied to all attached devices.
3. **Dusk-to-Dawn:** Power turns on automatically at dusk and remains on until dawn.
4. **2H/4H/6H/8H:** Power turns on at dusk and remains on for the selected duration (2, 4, 6, or 8 hours).

### Remote Control Operation

The included wireless RF remote control allows you to manage the power stake from up to 100 feet away. The remote has buttons for ON, OFF, DUSK, and timed modes (2H, 4H, 6H, 8H).

- Press **ON** to turn on power continuously.

- Press **OFF** to turn off power.
- Press **DUSK** to activate the dusk-to-dawn mode.
- Press **2H/4H/6H/8H** to activate the corresponding timed mode, starting at dusk.



light sensor



always on/off



countdown  
2/4/6/8hours

Image: Detailed view of the timer dial and light sensor on the power stake.

Video: Illustrates the mechanical timer settings and waterproof features of a similar outdoor power stake.

## MAINTENANCE

- Regularly inspect the unit and cord for any signs of damage, fraying, or wear. Discontinue use if damage is found.
- Keep outlet covers closed when not in use to protect against dust, dirt, and moisture.
- Clean the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the light sensor is clean and unobstructed for accurate dusk-to-dawn operation.
- Store the unit in a dry, protected area during off-season or prolonged periods of non-use.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Devices not turning on.	Unit is unplugged, timer is in OFF mode, overload protector tripped, or device is faulty.	Ensure unit is plugged in. Set timer to ON or desired mode. Check and reset the overload protector. Test the device in another outlet.
Dusk-to-Dawn mode not working correctly.	Light sensor is obstructed or exposed to artificial light.	Relocate the unit to an area where the light sensor receives natural light only. Clean the sensor.
Remote control not working.	Battery is dead or remote is out of range.	Replace the remote control battery (Alkaline). Move closer to the power stake (within 100ft).
Plugs with large transformers do not fit.	Outlet design is for standard plugs.	Use a short extension cord or adapter for bulky plugs if necessary, ensuring it is rated for outdoor use and does not exceed the unit's capacity.

## WARRANTY AND SUPPORT

For warranty information or technical support, please contact BN-LINK customer service. You can reach them at:

- **Phone:** 888-491-5507 ext 101
- **Website:** [Visit the BN-LINK Store on Amazon](#)