

[Manuals.plus](#) /

› [taopodo](#) /

› taopodo M13-BK Portable Bluetooth Speaker User Manual

taopodo M13-BK

taopodo M13-BK Portable Bluetooth Speaker User Manual

Model: M13-BK

1. INTRODUCTION

Thank you for choosing the taopodo M13-BK Portable Bluetooth Speaker. This powerful and versatile speaker is designed to deliver high-quality audio with dynamic RGB lighting, long battery life, and robust waterproof capabilities. Please read this manual carefully before use to ensure proper operation and to maximize your listening experience.

2. WHAT'S IN THE BOX

- 1 x taopodo M13-BK Bluetooth Speaker
- 1 x Type-C Charging Cable
- 1 x AUX Cable
- 1 x Portable Lanyard
- 1 x User Manual

3. PRODUCT OVERVIEW



Figure 3.1: taopodo M13-BK Portable Bluetooth Speaker (Front View)

This image shows the overall design of the taopodo M13-BK speaker, highlighting its cylindrical shape, speaker grille, and control panel with illuminated buttons.

A Better Experience





Bluetooth 5.4



IPX7 Waterproof



Built-in Microphone

Figure 3.2: Key Features of taopodo M13-BK Speaker

This image illustrates the speaker's advanced features including Bluetooth 5.4 connectivity, IPX7 waterproof rating, and a built-in microphone for hands-free calls.

Control Panel and Ports:

ADATTO A PIÙ SCENE



Figure 3.3: Control Panel Button Functions

This diagram details the functions of each button on the speaker's control panel, including power, volume, track control, EQ mode, and TWS pairing.

- **Power Button:** Press and hold for 2 seconds to power on/off. Single press to play/pause.
- **Light Button:** Single press to change light mode. Double press to turn lights on/off.
- **Volume Down / Previous Track:** Single press for volume down. Press and hold for 2 seconds for previous track.
- **Volume Up / Next Track:** Single press for volume up. Press and hold for 2 seconds for next track.
- **EQ Button:** Single press to cycle through EQ modes (Bass, Treble, Vocal).
- **Call Button:** Single press to answer/end call. Press and hold for 2 seconds to reject call.
- **TWS Button:** Press and hold for 2 seconds to initiate TWS pairing.
- **DC5V Port:** For charging the speaker.
- **USB Port:** For USB playback or charging out.
- **TF Card Slot:** For playing music from a TF (MicroSD) card.
- **AUX Port:** For wired audio connection via 3.5mm AUX cable.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the DC5V port on the speaker and the other end to a USB power adapter (not included) or a computer USB port. The charging indicator light will show charging status and turn off when fully charged.

A full charge provides up to 30 hours of playtime at 50% volume with lights off.

All Day Playtime



Figure 4.1: Speaker Battery Life Illustration

This image visually represents the speaker's impressive 30-hour battery life, ideal for extended use.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on, press and hold the **Power Button** for 2 seconds.
- To power off, press and hold the **Power Button** for 2 seconds again.

5.2 Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. Enable Bluetooth on your device (smartphone, tablet, laptop, etc.).
3. Search for "M13-BK" in the list of available Bluetooth devices.
4. Select "M13-BK" to connect. Once connected, the LED light will stop flashing and remain solid.

5. The speaker is now ready to play audio from your device.

5.3 True Wireless Stereo (TWS) Pairing

TWS allows you to connect two M13-BK speakers for a true stereo sound experience.



Figure 5.1: True Wireless Stereo (TWS) Setup

This image demonstrates how two taopodo M13-BK speakers can be paired together for an immersive stereo audio experience, ideal for larger spaces or enhanced sound.

1. Ensure both M13-BK speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the **TWS Button** for 2 seconds. You will hear an indication sound.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a confirmation sound.
4. Now, connect your device to the primary speaker via Bluetooth as described in section 5.2. The audio will play in stereo through both speakers.

5.4 Audio Playback (AUX & TF Card)

- **AUX Mode:** Insert the provided 3.5mm AUX cable into the AUX port on the speaker and connect the other end to your audio source. The speaker will automatically switch to AUX mode.
- **TF Card Mode:** Insert a TF (MicroSD) card with music files (MP3, WAV, etc.) into the TF card slot. The speaker will automatically detect the card and begin playing music.

5.5 RGB Light Control

The speaker features dynamic RGB lighting with multiple modes.

3 Dynamic RGB Lights

5 Change Modes * 30 Light Changes



Figure 5.2: Dynamic RGB Lighting

This image showcases the vibrant and dynamic RGB lighting effects of the taopodo M13-BK speaker, which can enhance any listening environment.

- Single press the **Light Button** to cycle through different RGB light modes.
- Double press the **Light Button** to turn the RGB lights on or off.

5.6 EQ Modes

Adjust the sound profile to your preference using the EQ modes.

ADATTO A PIÙ SCENE



Figure 5.3: Equalizer (EQ) Modes

This image illustrates the different EQ modes available on the speaker, allowing users to customize the audio output for bass, treble, or vocal emphasis.

- Single press the **EQ Button** to cycle through available sound modes (e.g., Bass Boost, Vocal, Standard).

5.7 Hands-Free Calling

When connected via Bluetooth to a smartphone, you can use the speaker for hands-free calls.

- To answer an incoming call, single press the **Call Button**.
- To end an ongoing call, single press the **Call Button**.
- To reject an incoming call, press and hold the **Call Button** for 2 seconds.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not in use for extended periods. Avoid fully discharging the battery frequently.
- **Water Exposure:** While IPX7 waterproof, ensure the charging port and other openings are dry before charging. Avoid prolonged submersion.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Bluetooth disabled on device; device too far.	Ensure speaker is in pairing mode (flashing LED). Enable Bluetooth on your device. Move device closer to speaker (within 10 meters). Forget previous connections on your device.

Problem	Possible Cause	Solution
No sound.	Volume too low; incorrect input mode; device not playing.	Increase speaker and device volume. Ensure correct input mode (Bluetooth, AUX, TF). Check if music is playing on the connected device.
TWS pairing fails.	Speakers already connected to other devices; speakers too far apart.	Disconnect both speakers from any Bluetooth devices. Ensure they are close to each other. Try TWS pairing again.
Sound distortion.	Volume too high; audio source quality; interference.	Lower the volume. Try a different audio source. Move away from sources of interference (e.g., Wi-Fi routers, other Bluetooth devices).

8. SPECIFICATIONS

Feature	Detail
Model Number	M13-BK
Output Power	30 Watts
Speaker Drivers	Dual 55mm Full-Range Drivers
Bluetooth Version	5.4
Bluetooth Range	Up to 20 meters (66 feet)
Battery Capacity	4000 mAh
Playtime	Up to 30 hours (at 50% volume, lights off)
Waterproof Rating	IPX7
Dimensions (L x W x H)	8.5 x 8.5 x 20.8 cm (3.35 x 3.35 x 8.19 inches)
Weight	900 grams (1.98 lbs)
Connectivity	Bluetooth 5.4, AUX-in, TF Card, USB
Special Features	RGB LED Lights, TWS Pairing, Built-in Microphone, DSP Audio Processing
Material	Acrylonitrile Butadiene Styrene (ABS)

9. WARRANTY AND SUPPORT

taopodo products are designed and manufactured to the highest quality standards. This product comes with a limited warranty. For specific warranty details and terms, please refer to the warranty information provided at the time of purchase or contact taopodo customer support.

For technical support, troubleshooting assistance, or any inquiries regarding your taopodo M13-BK speaker, please contact our customer service team through the retailer's support channels or visit the official taopodo website for contact information.

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DRG3G6BS>

More documents and user manuals: <https://manuals.plus/>