

[Manuals.plus](#) /

› [HRVEOCEI](#) /

› HRVEOCEI Swivel Rocking Recliner Chair Instruction Manual

HRVEOCEI Lazy Boy Recliners for Living Room

HRVEOCEI Swivel Rocking Recliner Chair Instruction Manual

Model: Lazy Boy Recliners for Living Room

1. INTRODUCTION

Thank you for choosing the HRVEOCEI Swivel Rocking Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read all instructions carefully before use and retain this manual for future reference.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure the chair's weight limit of **335 pounds** is not exceeded to maintain stability and prevent damage.
- Always follow the assembly instructions carefully to prevent any potential hazards.
- Be aware of potential variations in color and size as depicted in marketing materials.
- Keep children and pets away from moving parts during operation.
- Do not stand on the footrest or armrests.
- Avoid placing the recliner near heat sources or in direct sunlight to prevent material degradation.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present. A visual guide to the package contents is available in the assembly video in the next section.

- Rack (x1)
- Backrest Iron Frame (x1)

- Back (x1)
- Armrest Cover (x2)
- Cushion (x1)
- Screws (x10)
- Long Screws (x10)
- Wrench (x1)
- Glove (x1)

4. SETUP AND ASSEMBLY

Follow these steps to assemble your HRVEOCEI Swivel Rocking Recliner Chair. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Base:** Insert individual components into D-6 and then insert D-7. Ensure all pieces fit securely.
3. **Secure Handrail:** Bury the nut in the corresponding position and secure the screw on the handrail with the provided wrench.
4. **Cover Handrail:** Cover the handrail on the assembled handrail and zip it up.
5. **Attach Arms:** Insert arms into the seat. You will hear a "click" when they are engaged.
6. **Expand Sofa and Attach Cushion:** Pull the handle up to expand the sofa, cover the cushion, and stick the three Velcro strips to secure it.
7. **Attach Back Pad:** Plug the back pad into the seat frame.

Your browser does not support the video tag.

Video: Step-by-step assembly guide for the Swivel Rocking Recliner Chair. This video demonstrates unpacking, assembling the base, attaching armrests, and securing the backrest.

5. OPERATING INSTRUCTIONS

Your recliner chair offers multiple comfort positions and features:

- **Reclining Function:** Use the side handle to recline the chair up to 135 degrees. The footrest will pop out automatically. Release the handle to lock the position.
- **360° Swivel:** The chair base allows for a full 360-degree rotation, providing flexibility in your seating arrangement.
- **Rocking Feature:** The chair provides a gentle rocking motion for added relaxation.
- **Footrest Retraction:** To retract the footrest, apply gentle pressure with your legs while sitting upright.

RECLINING FUNCTION



Reading



Watching TV



Napping



Image: Demonstrates the reclining function, illustrating three common positions: reading, watching TV, and napping. A side handle is used to activate the recline and extend the footrest.

360° SWIVEL



Image: Shows the 360-degree swivel capability of the recliner chair, with arrows indicating rotation.

Rocking

Rock Your Body

The gentle rocking motion soothes and relieves stress.



Image: Illustrates the rocking feature of the recliner chair, showing its gentle back-and-forth movement.

Product Features



Image: Details product features including convenient side pockets for storage and the adjustable footrest mechanism.

Your browser does not support the video tag.

Video: Demonstrates the rocking, rotating, and footrest retraction features of the recliner chair, showcasing its versatility.

6. MAINTENANCE

Proper care will extend the life of your recliner chair:

- **Cleaning Fabric:** For general cleaning, use a soft brush or vacuum cleaner to remove dust and debris. For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner according to the product instructions, testing on an inconspicuous area first.
- **Frame Care:** Periodically check all screws and bolts to ensure they are tight. Retighten as necessary.
- **Moving Parts:** The reclining mechanism is designed for smooth operation. Avoid forcing the mechanism. If it becomes stiff, a small amount of silicone-based lubricant can be applied to pivot points, avoiding contact with

fabric.

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position the chair away from direct sun or use curtains/blinds.

7. TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|--|
| Chair does not recline smoothly. | Mechanism obstruction or loose connections. | Check for any objects obstructing the mechanism. Ensure all assembly bolts are tightened. Apply silicone lubricant to pivot points if necessary. |
| Footrest does not extend or retract properly. | Mechanism obstruction or improper engagement. | Verify no items are blocking the footrest. Ensure the side handle is fully engaged when reclining. Apply gentle leg pressure for retraction. |
| Chair feels unstable or wobbly. | Loose assembly bolts or uneven floor. | Check and tighten all assembly bolts. Ensure the chair is placed on a level surface. |

If the problem persists, please contact customer support.

8. SPECIFICATIONS

- **Brand:** HRVEOCEI
- **Model Name:** Swivel Rocking Chair Recliner
- **Product Dimensions:** 36"D x 35"W x 41"H
- **Color:** Brown
- **Material:** Textile (Linen finish), Foam fill
- **Maximum Weight Recommendation:** 335 Pounds
- **Item Weight:** 83 Pounds
- **Special Features:** Adjustable Backrest, Adjustable Footrest, Rocking, Swivel, Upholstered
- **Room Type:** Bedroom, Living Room, Office Reception
- **UPC:** 762821528384

Product Dimensions



Image: Diagram illustrating the key dimensions of the recliner chair, including width, depth, and height.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to your purchase documentation or contact the seller directly. Protection plans may be available for extended coverage.

- **Seller:** LFomni
- **Return Policy:** 30-day refund/replacement policy.
- **Protection Plans:** Optional 2-Year and 3-Year protection plans are available for purchase.

