

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COSYLAND](#) /

› [COSYLAND Toddler Step Stool with Armrest - Model CS000081-3-CA Instruction Manual](#)

COSYLAND CS000081-3-CA

COSYLAND Toddler Step Stool with Armrest

Model: CS000081-3-CA

INTRODUCTION

This instruction manual provides important information regarding the assembly, operation, maintenance, and safety of your COSYLAND Toddler Step Stool with Armrest. Please read this manual thoroughly before assembly and use, and retain it for future reference. Proper assembly and adherence to safety guidelines are crucial for ensuring the product's longevity and the user's safety.

SAFETY INFORMATION

- **Maximum Weight Capacity:** The step stool is designed to support a maximum weight of 300 lbs (approximately 136 kg). Do not exceed this weight limit.
- **Adult Supervision:** Always ensure children are supervised by an adult when using the step stool, especially when the armrest is removed.
- **Stability:** Ensure the step stool is placed on a flat, stable, and dry surface before use. The non-skid feet are designed to enhance stability on various floor types.
- **Armrest Function:** The armrest provides additional support and a sense of security for children. While it offers a guard at the front, it is not an anti-fall barrier for the back or sides. Continuous adult supervision is required.
- **Inspection:** Regularly inspect all components for wear, damage, or loose fasteners. Discontinue use if any damage is found and contact customer support.
- **Intended Use:** This step stool is intended for children and adults to reach elevated surfaces safely. Do not use it as a toy, climbing frame, or for purposes other than its intended design.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact COSYLAND customer support.

- Step Stool Components (pre-drilled bamboo panels)
- Removable Armrest Sections
- Hardware Pack (screws, bolts, nuts, washers)

- Assembly Tool (Hex screwdriver)
- Instruction Manual

ASSEMBLY INSTRUCTIONS

Assembly typically takes less than 30 minutes for one person. All parts and hardware are clearly labeled for ease of installation. A hex screwdriver is included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Identify each component using the provided labels.
2. **Attach Side Panels:** Secure the main step platforms to the side panels using the designated screws and the included hex screwdriver. Ensure all connections are firm but do not overtighten to avoid damaging the bamboo.
3. **Install Armrest (Optional):** If desired, attach the armrest sections to the upper part of the step stool. The armrest is designed to be removable, allowing for versatile use as your child grows or for adult use.
4. **Verify Stability:** Once assembled, gently shake the stool to ensure all connections are secure and the structure is stable.



Figure 1: Key features of the step stool, including its sturdy structure, rounded corners, anti-slip pads, and wider step surface.

OPERATING INSTRUCTIONS

The COSYLAND Toddler Step Stool is designed to promote independence and assist both children and adults in various daily activities.

Using with Children

- **Encouraging Independence:** Position the stool in front of a sink, counter, or bookshelf to allow your child to reach independently for tasks like hand washing, teeth brushing, or accessing items.
- **Potty Training:** The stool can be used to help children reach the toilet seat comfortably, aiding in potty training.
- **Kitchen Helper:** In the kitchen, the stool enables children to participate in meal preparation or other counter-height activities under adult supervision.



Figure 2: Child using the step stool to reach a bathroom sink.

One Step Stool, Many Possibilities



Figure 3: The step stool's versatility for different uses, including reading, washing, and potty training.

Using with Adults

The stool's robust construction and 300 lbs weight capacity allow adults to use it for reaching high shelves or as a temporary seat. The armrest can be removed for adult use or to convert it into a standard two-step stool.

Accompanying Your Child's Growth

The top handrail is removable for use as a step stool as your child grows.



Figure 4: Demonstrating the step stool's adaptability for both children (with armrest) and adults (without armrest).

CARE AND MAINTENANCE

- **Cleaning:** The smooth, scratch-resistant surface can be easily cleaned with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Drying:** After cleaning, wipe the stool dry immediately to prevent moisture damage to the bamboo.
- **Storage:** Store the step stool in a dry environment away from direct sunlight or extreme temperature changes to maintain its structural integrity.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

- **Stool feels wobbly after assembly:** Ensure all screws are fully tightened. If wobbling persists, disassemble and reassemble, carefully aligning all parts. Avoid overtightening during initial assembly to allow for proper alignment before final tightening.

- **Difficulty attaching armrest:** Check that the armrest sections are correctly oriented and aligned with the pre-drilled holes. Do not force components together.
- **Surface damage during assembly:** If bamboo splits or cracks while screwing, it may indicate overtightening or a manufacturing defect. Stop assembly and contact customer support for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	COSYLAND
Model Number	CS000081-3-CA
Colour	Black
Material	Bamboo
Product Dimensions (L x W x H)	39 x 40 x 65 cm (15.35 x 15.75 x 25.59 inches)
Item Weight	3 kg (6.6 lbs)
Maximum Weight Capacity	300 lbs (136 kg)
Special Features	Non-Skid Feet, Removable Armrests, Slip Resistant Step



Figure 5: Product dimensions of the step stool.

WARRANTY AND SUPPORT

Specific warranty information for the COSYLAND Toddler Step Stool is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to your purchase documentation or contact COSYLAND customer service directly through their official website or the retailer where the product was purchased.