

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Philips](#) /

› [Philips Power Bank DLP1812PB 10000mAh 20W with PD & QC3.0, USB-A and Type-C Ports, Compatible with iPhone 16/15 Series, Galaxy S25/S24/S23 Ultra, Type-C Cable Included \(Black\) User Manual](#)

Philips DLP1812PB

Philips Power Bank DLP1812PB User Manual

Model: DLP1812PB

1. INTRODUCTION

Thank you for choosing the Philips Power Bank DLP1812PB. This portable power solution is designed to keep your devices charged and ready, wherever you are. With its high capacity and fast-charging capabilities, it's an essential accessory for your mobile lifestyle. This manual provides important information on how to safely and effectively use your power bank.



Image 1.1: Philips Power Bank DLP1812PB. This image shows the sleek, black design of the power bank with the Philips logo and '10' (likely indicating 10000mAh) visible on its surface.

2. PRODUCT OVERVIEW

2.1 Key Features

- **20W USB Type-C PD Port:** Enjoy fast and reliable charging for smartphones, tablets, and other USB-C devices.
- **USB-A with QC Fast Charging:** Optimizes charging speeds for compatible devices by increasing voltage and current.
- **10000mAh High Capacity:** Provides enough power to charge most smartphones up to two times on a single charge.
- **Simultaneous Charging:** Charge up to three devices at once using the integrated Type-C port and dual USB-A ports.
- **LED Power Indicator:** Easily check the power bank's battery status with a soft glowing LED light.
- **Advanced Safety Protection:** Equipped with overcharge protection, short-circuit prevention, and overcurrent control for safe and efficient charging.
- **Compact and Portable:** Ideal for travel, work, or daily use.
- **USB-C Cable Included:** Comes with a Type-C cable for convenience.

2.2 Package Contents

- 1 x Philips Power Bank DLP1812PB
- 1 x Warranty Card
- 1 x User Manual
- 1 x Type-C Cable

2.3 Product Diagram



Image 2.1: Top view of the power bank highlighting its ports and button. From left to right: USB-C Input/Output port, Micro USB Input port, two USB-A Output ports, and the Power Button.



High quality battery



PSE certified



Made of flame retardant material



Superior shock-resistant design

Image 2.2: This image illustrates key features of the power bank, including its high-quality battery, PSE certification, flame-retardant material construction, and superior shock-resistant design.

3. SETUP

3.1 Initial Charging of the Power Bank

Before first use, it is recommended to fully charge your Philips Power Bank. This ensures optimal battery performance and longevity.

1. Connect the included USB Type-C cable to the USB-C Input/Output port on the power bank.
2. Connect the other end of the cable to a USB wall charger (not included) or a computer's USB port.
3. The LED indicators on the power bank will light up, indicating the charging progress. All LEDs will be solid when fully

charged.

Alternatively, you can use a Micro USB cable (not included) to charge the power bank via the Micro USB Input port.

4. OPERATING INSTRUCTIONS

4.1 Charging Your Devices

The Philips Power Bank can charge various devices such as smartphones, tablets, and other USB-powered gadgets.

1. Connect your device's charging cable to one of the power bank's output ports (USB-A or USB-C).
2. Connect the other end of the cable to your device.
3. Press the Power Button on the power bank to initiate charging. The LED indicators will show the remaining battery level.
4. Your device should begin charging automatically.

4.2 Simultaneous Charging

This power bank supports charging up to three devices concurrently.

Equipped with two USB-A ports you can charge two devices simultaneously



Image 4.1: The power bank simultaneously charging a tablet via its USB-C port and a smartphone via one of its USB-A ports, demonstrating its multi-device charging capability.

To charge multiple devices, simply connect each device to an available USB-A or USB-C port. The power bank will intelligently distribute the power. Note that charging speed may vary depending on the number of devices connected and their power requirements.

4.3 LED Indicator Status

- **Solid LEDs:** Indicate the remaining battery capacity. Each LED typically represents 25% of the battery.
- **Flashing LEDs:** Indicate that the power bank is currently being charged.
- **No LEDs:** The power bank is either off or completely discharged.

5. MAINTENANCE

Proper maintenance will extend the lifespan of your power bank.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use liquid cleaners or aerosols.

- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Battery Care:** To maintain battery health, fully charge the power bank at least once every three months if not in regular use. Avoid completely draining the battery frequently.
- **Avoid Drops:** While designed to be shock-resistant, avoid dropping the power bank to prevent internal damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not connected properly; Charger not working; Power bank fully discharged.	Ensure cables are securely connected. Try a different charger or cable. Allow a few minutes for the power bank to respond if deeply discharged.
Device not charging from power bank	Power bank is off; Power bank battery is empty; Incompatible cable; Device issue.	Press the Power Button to turn on. Recharge the power bank. Use the correct charging cable for your device. Test with another device.
Slow charging	Cable quality; Device not supporting fast charge; Multiple devices charging.	Use a high-quality cable. Ensure your device supports PD or QC for faster charging. Charging multiple devices simultaneously may reduce individual charging speeds.
LED indicators not working	Power bank is off; Faulty unit.	Press the Power Button. If still unresponsive, contact customer support.

7. SPECIFICATIONS

Feature	Specification
Model Number	DLP1812PB
Battery Capacity	10000mAh
Battery Cell Composition	Lithium Polymer
USB-C Output (PD)	20W Max
USB-A Output (QC)	QC 3.0
Input Ports	USB Type-C, Micro USB
Output Ports	USB Type-C, 2 x USB Type-A
Dimensions (L x W x H)	14 x 6.5 x 0.9 cm
Weight	280 g
Color	Black

8. WARRANTY & SUPPORT

Your Philips Power Bank DLP1812PB comes with a warranty. Please refer to the included Warranty Card for detailed terms and

conditions, including the warranty period and coverage.

For technical support, troubleshooting assistance, or warranty claims, please contact Philips customer service through their official website or the contact information provided on your warranty card. Keep your purchase receipt and warranty card as proof of purchase.

