

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZMISHIBO](#) /

› [ZMISHIBO Ceiling Fan with Light User Manual \(Models: 19.7 Inch, 13 Inch\)](#)

ZMISHIBO 19.7 Inch, 13 Inch

ZMISHIBO Ceiling Fan with Light User Manual

Models: 19.7 Inch, 13 Inch

INTRODUCTION

This manual provides instructions for the safe installation, operation, and maintenance of your ZMISHIBO Ceiling Fan with Light. Please read this manual thoroughly before installation and use, and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Ensure power is disconnected at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- Consult a qualified electrician if you are unsure about wiring procedures.
- Mount the fan to a ceiling joist or support structure capable of supporting the fan's weight.
- Do not bend fan blade holders during installation or cleaning.
- Keep hands clear of fan blades when operating.
- This product is for indoor use only.

PRODUCT COMPONENTS

The ZMISHIBO Ceiling Fan with Light includes the following main components:

- Ceiling Fan Unit (with integrated LED light)
- Remote Control
- Mounting Hardware
- Instruction Manual



ZMISHIBO Ceiling Fans with Lights

Product Details



Iron Paint Craft



Metal Frame



ABS Fan Blades



Acrylic Lampshade

Image: Product Details. This image displays the construction materials of the ZMISHIBO ceiling fan, including the iron paint craft finish, metal frame, ABS fan blades, and acrylic lampshade.

SETUP AND INSTALLATION

The ZMISHIBO Ceiling Fan with Light is designed for semi-flush mount installation and requires no assembly of the main fixture. Detailed installation instructions are provided in the included guide. It is recommended to consult a qualified electrician for installation.

Pre-Installation Checklist:


- Verify all components are present.
- Ensure the mounting location can support the fan's weight.
- Turn off power at the circuit breaker before beginning.

General Installation Steps (Refer to included guide for specifics):

1. Secure the mounting bracket to the ceiling junction box.
2. Connect the electrical wiring (live, neutral, ground) according to local codes.
3. Attach the fan body to the mounting bracket.
4. Ensure all connections are secure and the fan is firmly mounted.



Product Size



Room Size:

Height:
7FT-10FT


Length & Width:
8.5FT x 8.5FT

Image: 19.7 Inch Fan Dimensions. This image illustrates the dimensions of the larger ZMISHIBO ceiling fan model (19.7 inches diameter) and provides suggested room size specifications for optimal performance.



Product Size

Suggestion Room Size



V
120
Volt

💡
2000
LM



Memory
Function



After-Sales
Service

Room Size:

Height:
7FT-10FT

Length & Width:
8FT x 8FT



Image: 13 Inch Fan Dimensions. This image illustrates the dimensions of the smaller ZMISHIBO ceiling fan model (13 inches diameter) and provides suggested room size specifications for optimal performance.

OPERATING INSTRUCTIONS

Your ZMISHIBO Ceiling Fan with Light can be controlled via the included remote control or a smartphone application (Bluetooth required).

Remote Control and App Operation:

- **Power On/Off:** Use the dedicated power button.

- **Fan Speed:** Select from 6 available wind speeds.
- **Light Control:** Adjust brightness (10%-100%) and color temperature (3000K Warm, 4000K Nature, 6000K White). The light features a memory function, retaining the last setting.
- **Sleep Timer:** Set the fan to turn off automatically after 1, 2, or 4 hours.
- **Reverse Function (F/R):** Change the fan's rotation direction for summer (downdraft) or winter (updraft) airflow.
- **Night Light:** Activate a low-intensity light setting.
- **App Control:** Download the ZMISHIBO app. Bluetooth pairing is required for app control. Refer to the app's instructions for pairing.



APP & Remote Control



Image: Remote and App Control (19.7 Inch). This image illustrates the remote control and smartphone application interface for operating the 19.7-inch ZMISHIBO ceiling fan, highlighting features like code pairing, bright setting, night light, Bluetooth requirement, reverse function, and timer setting.



APP & Remote Control

APP Requires Bluetooth Support




**6 Fan
Speeds**


**Timer
Setting**

F/R
**Reverse
Function**


**Code
Pair**


**Night
Light**



Image: Remote and App Control (13 Inch). This image illustrates the remote control and smartphone application interface for operating the 13-inch ZMISHIBO ceiling fan, highlighting features like 6 fan speeds, timer setting, reverse function, code pairing, and night light.

Light Features:

- **Dimmable LED:** Adjust brightness from 10% to 100%.
- **Color Temperature:** Choose between 3000K (Warm White), 4000K (Natural White), and 6000K (Cool White).
- **Memory Function:** The light will recall the last brightness and color temperature setting when turned

on again.




Image: Three Color Temperatures & Dimming. This image demonstrates the adjustable light features, including three color temperature options (3000K, 4000K, 6000K) and smooth dimming capability from 10% to 100% brightness.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and light fixture periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.

- **Tightening:** Check all screws and connections annually to ensure they are secure.
- **Blade Balance:** If the fan wobbles, ensure all blades are securely attached and balanced.

TROUBLESHOOTING

Before attempting any repairs, ensure the power supply to the fan is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wiring; Remote control battery low.	Check circuit breaker; Verify wiring connections; Replace remote control battery.
Light does not work	No power supply; Loose wiring; LED driver issue.	Check circuit breaker; Verify wiring connections; Contact support if LED is faulty.
Fan wobbles	Loose mounting screws; Unbalanced blades.	Tighten all mounting screws; Ensure blades are securely attached and balanced.
Remote control not working	Battery low/dead; Remote not paired.	Replace battery; Refer to operating instructions for remote pairing.

SPECIFICATIONS

Feature	Detail
Brand	ZMISHIBO
Models	19.7 Inch, 13 Inch
Color	Black
Material	Metal (Frame), Plastic (Shade), ABS (Fan Blades)
Installation Type	Semi Flush Mount
Power Source	Corded Electric
Voltage	120V
Light Source Type	Integrated LED
Light Color Temperature	3000K (Warm), 4000K (Natural), 6000K (Cool)
Brightness	10%-100% Dimmable, up to 2000 Lumens
Fan Speeds	6 Speeds
Airflow Modes	2 (Downdraft for Summer, Updraft for Winter)
Control Method	Remote Control, App Control (Bluetooth)
Timer Settings	1H, 2H, 4H
Memory Function	Yes (for light settings)
Indoor/Outdoor Usage	Indoor Only

Feature	Detail
Suggested Room Height	7-10 FT
Suggested Room Size (19.7")	8.5 FT x 8.5 FT
Suggested Room Size (13")	8 FT x 8 FT
ASIN	B0DRHP2MHH

WARRANTY AND SUPPORT

ZMISHIBO provides **2-year support** for this product. If you encounter any issues or have questions regarding your ceiling fan, please contact our customer support team.

We aim to respond to all inquiries within 24 hours.

Contact Information: Please refer to the contact details provided on your purchase receipt or the official ZMISHIBO website for the most current support information.