

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Tineco](#) /

› [Tineco iFloor Y2 Wet Dry Vacuum Cleaner User Manual](#)

## Tineco iFloor Y2

# Tineco iFloor Y2 Wet Dry Vacuum Cleaner User Manual

Model: iFloor Y2

## INTRODUCTION

---

Thank you for choosing the Tineco iFloor Y2 Wet Dry Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.

## WHAT'S INCLUDED

---

Unpack your Tineco iFloor Y2 and ensure all components are present. The standard package includes:

- Main Vacuum Unit
- Charging Station
- Cleaning Tool
- Cleaning Solution

# Ce qui est inclus



Station de charge



Outil de nettoyage



Solution de nettoyage



The Tineco iFloor Y2 package includes the main vacuum unit, a charging station for convenient storage and charging, a specialized cleaning tool for maintenance, and a bottle of cleaning solution to enhance floor cleaning results.

## SETUP

1. **Assembly:** Insert the handle into the main body until it clicks securely into place.
2. **Charging:** Place the assembled unit onto the charging station. Connect the power adapter to the charging station and plug it into a wall outlet. The battery indicator will illuminate to show charging status. Fully charge the device before first use (approximately 3-4 hours).
3. **Fill Clean Water Tank:** Press the clean water tank release button and remove the tank. Open the tank cap and fill with clean tap water, or a mixture of water and Tineco cleaning solution (do not exceed the MAX fill

line). Reinsert the tank until it clicks.

## OPERATING INSTRUCTIONS

### Basic Operation

- **Power On/Off:** Press the Power Button to turn the device on or off.
- **Start Cleaning:** Tilt the main body back to engage the brush roll and begin cleaning.
- **Vacuum & Wash Function:** The iFloor Y2 is designed to vacuum and wash hard floors simultaneously.

# Aspire & Lave en un seul passage



The Tineco iFloor Y2 performs both vacuuming and washing simultaneously, effectively cleaning dry debris, wet spills, and pet hair from hard floors in a single pass, saving time and effort.

### Anti-Tangle Design

The iFloor Y2 features a specialized 3D scraper design that prevents hair from tangling around the roller brush. This design ensures the brush remains clean and maintains optimal cleaning performance, especially useful for homes with pets.



The Tineco iFloor Y2 features an anti-tangle brush roll design, effectively preventing hair from wrapping around the brush and maintaining optimal cleaning performance. The integrated scraper helps keep the brush clean during operation.

### Self-Cleaning Function

After each use, it is recommended to run the self-cleaning cycle to maintain the device's hygiene and performance.

1. Ensure the dirty water tank is not full and the clean water tank has sufficient water.
2. Place the iFloor Y2 securely on its charging station.
3. Press the Self-Clean button (often indicated by a circular arrow icon). The device will begin an automatic cleaning cycle.
4. Once the cycle is complete, empty the dirty water tank and clean the filter.

# Autonettoyage en une touche



Initiate the self-cleaning cycle with a single touch of a button. Place the iFloor Y2 on its charging base, press the self-clean button, and the device will automatically clean its brush roll and internal pathways, simplifying maintenance.

## **Brush Cleaning System**

The iFloor Y2 employs an advanced system to keep its brush roll clean during operation. This involves continuous rinsing with clean water and scraping away dirty water and debris.

# Nettoyage avec une brosse toujours propre

01 Rinçage à l'eau claire

02 Lavage avec une brosse de rouleau tournant à 450 tours/min

03 Racler l'eau sale et les cheveux

04 Aspiration immédiate de la saleté et des cheveux

The innovative brush cleaning system ensures the roller brush is continuously cleaned with fresh water at 450 rotations per minute. A squeegee scrapes away dirty water and debris, which is then immediately suctioned into the dirty water tank, ensuring only clean water is used for floor washing.

## Water Tank Management

Proper management of the clean and dirty water tanks is crucial for optimal performance.

- **Clean Water Tank:** Holds 1 liter of water. Refill when the indicator shows low water.
- **Dirty Water Tank:** Holds 0.8 liters of dirty water. Empty after each use or when the indicator shows full. Clean the tank and filter regularly to prevent odors and maintain suction.

# Réservoir de grande capacité

1L

Réservoir d'eau propre

\*30  
minutes



0,8L

Réservoir d'eau souillée

\*En Mode Normal. L'autonomie réelle peut varier en fonction de votre environnement et de vos habitudes.

The Tineco iFloor Y2 is equipped with a 1-liter clean water tank and a 0.8-liter dirty water tank, allowing for extended cleaning sessions without frequent refills or emptying. A full charge provides approximately 30 minutes of runtime in normal mode.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on	Battery is low or depleted.	Charge the device fully.

Problem	Possible Cause	Solution
Poor suction or leaves streaks	Dirty water tank is full, filter is clogged, or brush roll is dirty.	Empty and clean the dirty water tank. Clean or replace the filter. Run self-cleaning cycle or manually clean the brush roll.
Water not dispensing	Clean water tank is empty or improperly installed.	Refill the clean water tank. Ensure the tank is securely in place.
Unusual noise	Obstruction in brush roll or air path.	Turn off the device and check for any foreign objects in the brush roll area or air ducts. Remove any obstructions.

## SPECIFICATIONS

---

- **Model:** iFloor Y2
- **Brand:** Tineco
- **Product Dimensions:** 27.1 x 27.6 x 108.65 cm
- **Item Weight:** 4.1 kg
- **Clean Water Tank Capacity:** 1.0 Liters
- **Dirty Water Tank Capacity:** 0.8 Liters
- **Power / Wattage:** 140 watts
- **Voltage:** 25.2 Volts (DC)
- **Noise Level:** 80 Decibels

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or to purchase spare parts, please refer to the official Tineco website or contact Tineco customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.