

aopiata AP09

aopiata AP09 Bluetooth 5.4 Wireless Earbuds User Manual

Model: AP09

1. INTRODUCTION

Thank you for purchasing the aopiata AP09 Bluetooth 5.4 Wireless Earbuds. This manual provides essential information for the safe and effective use of your device. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or corrosive environments.
- Avoid dropping, impacting, or disassembling the device.
- Keep the device away from children and pets.
- Do not use the charging case in wet conditions, as it is not waterproof.
- Use only the provided charging cable or a certified equivalent.
- Prolonged listening at high volumes may cause hearing damage. Adjust volume to a safe level.

3. PACKAGE CONTENTS

- aopiata AP09 Wireless Earbuds (L/R)
- Charging Case
- USB Type-C Charging Cable
- Instruction Manual

- Ear Tips (S, M, L sizes)

4. PRODUCT OVERVIEW

The aopiata AP09 earbuds feature a compact design with touch controls and a digital display charging case.



Image: aopiata AP09 Wireless Earbuds in their charging case, displaying the current battery percentage on the front LED screen.

4.1. Components

- **Earbuds:** Left (L) and Right (R) earbuds with touch-sensitive surfaces and built-in microphones.
- **Charging Case:** Stores and charges the earbuds. Features an LED display for battery status.
- **USB Type-C Port:** For charging the case.

4.2. LED Power Display

The charging case features an LED display that shows the remaining battery percentage of the case and individual battery levels for the left (L) and right (R) earbuds.



Image: Detailed view of the charging case's LED display, indicating the overall case battery percentage and separate battery indicators for the left and right earbuds.

5. SETUP

5.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; magnets will hold them in place.
2. Connect the USB Type-C cable to the charging port on the case and the other end to a USB power adapter (not included).
3. The LED display on the case will show the charging status. The case takes approximately 1.5 hours to fully charge.
4. Once fully charged, the LED display will turn off.

Note: The charging case is not waterproof. Do not expose it to water or moisture.

36時間の長時間再生を実現



1.5H Type-C急速
充電時間
(イヤホン倉)

6H イヤホン1回の
充電で再生時間

36H イヤホン倉1回の
充電で再生時間

備考:使用後にイヤホンをケースに戻すと、自動的に充電されます。充電中はLEDディスプレイが点滅し、充電が完了すると消灯します。

Image: Visual representation of the earbuds' battery life (6 hours per charge, 36 hours total with case) and the Type-C fast charging feature. The charging case takes 1.5 hours to charge.

5.2. Pairing with a Device

The earbuds feature automatic pairing for convenience.

1. **First-time pairing:** Open the charging case and remove both earbuds. They will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "AP09" from the list.
4. Once connected, you will hear a confirmation sound, and the earbuds will be ready for use.
5. **Subsequent use:** After the initial pairing, simply open the charging case and remove the earbuds. They will automatically connect to the last paired device.

蓋を開けたら接続

初めて手動的に接続してから、再度起動時に蓋を開けたら自動電源オンと自動ペアリングができます。左右のイヤホンがBluetoothに自動的に接続、主耳と副耳の区別が無く、両耳でも片耳でもご自由に使っていただけます。



瞬時にペアリングする手順

- ①イヤホンを取り出す
- ②BLUETOOTHをオンにする
- ③自動ペアリング
(ヘッドホン名:AP09)

初めて使用する場合は、Bluetoothペアリングが必要です。(ヘッドホン名:AP09)

Image: Step-by-step guide for instant pairing: 1) Take out earbuds, 2) Turn on Bluetooth on your device, 3) Automatic pairing (Headphone name: AP09).

6. OPERATING INSTRUCTIONS

The aopiata AP09 earbuds utilize touch controls for various functions.

6.1. Power On/Off

- **Power On:** Open the charging case and remove the earbuds. They will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

6.2. Music Playback

- **Play/Pause:** Tap the touch button on either the L or R earbud once.
- **Volume Up:** Tap the touch button on the R earbud twice.
- **Volume Down:** Tap the touch button on the L earbud twice.
- **Next Track:** Tap the touch button on the R earbud three times.
- **Previous Track:** Tap the touch button on the L earbud three times.

6.3. Call Functions

- **Answer/End Call:** Tap the touch button on either the L or R earbud once.
- **Reject Call:** Long press the touch button on either the L or R earbud for approximately 2 seconds.

6.4. Voice Assistant (Siri/Google Assistant)

- **Activate:** Long press the touch button on either the L or R earbud for approximately 3 seconds.

6.5. Single/Dual Earbud Use

You can use either earbud independently or both together for stereo sound.

- **Single Earbud Mode:** Simply remove one earbud from the case, and it will connect to your device. The other earbud can remain in the case.
- **Dual Earbud Mode:** Remove both earbuds from the case. They will automatically connect to each other and then to your device, providing a stereo audio experience.

超軽量設計・快適な多機能タッチ操作



🎵 音楽用

- ▶ 一時停止/音楽再生: L/Rイヤホンのタッチボタンを1回押す。
- ⊕ 音量上げる: Rイヤホンのタッチボタンを2回押す。
- ⊖ 音量下げる: Lイヤホンのタッチボタンを2回押す。
- ⏮ 曲送り: Rイヤホンのタッチボタンを3回押す。
- ⏭ 曲戻り: Lイヤホンのタッチボタンを3回押す。

☎ 電話機能

- 着信応答/終了: 着信中、L/Rイヤホンのタッチボタンを1回押す。
- 通話拒否: 着信中、L/Rイヤホンのタッチボタンを約2秒間長押しする。

🗣 SIRI機能

- R/Lイヤホンのタッチボタンを約3秒間長押しする。

Image: A comprehensive guide to the touch controls for the earbuds, illustrating actions for music playback (play/pause, volume, track skip), phone calls (answer/end, reject), and activating the voice assistant.

片耳/両耳使用対応

どちらのイヤホンを取り出しても単独で使用できます。両耳のイヤホンを装着すると立体音響をより力強く耳に届けます。好みや使用シーンに合わせて使い分けることができます。



Image: Demonstrates the flexibility of using one or both earbuds, along with a visual guide to selecting the correct ear tip size (S, M, L) for a customized, comfortable fit.

7. MAINTENANCE

7.1. Cleaning

- The earbuds are IPX7 waterproof, allowing for rinsing. However, avoid using harsh chemicals or abrasive materials.
- Wipe the earbuds with a soft, damp cloth. Ensure they are completely dry before placing them back in the charging case.
- Clean the charging contacts on both the earbuds and the case regularly with a dry cotton swab to ensure proper charging.

- Clean the charging case with a dry, soft cloth. Do not use water or liquids on the charging case.

7.2. Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

抜群なフィット感

人間工学に基づいた設計、耳の形状に合わせてしっかりフィット、長時間使用しても耳が痛くならない。

超軽量設計
わずか4.0g



安心できるIPX7防水仕様



Image: Highlights the ergonomic design for a secure fit and the IPX7 waterproof rating, making the earbuds suitable for activities like washing, gym workouts, and running.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds do not power on.	Low battery.	Place earbuds in the charging case and charge fully.

Problem	Possible Cause	Solution
Earbuds do not pair.	Bluetooth is off on device; earbuds not in pairing mode; previously paired device interfering.	Ensure Bluetooth is on. Remove both earbuds from case to enter pairing mode. Forget 'AP09' from your device's Bluetooth list and re-pair.
No sound or intermittent sound.	Earbuds not connected; low battery; device volume too low; out of Bluetooth range.	Check Bluetooth connection. Charge earbuds. Increase device volume. Ensure device is within 10 meters of earbuds.
Charging case not charging.	Charging cable or adapter issue; dirty charging port.	Try a different USB Type-C cable and power adapter. Clean the charging port with a dry cotton swab.
Touch controls not responding.	Earbuds are wet; temporary software glitch.	Ensure earbuds are dry. Place earbuds back in the case, close the lid, then remove them to reset.

9. SPECIFICATIONS

Feature	Detail
Model Name	AP09
Brand	aopiata
Connectivity Technology	Wireless (Bluetooth 5.4 + EDR)
Headphone Form Factor	True Wireless
Color	01black
Earbud Weight	Approx. 3.8g per earbud
Bluetooth Range	Up to 10 meters
Noise Cancelling	CVC 8.0
Waterproof Rating	IPX7 (Earbuds only, charging case is not waterproof)
Earbud Playback Time	Up to 6 hours per charge
Total Playback Time (with case)	Up to 36 hours
Charging Case Charge Time	Approx. 1.5 hours
Charging Port	USB Type-C

Feature	Detail
TELEC Certification Number	R210-187442
Package Dimensions	10.1 x 8.1 x 2.9 cm
Package Weight	70 g



Image: An exploded diagram of an earbud highlighting its 13mm diaphragm speaker and polymer diaphragm, designed for rich audio reproduction and HiFi sound quality, alongside a user wearing the earbuds.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official aopiata website. Keep your proof of purchase for warranty claims.

