



[Manuals.plus](#) /

› [THTEN](#) /

› Thten KST 2224B-03 KLS 124-03 Trimmer Head Instruction Manual

## THTEN kobalt KLS 124-03 trimmer head

# Thten KST 2224B-03 KLS 124-03 Trimmer Head Instruction Manual

Model: kobalt KLS 124-03 trimmer head

## INTRODUCTION

This manual provides detailed instructions for the safe and effective use, setup, and maintenance of your Thten KST 2224B-03 KLS 124-03 Trimmer Head. This replacement trimmer head is designed for compatibility with specific Kobalt 24-volt straight shaft string trimmers, ensuring efficient and reliable performance for your lawn care needs.



Image: The Thten KST 2224B-03 KLS 124-03 Trimmer Head, featuring a black body with a blue cap and green trimmer line extending from its sides.

## SAFETY INFORMATION

---

Please read and understand all safety warnings before operating the trimmer head. Failure to follow these instructions may result in serious injury.

- Always wear eye protection and gloves when using the trimmer.
- Keep children and pets away from the trimmer while in use.
- Do not trim near flammable materials.
- Always unplug the trimmer before performing any maintenance or repairs.

## COMPATIBILITY

This trimmer head is compatible with the following Kobalt 24-volt 12-inch Straight Shaft Battery String Trimmer models:

- KLS 124-03
- KST 1124B-03
- KST 2024A-03
- KST 2224B-03
- KST 4024A-03
- KST 4024AB-03

It is also compatible with Kobalt Item numbers: 856456, 1157557, 1137837, 3488480.

**Compatible with Kobalt 24 Volt KST 2224B-03 KLS 124-03, KST 1124B-03, KST 2024A-03, KST 4024A-03, KST 4024AB-03 12 inch Straight Shaft String Trimmer inch Straight Shaft String Trimmer**

Item number:  
1157557, 1504979, 1157560, 1137837




Image: The trimmer head shown with text indicating its compatibility with various Kobalt 24 Volt KST models and item numbers.

## SETUP AND INSTALLATION

Follow these steps to install the trimmer head onto your compatible Kobalt string trimmer.

1. **Step 1: Remove the old trimmer head (if applicable).** Ensure the trimmer is unplugged or the battery is removed. Carefully remove the existing trimmer head according to your trimmer's manual.
2. **Step 2: Attach the new Thiten trimmer head.** Align the slot on the new trimmer head with the tap on the trimmer shaft. Push the head onto the shaft until it clicks securely into place.
3. **Step 3: Load the trimmer line.** This trimmer head features an easy quick-load spool system. Refer to the "Maintenance: Line Replacement" section for detailed instructions on loading the line.



## Installation Step 1

## Installation Step 2




Image: A two-part diagram illustrating the installation process. The top part shows aligning the trimmer head's slot with the trimmer's tap. The bottom part shows the direction of rotation for effective cutting.



Image: The Thten trimmer head securely attached to the end of a blue and black Kobalt string trimmer, ready for use.

## Video: Trimmer Head Assembly and Line Replacement

Your browser does not support the video tag.

Video: This video demonstrates the process of disassembling and reassembling the trimmer head, including how to properly load and secure the trimmer line onto the spool.

## OPERATING INSTRUCTIONS

---

Once installed, your trimmer head is ready for operation. This head provides enhanced cutting efficiency for maintaining clean, precise edges.

- **Dual-String Line Feed:** The dual-string line feed provides great cutting efficiency, allowing for faster and more effective trimming.
- **Optimal Cutting:** For best results, operate the trimmer with a sweeping motion, cutting in the direction indicated in the installation diagram to achieve clean edges around your yard, garden, or flower beds.
- **Reliable Performance:** Designed to meet Kobalt's high standards, this trimmer head ensures consistent and reliable performance.



Image: A person operating a string trimmer to cut grass along a pathway next to a house, demonstrating typical use.



Image: A person using a string trimmer in a garden area, showcasing the product's application in various outdoor spaces.

## MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your trimmer head.

### Line Replacement

The quick-load spool system makes reloading new string simple and tool-free.

- **Line Specifications:** The recommended line for this trimmer head is 0.080-inch diameter. Each spool typically holds 16 feet of line.
- **Reloading:** To reload, press the tabs on the side of the trimmer head to open it. Remove the old spool. Insert the new pre-wound spool, ensuring the line ends are threaded through the eyelets. Close the head securely.
- **Manual Feed:** If the line does not feed automatically, gently tap the trimmer head on the ground while the trimmer is running to advance the line.



Image: A blue trimmer line spool with green line, indicating a line length of 16 feet and a diameter of 0.080 inches.

### Cleaning and Storage

- After each use, clean the trimmer head to remove grass clippings and debris.
- Store the trimmer head in a dry, cool place, away from direct sunlight and moisture.

### TROUBLESHOOTING

If you encounter issues with your Thten trimmer head, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer line not feeding	Line tangled or empty spool	Check spool for tangles, replace line if empty. Ensure line is properly threaded.

Problem	Possible Cause	Solution
Poor cutting performance	Worn or incorrect line, debris in head	Replace line with recommended 0.080-inch diameter. Clean trimmer head of debris.
Trimmer head difficult to attach/detach	Misalignment or debris	Ensure proper alignment with trimmer shaft. Clean any debris from connection points.

## SPECIFICATIONS

---

**Brand:** THTEN

**Model Number:** kobalt KLS 124-03 trimmer head

**ASIN:** B0DRJFHL95

**Power Source:** Manual (refers to the head's operation, not the trimmer itself)

**Color:** BLACK

**Item Weight:** 1.6 ounces

**Product Dimensions:** 0.1"L x 0.1"W

**Cutting Width:** 0.1 Inches

**Assembly Required:** No

## WARRANTY AND SUPPORT

---

For any questions, concerns, or assistance with your Thten product, please contact our world-class, friendly support team for quick solutions. Refer to your purchase documentation for specific warranty details.

You can also visit the official THTEN Store for more information and products: [THTEN Store on Amazon](#)