

COZII ZM 5009

COZII ZM 5009 Professional Countertop Blender User Manual

Model: ZM 5009

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the COZII ZM 5009 Professional Countertop Blender. Failure to follow these safety guidelines may result in injury or damage to the appliance.

- Always ensure the blender is unplugged from the power outlet before assembly, disassembly, or cleaning.
- Keep hands and utensils out of the container while blending to prevent injury. Use the provided tamper only when the lid is securely in place and the blender is operating.
- Blades are sharp. Handle with extreme care during cleaning and assembly.
- Do not immerse the motor base in water or any other liquid. Wipe clean with a damp cloth.
- Ensure the lid is properly sealed on the pitcher or to-go cup before starting the blender.
- Avoid blending excessively hot liquids in the to-go cup, as pressure buildup may cause injury.
- Do not operate the blender if the cord, plug, or any part of the appliance is damaged or if it has malfunctioned or been dropped. Contact customer support for assistance.
- This appliance is intended for household use only.

2. PACKAGE CONTENTS

Your COZII ZM 5009 Professional Countertop Blender package includes the following components:

- Blender Motor Base
- 64oz (1.85L) Pitcher with Lid
- 21oz (600mL) To-Go Cup with Blade Assembly and Travel Lid
- Tamper

- Cleaning Brush
- Instruction Manual (this document)
- Recipe Book



Image: All components of the COZII ZM 5009 Professional Countertop Blender, including the motor base, large pitcher, to-go cup, and tamper.

3. SETUP

Before first use, wash all parts that will come into contact with food in warm, soapy water, then rinse thoroughly and dry. The pitcher, to-go cup, lids, and blade assembly are dishwasher safe.

Assembling the Blender

1. Place the motor base on a clean, dry, and stable countertop.
2. For the 64oz Pitcher: Place the pitcher onto the motor base, ensuring it is securely seated. Align the handle with the front of the base. Place the lid firmly on the pitcher.
3. For the 21oz To-Go Cup: Fill the to-go cup with ingredients. Screw the blade assembly onto the open end of the cup until tight. Invert the cup and place it onto the motor base, aligning the tabs.
4. Plug the power cord into a standard 120V AC electrical outlet. The power indicator light will

illuminate.



Image: All components of the COZII blender laid out, showing the motor base, large pitcher, to-go cup, and accessories.

4. OPERATING INSTRUCTIONS

Control Panel Overview

The COZII ZM 5009 features an intuitive touch panel with preset programs and variable speed control:

- **Start/Stop Button:** Press once to enter standby mode, then select a program or speed, and press again to start blending. Press to stop operation.
- **Speed Dial (0-8):** Rotate to manually select desired blending speed. '0' is off, '8' is maximum speed.
- **Preset Programs:**
 - **Smoothies:** Optimized for smooth, creamy beverages.
 - **Ice Crush:** Designed for efficient ice crushing.
 - **Puree:** For creating smooth purees from fruits or vegetables.
 - **Blend:** General blending function.
 - **Pulse:** Provides short bursts of power for controlled chopping or mixing.
 - **Ice Cream:** For making frozen desserts.
 - **Extract:** For extracting nutrients from ingredients.



TOUCH PANEL

7 SMART SETTINGS

8 SPEED ADJUSTMENT

Image: The COZII blender's touch control panel, highlighting the 7 smart settings and 8-speed adjustment dial.

7 Smart Settings & Touchscreen Control

With intelligent programs, you can make milkshake, fruit smoothies, frozen drinks at the touch of a button



 **EXTRACT**

 **ICE CREAM**

 **FROZEN DRINK**

 **SMOOTHIES**

Image: Visual representation of the 7 smart settings and touchscreen control for various blending tasks.

8 VARIABLE SPEEDS & PULSES FUNCTION



Image: A graphic detailing the 8 variable speeds and pulse function, showing recommended uses for juices, smoothies, milkshakes, purees, and hummus.

General Blending Steps

1. Prepare ingredients: Cut food into small pieces suitable for blending.
2. Load ingredients: Place ingredients into the 64oz pitcher or 21oz to-go cup. Ensure liquid ingredients are added first to aid blending. Do not exceed the MAX fill line.
3. Secure lid: Place the lid firmly on the pitcher or screw the blade assembly onto the to-go cup.
4. Place container: Securely place the pitcher or inverted to-go cup onto the motor base.
5. Select setting: Press the Start/Stop button to activate the control panel. Choose a preset program or adjust the speed dial to your desired level.
6. Start blending: Press the Start/Stop button again to begin blending.
7. Use Tamper (64oz Pitcher only): If ingredients get stuck, remove the small cap from the lid and use the tamper to push ingredients towards the blades. Do not use the tamper with the to-go cup.
8. Stop blending: Press the Start/Stop button to stop the blending cycle.
9. Serve: Carefully remove the container from the base and pour or drink directly from the to-go cup.

HOW TO USE



Image: A visual guide demonstrating the four simple steps to use the COZII blender: prepare ingredients, secure the lid, press start, and enjoy.

Using the 64oz Pitcher

The large 64oz pitcher is ideal for preparing larger batches of smoothies, soups, or sauces for the whole family. Its robust design and powerful blades ensure efficient blending of various ingredients.

64oz/1.85L LARGE CAPACITY

LARGE CAPACITY Perfect for whole family and commercial use



Image: A woman pouring a blended drink from the 64oz pitcher into several glasses, illustrating the blender's large capacity for family use.

Using the 21oz To-Go Cup

The convenient 21oz to-go cup allows for single-serving blends directly in the cup. After blending, simply replace the blade assembly with the travel lid for easy portability.



Image: A 21oz to-go cup filled with a vibrant purple smoothie, showcasing its convenience for individual servings.

Using the Tamper

The tamper is designed to push thick or frozen ingredients down towards the blades during blending in the 64oz pitcher, ensuring a smooth and consistent result. Always use the tamper through the lid's opening and never with the to-go cup.

Official Product Video: Main Features and Usage

Video: This official COZII video demonstrates the main features of the blender, including its powerful motor, various settings, and how to use both the large pitcher and the to-go cup for different preparations like ice crushing, smoothies, and nut butter.

Recipe Examples

The COZII ZM 5009 Professional Countertop Blender is versatile for a wide range of recipes:

- **Smoothies:** Blend fruits, vegetables, and liquids for healthy drinks.
- **Ice Crushing:** Create crushed ice for cocktails or frozen desserts.
- **Purees:** Prepare smooth purees for baby food or sauces.
- **Ice Cream:** Make homemade ice cream or sorbets.
- **Nut Butters:** Process nuts into creamy nut butter.
- **Nut Milks:** Create fresh, homemade nut milks.

- **Dips & Spreads:** Prepare various dips like hummus or salsa.
- **Hot Soups:** The high-speed blades can generate enough friction to heat soups.



Image: A visual guide showcasing the versatility of the COZII blender for making smoothies, ice cream, frozen drinks, and extracts.

5. MAINTENANCE & CLEANING

Proper maintenance ensures the longevity and optimal performance of your COZII blender.

Cleaning the Blender

- **Self-Clean Function:** For quick cleaning, add warm water and a drop of dish soap to the pitcher or to-go cup. Secure the lid, then run the blender on a low speed for 30-60 seconds. Rinse thoroughly.
- **Dishwasher Safe:** The pitcher, to-go cup, lids, and blade assembly are dishwasher safe. Place them on the top rack of your dishwasher.
- **Hand Washing:** For thorough cleaning, disassemble the parts and wash with warm, soapy water using the provided cleaning brush. Rinse well and allow to air dry.
- **Motor Base:** Wipe the motor base clean with a damp cloth. Never immerse the motor base in water.




Image: The COZII blender's pitcher and to-go cup components are shown inside a dishwasher, emphasizing their dishwasher-safe and BPA-free design for easy cleanup.

6. TROUBLESHOOTING

If you encounter any issues with your COZII blender, refer to the following common troubleshooting tips:

- **Blender does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the pitcher/to-go cup is correctly assembled and seated on the motor base. The blender has a safety interlock feature.
- **Ingredients are not blending smoothly:** Add more liquid to the mixture. Use the tamper (with the 64oz pitcher) to push ingredients towards the blades. Increase the speed setting or use the Pulse function for stubborn ingredients.
- **Motor smells or overheats:** This may occur with very thick mixtures or prolonged blending. Turn off the blender and allow it to cool down for at least 30 minutes before resuming use. Reduce the load or add more liquid.
- **Loud noise during operation:** While powerful blenders can be noisy, excessive noise might indicate improper assembly or an unbalanced load. Ensure the container is seated correctly and ingredients are evenly distributed.

If the problem persists, please contact COZII customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	COZII
Model Number	ZM 5009
Power	2000 Peak Watt
Capacity (Pitcher)	1.85 Liters (64 oz)
Capacity (To-Go Cup)	600 mL (21 oz)
Product Dimensions	5.5"D x 8"W x 10"H
Voltage	120 Volts
Number of Speeds	8
Controls Type	Touch
Special Feature	Pulse Technology
Material Type Free	BPA Free
Container Material	Plastic
Item Weight	11.44 pounds

2000 PEAK WATTS POWERFUL MOTOR



Unique fan and
motor technology
reduce operating noise

Image: A close-up view of the COZII blender's motor base, emphasizing its 2000 Peak Watt powerful motor.



PATENTED DESIGN **6** BLADES

We hardened the blades to handle the toughest ingredients, for a smoother texture. Sharper and More durable.

Image: A top-down view of the COZII blender's pitcher, showcasing its patented 6-blade design engineered for smoother textures and durability.

8. WARRANTY & SUPPORT

Warranty Information

The COZII ZM 5009 Professional Countertop Blender comes with a **3-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal household use.

Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, troubleshooting assistance, or warranty inquiries, please contact COZII customer support:

- **Official Website:** cozii.life
- **After-sales Service Email:** cozillife@gmail.com
- **Facebook:** facebook.com/@COZIILIFE
- **YouTube:** youtube.com/@cozillife

- **TikTok:** tiktok.com/@cozilife