



Manuals.plus /

› [Lenovo /](#)

› [Lenovo IdeaPad 1 15AMN7 Laptop User Manual](#)

Lenovo IdeaPad 1 15AMN7

Lenovo IdeaPad 1 15AMN7 Laptop User Manual

Model: IdeaPad 1 15AMN7

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lenovo IdeaPad 1 15AMN7 laptop. Please read this guide thoroughly to ensure proper use and to maximize the performance and longevity of your device.

The Lenovo IdeaPad 1 15AMN7 is a 15.6-inch laptop equipped with an AMD Ryzen 5 7520U processor, 16GB LPDDR5 RAM, a 512GB NVMe M.2 SSD, and AMD Radeon 610M Graphics. It comes pre-installed with Windows 10 Pro and features Wi-Fi 6 connectivity.

1. SETUP

1.1 Unboxing and Initial Inspection

Carefully remove the laptop and all accessories from the packaging. Inspect the device for any signs of damage. The package should include the laptop, a 65W AC adapter, and an ONT 32GB USB Drive.



Image: The Lenovo IdeaPad 1 15AMN7 laptop shown open at an angle, displaying its screen and keyboard.

1.2 Connecting to Power

1. Connect the AC adapter to the power input port on the side of the laptop.
2. Plug the power cord into a wall outlet.
3. Allow the battery to charge for at least 30 minutes before initial use, or until the battery indicator shows sufficient charge.

1.3 First Boot-Up and Windows Setup

1. Open the laptop lid and press the power button, typically located on the top-right of the keyboard.
2. Follow the on-screen instructions to complete the Windows 10 Pro setup process. This includes selecting your region, language, creating a user account, and connecting to a Wi-Fi network.
3. It is recommended to connect to the internet during setup to download essential updates.

1.4 Connecting Peripherals

Utilize the available ports to connect external devices such as a mouse, external display, or USB storage devices.



Image: Left side of the laptop showing the power input, USB-A, HDMI, and USB-C ports.



Image: Right side of the laptop showing the headphone/microphone combo jack, card reader, and another USB-A port.

2. OPERATING YOUR LAPTOP

2.1 Power On/Off and Sleep Mode

- **Power On:** Press the power button.
- **Shut Down:** Click the Start button, then Power > Shut down.
- **Sleep Mode:** Close the lid or click the Start button, then Power > Sleep.

2.2 Keyboard and Touchpad

The laptop features a full-size keyboard with a numeric keypad and a multi-touch touchpad.



Image: A top-down view of the laptop's keyboard, including the numeric keypad, and the touchpad.

- **Touchpad Gestures:** Refer to Windows settings for customizable multi-touch gestures (e.g., two-finger scroll, pinch-to-zoom).
- **Function Keys:** Use the Fn key in combination with F1-F12 for quick access to features like volume control, screen brightness, and Wi-Fi toggle.

2.3 Connectivity

- **Wi-Fi 6:** Connect to wireless networks via the Wi-Fi settings in Windows.
- **Bluetooth 5.2:** Pair with Bluetooth devices such as headphones or speakers through Windows Bluetooth settings.
- **USB Ports:** The laptop includes 1x USB 3.2 Gen 1 Type-C, 1x USB 3.2 Gen 1 Type-A, and 1x USB 2.0 Type-A for connecting various USB devices.
- **HDMI:** Use the HDMI v1.4 port to connect to an external monitor or TV.
- **Card Reader:** Insert compatible memory cards for data transfer.

2.4 Camera and Audio

- **720p HD Camera:** Located at the top of the display, it includes a privacy shutter. Slide the shutter to cover or uncover the camera lens.
- **Dolby Audio:** The integrated stereo speakers (1.5W x2) provide enhanced audio experience. Adjust volume using function keys or Windows settings.

3. MAINTENANCE

3.1 Cleaning Your Laptop

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- **Keyboard and Chassis:** Use a soft cloth. For stubborn dirt, a slightly damp cloth with mild soap solution can be used, ensuring no liquid enters openings.
- **Vents:** Periodically clean the ventilation openings on the bottom and sides of the laptop to prevent dust buildup, which can affect cooling performance.




Image: The bottom panel of the laptop, showing the ventilation grilles and rubber feet.

3.2 Software Updates

Regularly check for and install Windows updates and driver updates from Lenovo's official support website to ensure optimal performance and security.

3.3 Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.
- For optimal battery health, avoid prolonged exposure to extreme temperatures.

4. TROUBLESHOOTING

4.1 Common Issues and Solutions

- **Laptop does not power on:** Ensure the AC adapter is securely connected to both the laptop and a working power outlet. Try a different outlet. If the battery is completely drained, allow it to charge for a while before attempting to power on.
- **No display:** If the laptop powers on but the screen remains black, try connecting an external monitor to the HDMI port to check if the issue is with the laptop's display. Ensure the display brightness is not set to

minimum.

- **Wi-Fi connectivity issues:** Check if Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Ensure drivers are up to date.
- **Slow performance:** Close unnecessary applications. Check for background processes consuming high resources. Ensure sufficient free storage space on the SSD. Run a system scan for malware.
- **Keyboard or touchpad not responding:** Restart the laptop. Check for updated drivers in Device Manager.

For more complex issues, refer to the Lenovo support website or contact customer service.

5. SPECIFICATIONS

Feature	Detail
Model Name	IdeaPad 1 15AMN7
Processor	AMD Ryzen 5 7520U (4-Core, up to 4.3GHz)
Graphics	AMD Radeon 610M Graphics (Integrated)
RAM	16GB LPDDR5 5500 MHz
Storage	512GB NVMe M.2 SSD
Display	15.6" FHD (1920 x 1080) 220 nits, Anti-glare, 45% NTSC, 60Hz
Operating System	Windows 10 Pro
Wireless Connectivity	Realtek Wi-Fi 6 (2x2), Bluetooth 5.2
Ports	1x USB 3.2 Gen 1 Type-C, 1x USB 3.2 Gen 1 Type-A, 1x USB 2.0 Type-A, 1x HDMI v1.4, 1x Headphone/Microphone Combo Jack, 1x Card Reader, 1x Power Jack
Camera	720p HD Camera with Privacy Shutter
Audio	Stereo speakers, 1.5W x2, Dolby Audio
Battery	3 Cell 42Wh (Up to 8 hours non-gaming battery life)
Dimensions (LxWxH)	14.18 x 9.29 x 0.70 inches
Weight	3.48 lbs
Color	Abyss Blue

6. WARRANTY AND SUPPORT

6.1 Product Warranty

Your Lenovo IdeaPad 1 15AMN7 laptop is covered by a standard manufacturer's warranty. Specific warranty

terms and duration are typically provided with your purchase documentation. Please retain your proof of purchase for warranty claims.

6.2 Technical Support

For technical assistance, driver downloads, or further support, please visit the official Lenovo support website. You can find contact information and resources by searching for your specific model (IdeaPad 1 15AMN7) on their support portal.

Lenovo Support Website: <https://support.lenovo.com>