



Manuals.plus /

› ChooChoo /

› ChooChoo SR2402-GY Shoe Storage Cabinet Instruction Manual

ChooChoo SR2402-GY

ChooChoo SR2402-GY Shoe Storage Cabinet Instruction Manual

Brand: ChooChoo | Model: SR2402-GY

1. INTRODUCTION

Thank you for choosing the ChooChoo SR2402-GY Shoe Storage Cabinet. This manual provides detailed instructions for the assembly, operation, and maintenance of your new shoe cabinet. Designed with a farmhouse style, this slim and narrow cabinet features two flip-top drawers, a built-in deodorizer, and additional hooks, making it ideal for entryways, living rooms, or porches. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- Always secure the cabinet to the wall using the provided anti-tip kit to prevent tipping and potential injury, especially in households with children or pets.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not overload the drawers. The cabinet is designed to hold up to 16 pairs of shoes, depending on shoe size.
- Keep small parts and packaging materials away from children during assembly.
- Assemble the unit on a soft, clean surface to prevent scratches.



Image: Safety instructions for securing the shoe cabinet to the wall using the anti-tip kit.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

3.1. Parts List

- Main cabinet panels (top, bottom, sides, back)
- Flip-top drawer panels (2 sets)
- Adjustable internal dividers
- Legs (4)
- Side hooks (2)
- Deodorizer unit with power cable

3.2. Hardware List

- Various screws, cam locks, and dowels
- Metal handles (2)
- Anti-tip kit (wall anchors, strap, screws)
- Cable clips for deodorizer cable

4. ASSEMBLY INSTRUCTIONS

Assembly is straightforward and typically takes 20-30 minutes with two people. A screwdriver is required.

4.1. General Assembly Tips

- It is recommended that at least two people install this product together.
- Follow the numbered steps in sequence.
- Do not overtighten screws to avoid damaging the wood.

4.2. Step-by-Step Guide

For a visual guide, please refer to the assembly videos below.

Your browser does not support the video tag.

Video: Detailed instructions on how to install the ChooChoo Shoe Cabinet, covering each step of the assembly process.

Your browser does not support the video tag.

Video: A comprehensive guide to the Shoe Storage Cabinet Installation, demonstrating the assembly process.



Image: Product dimensions of the ChooChoo Shoe Storage Cabinet, including height, width, and depth.



Image: An overview of the ChooChoo Shoe Storage Cabinet's key features, highlighting its design elements and functionalities.



Image: Illustration of the adjustable and removable shelf, demonstrating how to customize storage space for various shoe types.

5. OPERATING INSTRUCTIONS (DEODORIZER)

The ChooChoo Shoe Storage Cabinet features a built-in deodorizer to maintain freshness and hygiene. The deodorizer supports 4 cycle modes and 4 timing modes.

5.1. Deodorizer Functions

- **Remove Odors:** Eliminates unpleasant smells from shoes.
- **Sterilization:** Helps to reduce bacteria and germs.
- **Formaldehyde Reduction:** Contributes to a healthier environment by reducing formaldehyde.
- **Air Purification:** Circulates air to keep the cabinet fresh.




Image: Visual representation of the deodorizer's air purification and odor removal capabilities within the shoe cabinet.

5.2. Using the Deodorizer

To operate the deodorizer, connect the power cable to a suitable power source. Use the touch controls on the top panel to select your desired mode and timing.

Your browser does not support the video tag.

Video: Demonstration of the shoe cabinet's deodorizer operation mode, showing how to select timing and cycle modes.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your ChooChoo Shoe Storage Cabinet, follow these maintenance tips:

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Keep the cabinet away from direct sunlight and excessive moisture to prevent warping or discoloration.
- Regularly check and tighten all hardware to maintain stability.
- Clean the deodorizer unit's air vents periodically to ensure optimal performance.

7. TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet feels unstable/wobbly	Screws are loose; Anti-tip kit not installed.	Tighten all screws. Install the anti-tip kit securely to the wall.
Drawers do not close properly	Shoes are too large or improperly placed; Internal divider is misaligned.	Adjust the internal divider or remove it for taller shoes. Ensure shoes are placed flat.
Deodorizer not working	Power cable not connected; Unit is off.	Check power connection. Press the power button on the deodorizer unit.

8. SPECIFICATIONS

Feature	Detail
Brand	ChooChoo
Model Number	SR2402-GY
Color	Grey
Material	Engineered Wood
Product Dimensions	9.45"D x 31.5"W x 42.9"H
Item Weight	43.4 Pounds
Number of Drawers	2
Number of Shelves	3 (internal adjustable)
Additional Features	Adjustable Shelf, Anti-Tipping, Removable Shelf, Built-in Deodorizer
Installation Type	Freestanding

9. WARRANTY AND SUPPORT

For any questions, concerns, or to report missing/damaged parts, please contact ChooChoo customer support. Information regarding extended protection plans may be available from your retailer.

- **2-Year Protection Plan:** Available for purchase.
- **3-Year Protection Plan:** Available for purchase.
- **Complete Protect:** Monthly plan covering eligible past and future purchases.

Please refer to your purchase documentation for specific warranty details and contact information.