

YESHOMY YH-0158SHUA44

YESHOMY Dresser for Bedroom, 6 Drawer Dressers, Wide Modern TV Stand

USER MANUAL - MODEL: YH-0158SHUA44

1. INTRODUCTION

Thank you for choosing the YESHOMY 6-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This versatile dresser is designed to offer ample storage and can also function as a TV stand, accommodating televisions up to 65 inches. Its robust construction ensures durability and stability for everyday use.

2. SAFETY INFORMATION

- **Anti-Tip Kit:** It is crucial to install the included anti-tip kit to prevent accidental tipping, especially in households with children or pets. Follow the assembly instructions carefully for proper installation.
- **Weight Capacity:** The top surface of the dresser has a maximum weight capacity of **200 lbs**. Each drawer has a maximum weight capacity of **30 lbs**. Do not exceed these limits to ensure stability and prevent damage.
- **Level Surface:** Always place the dresser on a flat, level surface to prevent wobbling and ensure stability.
- **Supervision:** Do not allow children to climb on or play with the dresser.

3. PACKAGE CONTENTS

Before assembly, please verify that all components listed in the assembly guide are present and undamaged. The package typically includes:

- Dresser components (panels, drawers, hardware)
- Assembly Guide
- Anti-tip kit

- Necessary assembly tools (e.g., Allen wrench, if applicable)

If any parts are missing or damaged, please contact customer support immediately.

4. SETUP & ASSEMBLY

Assembly of the YESHOMY Dresser is required. Please follow the detailed, step-by-step instructions provided in the separate assembly guide included with your product. Ensure you have adequate space and the necessary tools before beginning.

Key Assembly Considerations:

- **Identify Parts:** Lay out all parts and hardware, matching them with the diagrams in the assembly guide.
- **Secure Connections:** Ensure all screws and fasteners are tightened securely, but do not overtighten to avoid stripping or damaging the wood.
- **Anti-Tip Installation:** The anti-tip kit must be installed as directed in the assembly guide to secure the dresser to a wall. This is a critical safety step.



Figure 4.1: Product Dimensions. This image illustrates the overall dimensions of the dresser: 58.27 inches (W) x 15.16 inches (D) x 26.57 inches (H), along with individual drawer dimensions.



Figure 4.2: Key Components. This diagram highlights important features such as the anti-tip kit for safety, smooth slide rails for drawers, durable metal handles, and the solid base construction.

5. OPERATING INSTRUCTIONS

5.1 Drawer Usage

The dresser features six spacious drawers designed for smooth operation. Each drawer is equipped with high-strength hardware to ensure easy pushing and pulling. Organize your belongings efficiently within the drawers, keeping in mind the **30 lbs** weight limit per drawer.



Figure 5.1: Drawer Capacity and Features. This image demonstrates the large storage capacity of the drawers and highlights the waterproof thickened top surface and stable structure of the dresser.

5.2 Using as a TV Stand

The robust top surface of the dresser is designed to function as a TV stand, capable of accommodating televisions up to 65 inches. Ensure the television's weight does not exceed the **200 lbs** top weight capacity. Distribute the weight evenly on the surface.



Figure 5.2: Dresser as a TV Stand. This image shows the YESHOMY dresser with a television placed on its top surface, illustrating its dual functionality.

5.3 Storage and Organization

Utilize the six drawers for organized storage of clothing, accessories, or other household items. The spacious design helps maintain a tidy living space.



Figure 5.3: Organized Storage. This image provides an internal view of the dresser, demonstrating how items can be neatly stored within the drawers.

6. MAINTENANCE & CARE

- **Cleaning:** Wipe the dresser surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry or slightly damp cloth to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.
- **Hardware:** Periodically check and tighten all hardware connections to ensure the dresser remains stable and secure.

7. TROUBLESHOOTING

If you encounter any issues with your YESHOMY dresser, please refer to the following common solutions:

- **Wobbly Dresser:** Ensure the dresser is placed on a level surface. Check all assembly screws and tighten them if loose. Verify the anti-tip kit is securely installed.
- **Sticking Drawers:** Ensure the drawer slides are correctly aligned and free of obstructions. Re-check the assembly

of the drawer and its runners according to the instruction manual. Do not overload drawers beyond their weight capacity.

- **Missing Parts:** If you find any parts missing during assembly, do not proceed. Contact customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	YESHOMY
Model Number	YH-0158SHUA44
Product Dimensions (L x W x H)	58.27" x 15.16" x 26.57"
Color	Dark Yellow
Finish Type	Matte Finish
Furniture Finish (Hardware)	Silver (Drawer Pulls)
Item Weight	89 Pounds
Top Weight Capacity	200 lbs
Drawer Weight Capacity (each)	30 lbs
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Included Components	A Dresser

9. SUPPORT

If you have any questions regarding the assembly, operation, or maintenance of your YESHOMY dresser, please do not hesitate to contact our customer support team. Refer to your purchase documentation for specific contact details or visit the official YESHOMY website for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DRK7RB2D>

More documents and user manuals: <https://manuals.plus/>