

Furnistyle ZFFS-0016

Furnistyle Gaming Chair with Footrest (Model ZFFS-0016) - Instruction Manual

Your guide to assembly, operation, and care.

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Furnistyle Gaming Chair with Footrest. Designed for comfort and durability, this ergonomic chair features a spacious 19-inch-wide flat seat, supportive neck and lumbar pillows, and a retractable footrest. It is upholstered in premium waterproof PU leather and padded with high-density responsive foam, ensuring comfort during extended use.

Key features include linkage armrests that adjust with the backrest, a backrest that reclines from 90° to 135°, 360° swivel, and 4 inches of adjustable height. The chair is built with a reinforced steel frame, silent casters, and a heavy-duty nylon base, supporting up to 300 pounds.

SAFETY INFORMATION

Before assembly and use, please observe the following safety guidelines:

- Inspect the product upon delivery for any damages. Do not proceed with assembly if significant damage is found.
- Avoid exposing the chair to direct sunlight for prolonged periods, as this may lead to degradation of the upholstery material.
- Ensure all screws and bolts are securely tightened after assembly and periodically check for tightness during use.
- Do not stand on the chair or use it for purposes other than its intended use as a seating device.
- Keep small children and pets away from the chair during assembly to prevent accidents.

SETUP AND ASSEMBLY

Assembly of the Furnistyle Gaming Chair is designed to be straightforward, with an estimated setup time of 30 minutes. All necessary parts and a detailed assembly guide are included in the package.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the assembly

guide are present and undamaged.

2. **Assemble the Base:** Attach the five-star base legs to the central hub using the provided screws and Allen wrench. Insert the silent casters into the ends of each leg.
3. **Install Gas Lift:** Drop the gas lift cylinder into the central hole of the assembled base.
4. **Attach Control Unit to Seat:** Align the holes on the control unit with the pre-drilled holes on the underside of the seat cushion. Secure it with screws.
5. **Attach Footrest Mechanism:** Insert the footrest anchor inserts into the designated slots on the underside of the seat. Slide the retractable footrest into the mechanism.
6. **Connect Seat to Base:** Place the assembled seat onto the gas lift cylinder, ensuring it is securely seated.
7. **Attach Backrest Plate:** Mount the steel plate upright to the backrest using screws.
8. **Attach Backrest to Seat:** Secure the backrest to the seat using the appropriate screws. Close any Velcro flaps to conceal connections.
9. **Install Armrests:** Attach the padded linkage armrests to the sides of the chair, securing them with screws. Push in the protective caps over the screw heads.
10. **Attach Cushions:** Clip the headrest pillow onto the top of the backrest. Loop the lumbar pillow straps around the backrest and clasp them together, positioning the pillow for optimal support.

Your browser does not support the video tag.

Video: Furnistyle Gaming Chair Installation Guide. This video demonstrates the step-by-step assembly process for the gaming chair, from attaching the base to securing the cushions.




Image: Diagram illustrating the product dimensions of the Furnistyle Gaming Chair, including height, width, and depth measurements.

OPERATING INSTRUCTIONS

Your Furnistyle Gaming Chair offers multiple adjustment options for personalized comfort:

- **Recline Function:** The backrest can be adjusted effortlessly from an upright 90° position to a reclined 135° angle. Use the recline lever located on the side of the seat to adjust and lock the backrest at your desired angle.
- **Height Adjustment:** Adjust the chair's height by up to 4 inches using the lift lever. This allows you to find the optimal seating height for your desk or gaming setup.

- **360° Swivel:** The chair features a smooth 360° swivel base, allowing for easy rotation and movement without needing to reposition the entire chair.
- **Linkage Armrests:** The padded armrests are designed to automatically adjust their angle in conjunction with the backrest's recline, providing continuous support for your elbows and arms.
- **Retractable Footrest:** For enhanced relaxation, pull out the flip-up footrest located beneath the seat. Extend it fully to support your legs when reclining, and push it back in when not in use.
- **Lumbar and Neck Support:** The included lumbar and neck pillows are adjustable. Position them to provide targeted support to your lower back and neck, reducing strain during long sessions.



Image: Visual representation of the adjustable features of the gaming chair, including recline angles, height adjustment, 360° swivel, silent casters, and the flip-up footrest.

Your browser does not support the video tag.

Video: Furnistyle Wide Gaming Chair for Adults - Showcase Video. This video highlights the various features and ergonomic design of the gaming chair, including its wide seat, linkage armrests, and reclining capabilities.

MAINTENANCE

To ensure the longevity and appearance of your Furnistyle Gaming Chair, follow these care instructions:

- **Spot Clean:** For minor spills or stains, immediately spot clean the affected area with a soft, damp cloth and a mild soap solution. Gently blot the area; do not rub vigorously.
- **Wipe Clean:** Regularly wipe down the PU leather surfaces with a clean, dry or slightly damp cloth to remove dust and dirt.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the upholstery.
- **Check Fasteners:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Caster Care:** Keep the silent casters free of hair and debris to ensure smooth movement.

TROUBLESHOOTING

If you encounter any issues with your Furnistyle Gaming Chair, please refer to the following general advice:

- **Chair Wobbles:** Ensure all screws and bolts are securely tightened. Check that the base is assembled correctly and the gas lift is properly inserted.
- **Difficulty Reclining/Adjusting Height:** Verify that the levers are engaged correctly. Sometimes, a slight shift in weight is needed to activate the mechanism.
- **Casters Not Rolling Smoothly:** Check the casters for any trapped debris (hair, lint, etc.) and clean them thoroughly.
- **Unusual Noises:** Inspect all connections for looseness. Applying a small amount of silicone lubricant to moving parts (excluding the gas lift cylinder) may help.

For persistent issues or concerns not addressed here, please contact Furnistyle customer service for assistance.

SPECIFICATIONS

Attribute	Detail
Brand	Furnistyle
Model Name	Black and White Gaming Chair
Model Number	ZFFS-0016
Color	Blackwhite (Flat)
Material	PU Leather, Sponge
Product Dimensions	25.75"D x 25.75"W x 49.75"H
Size	24.8"W x 20.5"D x 50.8"H
Maximum Weight Recommendation	300 Pounds
Back Style	Wing Back
Special Features	Adjustable Backrest, Adjustable Height, Adjustable Lumbar, Arm Rest, Ergonomic
Reclining Position Count	Infinite Position (90°-135°)
Swivel	360°
Included Components	Arm Pad, Caster, Cushion, Headrest, Lumbar Pillow, Retractable Footrest
Item Weight	36 pounds
UPC	769643183258

WARRANTY AND SUPPORT

Furnistyle is committed to providing quality products and excellent customer service. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

If you have any questions, concerns, or require assistance with your product, our professional customer service team is available to help. Please refer to the contact information provided with your purchase or on the official Furnistyle website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question