

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LINSY HOME](#) /
- › [LINSY Home Gel Memory Foam Mattress Topper \(Model HM010, 160 x 200 x 7.5cm\) Instruction Manual](#)

## LINSY HOME HM010

# LINSY Home Gel Memory Foam Mattress Topper

Model: HM010 | Size: 160 x 200 x 7.5cm

## INTRODUCTION

---

Thank you for choosing the LINSY Home Gel Memory Foam Mattress Topper. This topper is designed to enhance your sleep experience by providing superior comfort and support. Featuring breathable gel memory foam and a luxurious Tencel cover, it adapts to your body's contours, distributes weight evenly, and promotes air circulation for a refreshing and odorless sleep environment. The anti-slip bottom and adjustable corner straps ensure the topper stays securely in place.



Image: The LINSY Home Gel Memory Foam Mattress Topper placed on a bed, ready for use.

## SETUP INSTRUCTIONS

1. **Unpack the Topper:** Carefully remove the mattress topper from its packaging. The topper is compressed and rolled for shipping.
2. **Allow for Expansion:** Place the topper flat on a clean, dry surface. Allow 24 to 72 hours for the memory foam to fully expand and regain its original shape and thickness. Minor initial odor is normal and will dissipate during this period.
3. **Position on Mattress:** Once fully expanded, place the mattress topper directly on top of your existing mattress. Ensure it is centered and aligned with the mattress edges.
4. **Secure with Straps:** Utilize the adjustable elastic straps located at each corner of the topper. Stretch these straps over the corners of your mattress to secure the topper firmly in place and prevent shifting during sleep.



Image: A person unrolling and positioning the mattress topper on a bed.




Image: Detail of the non-slip bottom and adjustable corner strap for secure placement.

## USAGE

---

The LINSY Home Gel Memory Foam Mattress Topper is designed for versatile use, suitable for box spring beds, guest beds, caravans, or sofas. Its advanced construction provides a comfortable and supportive sleep surface.

- **Gel Memory Foam:** The breathable memory foam adapts perfectly to your body's morphology, distributing weight evenly to relieve pressure points.
- **Enhanced Airflow:** Special perforations within the foam ensure good air circulation, making the topper highly breathable and contributing to a fresh sleep climate.
- **Tencel Fabric Cover:** The luxurious Tencel cover is soft, breathable, and cooling, providing a pleasant and hypoallergenic surface for sleep. It also features moisture-wicking properties to keep you dry.



Image: Exploded view diagram illustrating the Tencel fabric, Swirl Gel Memory Foam, and breathable mesh base layers.



Image: Close-up of the soft, textured Tencel fabric cover.



Image: CertiPUR-US certification logo, ensuring foam quality and safety.

## MAINTENANCE

Proper care will extend the life and performance of your mattress topper.

- **Removable Cover:** The Tencel cover is equipped with a zipper, making it easy to remove for cleaning.
- **Washing Instructions:** The cover is machine washable. Please follow the care label instructions, typically machine wash cold on a gentle cycle. Do not bleach. Tumble dry low or air dry.
- **Foam Care:** The memory foam core itself is not washable. If the foam gets wet, gently blot with a clean towel and allow it to air dry completely in a well-ventilated area away from direct sunlight or heat. Do not

machine wash or dry the foam.



Image: Demonstrating the easy removal of the topper cover via zipper.



Image: The removable cover next to a washing machine, highlighting its machine-washable feature.

## TROUBLESHOOTING

- **Initial Odor:** New memory foam products may have a slight, harmless odor upon unpacking. This is normal and will typically dissipate within 24-72 hours in a well-ventilated room.
- **Slow Expansion:** If the topper does not fully expand within 24 hours, allow additional time (up to 72 hours). Cooler temperatures can slow expansion. Ensure it is laid flat in a warm room.
- **Size Discrepancy:** While manufactured to precise specifications, minor variations in dimensions can occur. If you experience a significant size discrepancy, please contact customer support.
- **Topper Shifting:** Ensure the corner straps are securely fastened around your mattress. The anti-slip bottom is designed to minimize movement, but proper strap application is crucial.

## SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	200 x 160 x 7.5 cm
Product Weight	11.52 kg

Feature	Detail
Model Number	HM010
Brand	LINSY HOME
Color	White
Material	Gel Memory Foam, Tencel
Fabric Type	30% Tencel
Special Feature	Moisture-wicking
Closure Type	Zipper
Care Instructions	Machine wash (cover only)
Water Resistance Level	Water repellent
Age Range (Description)	Adult

## SUPPORT

---

For additional information, assistance, or if you have any questions regarding your LINSY Home Gel Memory Foam Mattress Topper, please do not hesitate to contact our customer service team. We are committed to ensuring your satisfaction.

Please refer to your purchase documentation or the retailer's website for specific contact details.