Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax SL-5406GRN

Snailax Collapsible Foot Spa Massager SL-5406GRN User Manual

Model: SL-5406GRN

1. Introduction

Thank you for choosing the Snailax Collapsible Foot Spa Massager. This device is designed to provide a relaxing foot soaking experience with features such as adjustable heat, massage rollers, bubble therapy, and a pumice stone. Its collapsible design ensures convenient storage. Please read this manual thoroughly before use to ensure safe and proper operation.

2. Safety Information

To reduce the risk of electric shock, burns, fire, or injury, always follow these basic safety precautions:

- Read all instructions before using this appliance.
- Do not use while sleeping or drowsy.
- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use on sensitive skin areas or where circulation is poor.
- This appliance is for household use only.

3. Product Components

The Snailax Collapsible Foot Spa Massager includes the following key components:

- **Control Panel:** Digital display with buttons for power, temperature adjustment, timer, and bubble function.
- **Massage Rollers:** Eight integrated rollers designed to soothe the soles of your feet.
- **Pumice Stone:** A removable stone for exfoliating rough skin.
- **Bubble Holes:** Located at the bottom for bubble therapy.
- **Heat Source:** Integrated heating element to maintain water temperature.
- **Drainage Outlet:** For easy water removal.
- **Collapsible Basin:** Flexible material allowing for compact storage.
- **Sturdy Handle:** For convenient carrying and portability.



Image 3.1: Top view of the Snailax Foot Spa, showing the control panel, internal massage rollers, and bubbling water.



Image 3.2: Detailed view of internal components, highlighting the bubble holes, pumice stone, heat source, and red light.




Image 3.3: Close-up of the eight massage rollers designed for foot relaxation.

4. Setup

1. **Unpack:** Carefully remove the foot spa from its packaging.
2. **Expand:** Place the collapsed foot spa on a flat, stable surface. Gently push down on the bottom of the basin while pulling up on the top edges to expand it to its full size. Ensure all sides are securely locked into place.
3. **Fill with Water:** Fill the foot spa with water up to the 'MAX' line indicated inside the basin. Do not overfill.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.



Image 4.1: The foot spa in its collapsed state, being stored under furniture, demonstrating its space-saving design.



Image 4.2: Visual representation of the foot spa's foldable design, showing its compact form for storage.

5. Operating Instructions

Once set up, follow these steps to operate your Snailax Foot Spa:

1. **Power On:** Press the ON/OFF button on the control panel to turn on the foot spa.
2. **Set Temperature:** Use the 'Temp+' and 'Temp-' buttons to adjust the desired water temperature. The temperature range is 95°F-118°F (35°C-48°C). The foot spa will automatically heat and maintain this temperature.
3. **Set Timer:** Press the 'Timer' button to set the duration of your foot soak. Available settings are 10, 20, 30, 40, 50, or 60 minutes.
4. **Activate Bubbles:** Press the 'Bubble' button to activate the bubble massage function.
5. **Begin Soak:** Place your feet into the water, ensuring they are comfortably positioned over the massage rollers. You can gently move your feet back and forth over the rollers for an enhanced massage.
6. **Pumice Stone Use:** The integrated pumice stone can be used to gently exfoliate the soles of your feet during your soak.
7. **Power Off:** After your session, press the ON/OFF button to turn off the foot spa and unplug it from the outlet.



Image 5.1: Detailed view of the easy-to-operate control panel.



Image 5.2: Illustration of the adjustable temperature feature, maintaining water warmth for a comfortable soak.




Image 5.3: Overview of the six timer settings, allowing for customized session durations.

Image 5.4: The foot spa in operation, demonstrating bubble massage and red light features.

6. Maintenance and Cleaning

1. **Drain Water:** After each use, unplug the foot spa. Open the drainage outlet to empty the water.
2. **Clean:** Rinse the basin with clean water. Wipe down the interior and exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
3. **Dry:** Allow the foot spa to air dry completely before collapsing and storing.
4. **Store:** To collapse, gently push down on the top edges while lifting the bottom of the basin. Store in a cool, dry place, such as under a sofa or bed, away from direct sunlight.



Image 6.1: The foot spa's upgraded handle, designed for easier carrying and portability.

7. Troubleshooting

Problem	Possible Cause	Solution
Foot spa does not turn on.	Not plugged in; power outlet malfunction; damaged cord/plug.	Ensure the power cord is securely plugged into a working outlet. Check for any visible damage to the cord or plug.
Water is not heating or cools down quickly.	Temperature setting too low; heating element malfunction.	Verify the temperature is set to the desired level (95°F-118°F). Ensure the room temperature is not excessively cold. If the issue persists, contact customer support.
Bubbles are weak or not working.	Bubble function not activated; air vents blocked.	Press the 'Bubble' button on the control panel. Ensure the bubble holes at the bottom of the basin are clear of debris.
Massage rollers are not moving (if applicable).	Rollers are manual; debris obstructing movement.	The massage rollers are designed for manual foot movement. Ensure no debris is preventing smooth rotation.

8. Specifications

- **Model Number:** SL-5406GRN
- **Product Dimensions:** 13.39 x 4.53 x 16.14 inches (Expanded)
- **Weight:** 5.09 Pounds
- **Power Source:** Corded Electric
- **Material:** Acrylonitrile Butadiene Styrene
- **Temperature Range:** 95°F-118°F (35°C-48°C)
- **Timer Settings:** 10, 20, 30, 40, 50, 60 minutes
- **Manufacturer:** Snailax

9. Warranty and Support

Snailax products are manufactured with a focus on quality and performance. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or contact Snailax customer support directly. Keep your purchase receipt as proof of purchase.
For technical assistance, troubleshooting, or warranty claims, please contact Snailax customer service through their official website or the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRNH7KB4

More documents and user manuals: **https://manuals.plus/**