

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [SHPAI](#) /
- › SHPAI 10' x 14' Outdoor Hardtop Gazebo Instruction Manual

SHPAI 10' x 14' with Gutters

SHPAI 10' x 14' Outdoor Hardtop Gazebo Instruction Manual

Model: 10' x 14' with Gutters

1. PRODUCT OVERVIEW

The SHPAI 10' x 14' Outdoor Hardtop Gazebo is designed to provide a durable and comfortable outdoor living space. It features a galvanized steel double roof, integrated drainage system, and removable curtains and netting for versatile use.



Image 1.1: The SHPAI 10' x 14' Outdoor Hardtop Gazebo in an outdoor setting.

Key Features:

- **Galvanized Steel Double Roof:** Fade-resistant, rust-resistant, provides UV protection, and withstands heavy snow. The double-roof design enhances ventilation and reduces wind speed.
- **Integrated Drainage System:** Sloped roof and gutters direct rainwater to the four corners, preventing water from dripping around the gazebo.
- **Removable Netting & Curtains:** Double-track system with double-sided zippers for easy operation. Netting provides ventilation and insect protection. Waterproof curtains offer UV protection, rain resistance, privacy, and warmth.
- **Ceiling Hooks:** Three "J" hooks are provided for hanging lights or fans (maximum capacity 25 lbs).
- **Enhanced Stability:** Features a triangular structure, upgraded 3.94" posts, and anchoring plates with plastic base covers to prevent rust and protect from sharp screws.

2. SAFETY INFORMATION

Read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or

damage to the product.

- **Assembly Team:** Always assemble this gazebo with a team of 2-5 people. Attempting to assemble alone can be difficult and unsafe.
- **Stable Foundation:** Secure the gazebo to a stable and level foundation using appropriate anchoring methods.
- **Weight Capacity:** Do not exceed the 25 lbs maximum capacity for the ceiling hooks.
- **Flammable Materials:** Keep the area around the gazebo clear of flammable materials, especially when using lights or fans.
- **Sharp Edges:** Wear protective gloves when handling roof pieces and other metal components during assembly to avoid cuts.
- **Weather Conditions:** While designed to withstand various weather conditions, extreme weather (e.g., severe storms, very heavy snow loads beyond specifications) may require additional precautions or temporary disassembly.
- **Children and Pets:** Ensure plastic base covers are properly installed to protect children and pets from sharp screws.

3. ASSEMBLY INSTRUCTIONS

Assembly typically takes 3-6 hours with a team of 2-5 people. Follow the detailed step-by-step instructions provided in the separate assembly manual included with your product. The following provides general guidance and important tips.

3.1 Pre-Assembly Checklist

- Verify all parts are present and undamaged against the parts list in your assembly manual.
- Gather necessary tools (e.g., wrenches, screwdrivers, ladder).
- Ensure you have a clear, level assembly area.
- Have at least two, preferably more, adults available to assist with assembly.
- Wear appropriate safety gear, including gloves, especially when handling metal roof panels.

3.2 General Assembly Steps

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out. Refer to the parts diagram in your manual to identify each piece.
2. **Assemble Frame:** Begin by assembling the main support posts and horizontal beams. Ensure all connections are secure but do not fully tighten bolts until the entire frame is aligned.
3. **Install Roof Structure:** Attach the roof support beams and the double-roof frame. Pay attention to the orientation of the pieces for proper ventilation and drainage.
4. **Attach Roof Panels:** Carefully install the galvanized steel roof panels. Ensure they overlap correctly for water resistance. **Important:** Do not overtighten roof support screws initially; allow for slight adjustment before final tightening.
5. **Secure Anchoring Plates:** Once the main structure is complete and aligned, secure the anchoring plates to your chosen foundation. Install the plastic base covers over the anchoring plates.
6. **Hang Curtains and Netting:** Install the double-track system and hang the netting and curtains.
7. **Final Tightening:** Once all components are in place and aligned, systematically tighten all bolts and screws.



Triangular Structure
more stable



Galvanized Steel Frame
more durable




Anchoring Plate
more sturdy



Image 3.1: Illustration of the triangular structure, galvanized steel frame, and anchoring plate for enhanced stability.

Upgraded Screws to Stainless Steel Screws



ORDINARY IRON SCREWS

After 1 year
Ordinary screws



SHPAI

After 1 year
Provide superior durability and rust resistance

Image 3.2: Upgraded stainless steel screws provide superior durability and rust resistance for assembly.

UPGRADED 3.94" POSTS

Enhanced stability and durability



Plastic Base Cover

Prevents rust and protects children and pets from sharp screws, enhancing safety.



Image 3.3: Detail of the upgraded 3.94" posts and plastic base cover, designed to prevent rust and protect from sharp screws.

4. OPERATING INSTRUCTIONS

4.1 Curtains and Netting

The gazebo features a double-track system for the netting and curtains, allowing for flexible configuration:

- **Fully Open:** Slide both the netting and curtains to the side posts to enjoy an unobstructed view and maximum ventilation.
- **Semi-Open (Netting Only):** Close the netting to keep insects out while maintaining airflow and partial visibility.
- **Fully Closed:** Close both the netting and curtains for privacy, protection from UV rays, rain, and to retain warmth.

The double-sided zippers allow for easy access from both inside and outside the gazebo.

REMOVEABLE CURTAINS & NETTINGS




Image 4.1: Demonstrates the multi-functional curtains and netting in fully open, semi-open, and fully closed positions.

4.2 Ceiling Hooks

Three ceiling hooks are provided for hanging decorative items, lights, or small fans. Ensure the total weight on each hook does not exceed 25 lbs.

NETTING & HOOKS ON TOP

Netting prevents bugs while hooks for hanging lights or deco.



Image 4.2: View of the ceiling netting and integrated hooks for hanging lights or decorations.

5. MAINTENANCE

Regular maintenance will extend the life and appearance of your SHPAI gazebo.

- **Cleaning the Roof:** Periodically clean the galvanized steel roof panels to remove leaves, debris, and dirt. Use a soft brush or cloth with mild soap and water. Rinse thoroughly.
- **Cleaning Curtains and Netting:** The polyester curtains and Textilene netting can be cleaned with mild soap and water. Allow them to air dry completely before retracting or storing.
- **Frame Inspection:** Annually inspect the alloy steel frame for any signs of rust, loose bolts, or damage. Tighten any loose fasteners. Address rust spots promptly with appropriate rust-inhibiting paint.
- **Drainage System:** Ensure the gutters and drainage holes are clear of debris to allow for efficient water runoff.
- **Winter Care:** While the roof is designed to withstand snow, heavy accumulation should be cleared to prevent excessive stress on the structure.

6. TROUBLESHOOTING

- **Water Accumulation on Roof:**

- Check if the roof panels are correctly installed and overlapping.
- Ensure the gutters and drainage holes are free from debris.
- Verify the gazebo is installed on a level surface.

- **Curtains/Netting Not Sliding Smoothly:**

- Inspect the tracks for any obstructions or dirt. Clean as necessary.
- Ensure the tracks are not bent or damaged.

- **Gazebo Feels Unstable:**

- Re-check all bolts and screws for tightness, especially those connecting the posts to the base and roof structure.
- Confirm the anchoring plates are securely fastened to the ground.
- Ensure the ground beneath the gazebo is level.

- **Difficulty During Assembly:**

- Refer to the detailed assembly manual for specific step-by-step instructions and diagrams.
- Ensure you have enough people assisting with the assembly.
- Do not fully tighten all screws until the entire section is assembled and aligned to allow for minor adjustments.

7. SPECIFICATIONS

Feature	Detail
Brand	SHPAI
Model	10' x 14' with Gutters
Product Dimensions (L x W x H)	166.4" x 117.2" x 114.7" (422.6 cm x 297.7 cm x 291.3 cm)
Item Weight	322.7 Pounds (146.4 kg)
Frame Material	Alloy Steel
Roof Material	Galvanized Steel
Curtain Material	180G/M2 PU Coated Polyester
Netting Material	Textilene (CPAI-84 Fire-resistant)
Color	Gray
Water Resistance Level	Waterproof
UV Protection	99% UV-proof, UPF 50+
Assembly Required	Yes

GAZEBO DIMENSION



Image 7.1: Detailed dimensions of the gazebo, including height, length, and width.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact SHPAI customer service directly. SHPAI is committed to providing high-quality products and support.

If you encounter any issues or have questions regarding your gazebo, please contact SHPAI customer support through the retailer where the product was purchased or via the official SHPAI website.

Manufacturer: SHPAI