

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Outsunny](#) /

› [Outsunny 7.6 x 3.4ft Horizontal Outdoor Storage Shed for 3 Trash Cans \(Model: 84H-206V00CG\) - Instruction Manual](#)

Outsunny 84H-206V00CG

Outsunny 7.6 x 3.4ft Horizontal Outdoor Storage Shed Instruction Manual

Model: 84H-206V00CG

Brand: Outsunny

Safety Information Instructions	Product Overview Maintenance	Setup & Assembly Troubleshooting	Operating Specifications	Warranty & Support
---	--	--	--	--

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or property damage.

- Always follow the assembly instructions carefully.
- Use appropriate tools and safety gear when handling components.
- Keep hands and fingers away from the locking mechanism when locking or unlocking the doors.
- Always supervise children when they are near the shed.
- Do not exceed the weight limit of the shed.
- Ensure the shed is placed on a level, stable surface to prevent tipping.
- Secure the shed to the ground using appropriate anchors (not included) to prevent wind damage.

2. PRODUCT OVERVIEW

The Outsunny 7.6 x 3.4ft Horizontal Outdoor Storage Shed is designed to provide a secure and organized solution for storing up to three standard trash cans, garden tools, or other outdoor essentials. Constructed from durable galvanized steel, it offers excellent weather resistance and features convenient access options.

Key Features:

- **Triple Bin Protection:** Accommodates up to 3 bins, protecting them from elements and pests.
- **Convenient Lid Access:** Features a pneumatic lifting lid for easy disposal without opening the main doors.
- **Secure Locking System:** Equipped with lockable double doors and a secure locking system (locks

and keys included) for enhanced security.

- **Weather-Resistant Construction:** Made from galvanized steel to resist blisters, cracks, warps, and is waterproof for lasting outdoor use.
- **Spacious Design:** Offers ample storage with overall dimensions of 91.7" W x 41.3" D x 46.7" /52.4" H.



Image: The Outsunny Horizontal Outdoor Storage Shed with its top lid and double front doors open, revealing the spacious interior designed to hold multiple trash cans. A shovel and watering can are visible on the side, indicating its versatility for garden storage.

3. SETUP & ASSEMBLY

Assembly of the Outsunny storage shed requires careful attention to detail. It is recommended to have at least two people for assembly. Ensure all parts are present before beginning.

Assembly Overview:

1. **Base Frame Assembly:** Connect the base frame components using the provided fasteners. Ensure all corners are securely joined.
2. **Side and Back Panel Installation:** Attach the side and back panels to the assembled base frame. Secure them with screws, ensuring proper alignment.
3. **Front Frame and Door Installation:** Assemble the front frame and attach it to the side panels. Install

the double doors, ensuring they open and close smoothly.

4. **Roof Panel Assembly:** Secure the roof panels to the top frame. Attach the pneumatic lifting mechanism for the lid.
5. **Final Checks:** Verify all screws are tightened, and all components are stable. Test the lid and door mechanisms.

Visual Assembly Guides:

Video: An official installation guide for the Outsunny 84H-206V00SR Trash Can Shed, demonstrating the step-by-step assembly process. This video is provided by the seller, Aosom Canada.

Video: An official installation guide for an Extended Outdoor Garbage Bin Storage Shed, demonstrating the step-by-step assembly process. This video is provided by the seller, guangjingbing.




Image: A detailed view of the pneumatic lifting lid mechanism, highlighting the smooth operation for effortless rubbish disposal.

LOCKABLE DOUBLE DOORS

Can be opened and closed independently



Door bolts



Lock and keys included



Image: A close-up of the lockable double doors, showing the door bolts and the included lock and keys for secure storage.

4. OPERATING INSTRUCTIONS

Lid Access:

To dispose of waste, simply lift the top lid. The pneumatic mechanism will assist in opening and holding the lid in place, allowing for convenient, hands-free access to the bins inside. Gently push down to close.

Door Access:

To move trash cans in or out, unlock the double doors using the provided keys. The doors can be opened independently for flexible access. Ensure doors are securely latched and locked after use.



Image: The Outsunny storage shed with its double doors fully open, revealing two green recycling bins stored neatly inside. This demonstrates the ease of access for placing or removing bins.

5. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your storage shed.

- **Cleaning:** Clean the shed periodically with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the galvanized steel finish.
- **Inspection:** Regularly inspect all fasteners and connections to ensure they remain tight. Tighten any loose screws as needed.
- **Lubrication:** Apply a silicone-based lubricant to the door hinges and pneumatic lid mechanism annually to ensure smooth operation.
- **Drainage:** Ensure the area around the shed is clear of debris to allow for proper water drainage and prevent moisture buildup.

6. TROUBLESHOOTING

- **Difficulty Opening/Closing Doors or Lid:** Check for obstructions around hinges or tracks. Ensure all fasteners are properly tightened. Lubricate moving parts if necessary.

- **Water Leakage:** Verify that all panels are correctly installed and sealed. Check for any gaps or damage to the roof or walls. Ensure the shed is on a level surface.
- **Shed Instability:** Confirm the shed is on a flat, stable surface. Consider anchoring the shed to the ground for added stability, especially in windy conditions.

7. SPECIFICATIONS

Feature	Detail
Brand	Outsunny
Model Number	84H-206V00CG
Overall Dimensions (W x D x H)	91.7" x 41.3" x 46.7" / 52.4" (233 x 105 x 118.5/133 cm)
Bottom Size (W x D)	90.6" x 39.8" (230 x 101 cm)
Area	25 sq.ft. (2.3 m ²)
Material	Galvanized Steel (Alloy Steel Frame)
Color	Dark Grey
Item Weight	103 lbs (46.72 kg)
Water Resistance Level	Waterproof



Image: A diagram illustrating the key dimensions of the Outsunny storage shed, including width, depth, and height with the lid open and closed.

8. WARRANTY & SUPPORT

For any questions, concerns, or assistance with your Outsunny storage shed, please contact Aosom

Canada customer support. Refer to your purchase documentation for specific warranty details and return policies.

- **Customer Support:** Contact Aosom Canada for assistance.
- **Return Policy:** Eligible for return or refund within 30 days of receipt.

© 2026 Outsunny. All rights reserved.