

RAR-2P1, RAR-2P2, RAK-18NH5, RAK-25NH5, RAS-24GH4, RAS-18GH4, RAK-35NH5, RAK-50NH5, RAF-35FX8, RAS-63CHA2, RAF-25FX8, RA

Instruction Manual for Generic Replacement Remote Control

Compatible with Hitachi Air Conditioner Models: RAR-2P1, RAR-2P2, RAK-18NH5, RAK-25NH5, RAS-24GH4, RAS-18GH4, RAK-35NH5, RAK-50NH5, RAF-35FX8, RAS-63CHA2, RAF-25FX8, RAS-72CHA3, RAI-25NH5, RAI-35NH5, RAI-50NH5

INTRODUCTION

This document provides instructions for the Generic Infrared Replacement Remote Control, designed for use with various Hitachi Air Conditioner models. Please verify that your original remote control matches the images provided in this manual to ensure compatibility and proper function. This remote operates using infrared signals and requires no complex programming.



Image 1: Front view of the replacement remote control. This image displays the primary buttons and the LCD screen.

SETUP

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote. No programming or setup is required; once batteries are installed, the remote is ready for use.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.




Image 2: Back view of the remote control with the battery cover open, illustrating the correct placement for AAA batteries.

OPERATING INSTRUCTIONS

To operate the air conditioner, point the remote control directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the unit.



Image 3: Front view of the remote control with the sliding panel open, showing all available buttons for various functions.

Button Functions

- **Power Button (①):** Turns the air conditioner ON or OFF.
- **Mode Button (fan/snowflake/waterdrop icons):** Cycles through available operating modes such as Cool, Heat, Fan, Dry, and Auto.
- **Fan Speed Button (fan icon):** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Temperature Adjustment Buttons (°C button and implied up/down arrows):** Increases or decreases the desired temperature setting.
- **Swing Button (arrow icons):** Controls the vertical or horizontal movement of the air conditioner's louvers.

- **Timer Button (clock icon):** Used to set the automatic ON/OFF timer for the air conditioner.
- **Reset Button (RESET):** Resets the remote control to its default settings.
- **Favorite/Star Button (star icon):** Saves or recalls your preferred operating settings.
- **Sleep Mode Button (moon icon):** Activates a quiet, energy-saving sleep mode.

MAINTENANCE

Proper maintenance ensures the longevity and reliable performance of your remote control.

Battery Replacement

- Replace batteries when the remote's display dims, buttons become unresponsive, or the air conditioner fails to respond to commands.
- Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.

Cleaning

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the remote's surface or internal components.

TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
 - Ensure fresh AAA batteries are installed with correct polarity.
 - Check for any obstructions between the remote control and the air conditioner's infrared receiver.
 - Confirm you are within the effective operating range (typically within 8 meters and directly in front of the unit).
- **Limited functionality:**
 - This is a replacement remote control. While it supports core functions, some advanced or unique features present on your original air conditioner remote may not be fully supported.
 - Refer to your original air conditioner's manual for specific feature compatibility.
- **Display is dim or blank:**
 - This indicates low battery power. Replace both AAA batteries immediately.

SPECIFICATIONS

Product Type	Infrared (IR) Replacement Remote Control
Compatible Brands	Hitachi Air Conditioners
Compatible Models	RAR-2P1, RAR-2P2, RAK-18NH5, RAK-25NH5, RAS-24GH4, RAS-18GH4, RAK-35NH5, RAK-50NH5, RAF-35FX8, RAS-63CHA2, RAF-25FX8, RAS-72CHA3, RAI-25NH5, RAI-35NH5, RAI-50NH5

Power Source	2 x AAA Batteries (not included)
Color	Light Grey / White (as pictured)
Manufacturer	Easytry

WARRANTY INFORMATION

No specific warranty information is provided with this replacement remote control. Please refer to the seller's return policy or contact the seller directly for details regarding returns or defects.

SUPPORT INFORMATION

For technical assistance or inquiries regarding this product, please contact the seller directly through the platform where the purchase was made. Ensure to provide your order details for efficient support.