

MSZ-SF Series Replacement Remote

Remote Control Instruction Manual

For Mitsubishi MSZ-SF Series AC Air Conditioners

1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your replacement remote control for Mitsubishi MSZ-SF series air conditioners. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.



Image: Front view of the remote control, showing the display screen and basic temperature/power buttons.

2. SAFETY INFORMATION

- Do not expose the remote control to direct sunlight, high temperatures, or high humidity.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep batteries out of reach of children.

3. PACKAGE CONTENTS

- 1 x Replacement Remote Control (as shown in product images)

Note: Batteries are not included. Two AAA batteries are required for operation.

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover slid open, showing the battery compartment.

This remote control is an infrared replacement and typically requires no programming or setup. It should function directly with compatible Mitsubishi MSZ-SF series AC units once batteries are installed.

5. OPERATING INSTRUCTIONS

5.1 Button Functions Overview



Image: Top-down view of the remote control, clearly showing the layout of all buttons and the display screen.

| Button | Function |
|------------|--|
| OFF/ON | Powers the AC unit on or off. |
| TEMP + / - | Adjusts the temperature setting up or down. |
| MODE | Cycles through operating modes (e.g., Cool, Heat, Dry, Fan, Auto). |

| Button | Function |
|---------------------|---|
| FAN | Adjusts fan speed. |
| WIDE VANE | Controls the horizontal airflow direction. |
| L-VANE-R | Controls the left-right vertical airflow direction. |
| ECONO COOL | Activates energy-saving cooling mode. |
| POWERFUL | Activates rapid cooling/heating for a short period. |
| SMART SET | Recalls preferred settings. |
| NATURAL FLOW | Simulates natural breeze airflow. |
| INDIRECT/DIRECT | Adjusts airflow direction to avoid direct draft. |
| SLEEP | Activates sleep mode for comfortable night operation. |
| WEEKLY TIMER ON/OFF | Activates or deactivates the weekly timer program. |
| ON / OFF (Timer) | Sets the ON/OFF timer for automatic operation. |
| EDIT/SEND | Used for editing and sending timer settings. |
| SET | Confirms selected settings. |
| CANCEL | Cancels current timer settings. |
| DAY | Selects the day for weekly timer settings. |
| TIME | Adjusts the time for timer settings. |
| 1~4 | Selects program numbers for weekly timer. |
| DELETE | Deletes timer settings. |
| °C/°F CLOCK RESET | Switches temperature unit between Celsius and Fahrenheit; resets clock. |

5.2 Basic Operation

- **Power On/Off:** Press the **OFF/ON** button to turn the AC unit on or off.
- **Temperature Adjustment:** Use the **TEMP +** or **TEMP -** buttons to set your desired temperature.
- **Mode Selection:** Press the **MODE** button repeatedly to cycle through available operating modes (e.g., Cool, Heat, Dry, Fan, Auto).
- **Fan Speed:** Press the **FAN** button to adjust the fan speed.

5.3 Advanced Functions

- **Airflow Direction:** Use **WIDE VANE** and **L-VANE-R** buttons to adjust the horizontal and vertical airflow.
- **Timer Settings:** To set the ON/OFF timer, press the respective **ON** or **OFF** timer buttons. Use the arrow buttons to adjust time and then **SET** to confirm. For weekly timer, refer to your AC unit's main manual for detailed programming steps, as this remote provides the interface for such functions.
- **Special Modes:** Activate **ECONO COOL** for energy efficiency, **POWERFUL** for quick temperature changes, or **SLEEP** for optimized night operation.

6. MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight when not in use for extended periods.
- **Battery Replacement:** Replace batteries when the display becomes dim or the remote control becomes unresponsive. Always replace both batteries simultaneously.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|-------------------------|--|---|
| Remote not responding | Dead or incorrectly inserted batteries. Obstruction between remote and AC unit. | Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure remote is pointed directly at the AC unit's receiver. |
| Limited functionality | This is a replacement remote; some advanced functions may not be fully supported by all AC models. | Verify compatibility with your specific AC model. Refer to your AC unit's original manual for full feature details. |
| Display is dim or blank | Low battery power. | Replace both AAA batteries. |

8. SPECIFICATIONS

- **Model Compatibility:** Mitsubishi MSZ-SF25VE, MSZ-SF35VE, MSZ-SF42VE, MSZ-SF50VE, MSZ-SF25VE-E1, MSZ-SF35VE-E1, MSZ-SF42VE-E1, MSZ-SF50VE-E1, MSZ-SF25VE-E2, MSZ-SF35VE-E2, MSZ-SF42VE-E2 AC Air Conditioners.
- **Power Source:** 2 x AAA Batteries (not included)
- **Transmission Type:** Infrared (IR)
- **Color:** Black/White (as pictured)
- **Manufacturer:** Easytry

9. WARRANTY AND SUPPORT

This product is a replacement remote control. For specific warranty information, please refer to the seller's policy at the time of purchase. If you encounter any issues or have questions regarding the compatibility or functionality of this remote control, please contact the seller directly for assistance.

Please ensure your current remote matches the appearance of this replacement remote for guaranteed compatibility. If your AC model is not explicitly listed in the product title, please contact the seller before purchase to confirm compatibility.

