



Manuals.plus /

› TrustCell /

› TrustCell Replacement Battery User Manual for Magnavox Camcorders

TrustCell CS-CBP308MD

TrustCell Replacement Battery User Manual

Model: CS-CBP308MD

1. INTRODUCTION

Thank you for choosing the TrustCell Replacement Battery. This manual provides essential information for the safe and effective use of your new battery. Please read this manual thoroughly before using the product and retain it for future reference. This battery is designed as a high-quality replacement for various Magnavox camcorder models, including CVL-810, CVM-310, CVM-315, CVM710, CVM-720, CVN-310AV, CVR-325AV, CVR-330AV, CVR-335AV, V80096BK01, and VHS-130.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Product Specifications:** Ni-MH, Voltage: 12.0V, Rate: 1800mAh/21.60Wh.
- **Dimensions:** 143.00x62.00x21.00mm, Gross Weight: 540.0g.
- Manufactured to exact specifications as the original battery, ensuring compatibility and performance.
- Equipped with strict spec detection and use testing for safe and durable operation.
- Includes over charge, over discharge, over voltage, and short circuit protection for enhanced battery life.
- Certifications: ISO9001, RoHS, CE, UN38.3, and MSDS.

2.2 Product Specifications

| Specification | Value |
|--------------------|---------------------------|
| Battery Type | Ni-MH |
| Capacity | 1800mAh |
| Voltage | 12V |
| Rate | 21.6Wh |
| Product Dimensions | 2.44 x 0.83 x 5.63 inches |
| Item Weight | 1.19 pounds |
| Model Number | CS-CBP308MD |
| Manufacturer | TrustCell |

2.3 What's in the Box

- 1 x TrustCell Replacement Battery (Model: CS-CBP308MD)

2.4 Product Images



Image 1: Top-down view of the TrustCell Replacement Battery, showing its compact design.



Image 2: Close-up view of the battery's label, displaying model number, part number, rating, and caution information.

3. SETUP

Before first use, please follow these steps:

1. **Initial Charging:** A new battery will achieve its best performance after 2 or 3 complete cycles of charge and discharge. Fully charge the battery before its first use.
2. **Installation:** When installing the battery into your device, ensure the connector has been properly and securely connected. Refer to your device's instruction manual for specific battery installation procedures.
3. **Charger Compatibility:** Use only the original or a high-quality, compatible charger designed for your device. Avoid using low-quality third-party adapter chargers, as this can shorten the battery's life.

4. OPERATING

Once installed and charged, the battery operates seamlessly with compatible Magnavox camcorders. The battery provides reliable power for recording and playback functions. Monitor your device's battery indicator to determine remaining power and when recharging is necessary.

5. MAINTENANCE

Proper maintenance can extend the life of your battery:

- **Regular Charging:** Avoid completely draining the battery before recharging. Frequent partial charges are generally better for Ni-MH batteries than deep discharges.
- **Storage:** If storing the battery for an extended period, charge it to about 50% capacity and store it in a cool, dry place. Recharge it every few months to prevent deep discharge.
- **Cleaning:** Keep the battery contacts clean using a dry cloth or cotton swab. Dirty contacts can interfere with charging and power delivery.
- **Temperature:** Avoid exposing the battery to extreme temperatures, both hot and cold, as this can degrade performance and lifespan.

6. TROUBLESHOOTING

If you encounter issues with your battery, consider the following:

- **Battery Not Charging:** Ensure the charger is properly connected and functioning. Check battery contacts for cleanliness. Verify the charger is compatible with Ni-MH batteries.
- **Short Battery Life:** Ensure the battery has completed 2-3 full charge/discharge cycles. Avoid using low-quality third-party chargers. Check for excessive power consumption by the device.
- **Device Not Powering On:** Confirm the battery is correctly installed and fully charged. Check if the device itself has any issues.

If problems persist, please refer to the Warranty and Support section for contact information.

7. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following cautions:

- **Do not disassemble** the battery pack. There are no user-serviceable parts inside.
- **Do not dispose of in fire or water.** This can cause explosion or leakage.
- **Do not store above 60 °C (140 °F).** High temperatures can damage the battery and pose a safety risk.

- **Do not attempt to open or service the battery pack.** Warranty will be void if the label is removed.
- **Replace only with the battery pack designated for this product.** Using incompatible batteries can be dangerous.
- **Do not crush, puncture, short external contacts, or dispose of in fire or water.** These actions can lead to severe damage, fire, or explosion.

8. WARRANTY AND SUPPORT

TrustCell provides comprehensive support for your product:

- **Warranty:** We offer a refund or replacement for 1 year from the date of purchase.
- **Customer Service:** Our dedicated after-sales service team is available 24/7 to assist you.
- **Contact Us:** If you have any problems or questions regarding your TrustCell Replacement Battery, please feel free to contact us via email. We commit to replying to your inquiries within 24 hours.