Arecovas KBS-52K131

Arecovas 52-Inch Modern Ceiling Fan with Light and Remote

User Instruction Manual

1. Introduction

Thank you for choosing the Arecovas 52-Inch Modern Ceiling Fan. This manual provides detailed instructions for installation, operation, and maintenance to ensure safe and efficient use of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.



Image: The Arecovas 52-inch ceiling fan, showcasing its sleek design, five blades, integrated LED light, and the included remote control. Two blade finishes (black and lighter wood) are also visible.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or personal injury, always turn off power at the main circuit breaker or fuse box before beginning installation.

- All wiring must be in accordance with national and local electrical codes.
- The fan must be mounted to a ceiling joist or support capable of withstanding a fan weight of at least 35 lbs (15.9 kg).
- Ensure the fan blades are at least 7 feet (2.1 meters) from the floor.
- Do not operate the fan with damaged power cords or plugs.
- Do not insert objects into the fan blades while the fan is operating.

3. Package Contents

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Housing
- 5 Reversible Fan Blades (Black and Lighter Wood Finish)
- Integrated LED Light Kit with Acrylic Cover
- Remote Controller with Wall Cradle
- Mounting Hardware (Canopy, Mounting Bracket, Screws, Wire Nuts)
- Downrods (5-inch and 10-inch options)
- Instruction Manual



Image: A visual representation of the fan's components, including the double-sided blades, two downrod lengths (5-inch and 10-inch), and the remote control, along with fan dimensions for both downrod and flush mount configurations.

4. Product Overview

The Arecovas ceiling fan is designed for optimal air circulation and lighting in various indoor spaces. It features a quiet DC motor, reversible blades for year-round comfort, and a dimmable LED light with adjustable color temperatures.

- **Sleek Design:** Modern aesthetic with a metal housing and wooden blades.
- **Dual-Finish Blades:** Black wood on one side, lighter wood on the other for versatile decor matching.
- **Quiet DC Motor:** Operates below 30 decibels, ensuring a tranquil environment.
- **Integrated LED Light:** Dimmable from 10% to 100% with 3 color temperature options (3000K, 5000K, 6000K).
- **Remote Control:** Full control over fan speeds, light settings, and timer functions.




Image: A detailed view of the fan's DC motor, highlighting its efficient and quiet operation, with text indicating 78% higher energy efficiency and noise levels below 30 dB.



Image: A close-up of the fan's double-sided blades, illustrating the two distinct wood finishes (lighter wood and black wood) available for aesthetic versatility.

5. Installation

The Arecovas ceiling fan supports both downrod and flush mount installations. Choose the method suitable for your ceiling height.

5.1 Pre-Installation Checklist

- Ensure power is OFF at the circuit breaker.
- Confirm you have all package contents.
- Gather necessary tools (screwdriver, wire strippers, ladder, etc.).

5.2 Mounting Options

Downrod Mount: Ideal for higher ceilings to optimize airflow distribution.
Flush Mount: Suitable for rooms with lower ceilings or smaller spaces, saving vertical room.



Image: Two illustrations demonstrating the two available mounting options: a downrod mount for higher ceilings and a flush mount for lower ceilings, highlighting the fan's adaptability.

5.3 General Installation Steps (Refer to detailed diagrams in the included paper manual)

1. Secure the mounting bracket to the ceiling electrical box.
2. Assemble the fan motor housing with the chosen downrod or prepare for flush mount.

3. Hang the fan assembly onto the mounting bracket.
4. Connect electrical wires (Live, Neutral, Ground) according to local codes.
5. Attach the fan blades to the motor housing.
6. Install the LED light kit and acrylic cover.
7. Restore power and test the fan and light functions.



Image: A person on a ladder installing the ceiling fan, emphasizing the ease of installation and potential time/cost savings.

6. Operation

Your Arecovas ceiling fan is controlled by the included remote. Ensure batteries are installed correctly.

6.1 Remote Control Functions

- **ALL OFF:** Turns off both fan and light.
- **LIGHT ON/OFF:** Toggles the light on or off.
- **F/R (Forward/Reverse):** Changes fan direction for summer (downdraft) or winter (updraft) mode.
- **Fan Speed Buttons (1-6):** Adjusts fan speed from low (1) to high (6).
- **Timer Buttons (1H/4H/8H):** Sets the fan to turn off automatically after 1, 4, or 8 hours.



Image: A visual representation of the ceiling fan and its remote control, with icons illustrating various functions such as fan speed, light control, timer, and reversible mode, emphasizing convenient control.




Image: This image illustrates two convenient ways to use the remote control: either mounted in its wall cradle to function as a wall switch or used as a handheld remote for portability.

6.2 Fan Speed Settings

The fan offers 6 adjustable speeds:

- **Level 1-2:** Low Comfortable Wind
- **Level 3-4:** Medium Natural Wind
- **Level 5-6:** High Cooling Wind




Image: A graphic illustrating the fan's 6 adjustable speed settings, categorized into Low Comfortable Wind (Levels 1-2), Medium Natural Wind (Levels 3-4), and High Cooling Wind (Levels 5-6).

6.3 Light Settings

The integrated LED light offers 3 color temperatures and is fully dimmable:

- **3000K:** Warm Yellow Light

- **5000K:** Natural Light
- **6000K:** Cold White Light

Press and hold the light button on the remote to adjust brightness (10%-100%).




Image: Three distinct images demonstrating the fan's LED light at different color temperatures: 3000K (Warm Yellow Light), 5000K (Natural Light), and 6000K (Cold White Light), illustrating its versatility for various scenarios.




Image: A close-up view of the fan's replaceable LED light kit, showing the LED light board and shade, indicating ease of replacement.

6.4 Reversible Function (Summer/Winter Mode)

The fan's reversible DC motor allows for year-round comfort:

- **Summer Mode (Downdraft):** Blades rotate counter-clockwise, creating a cooling breeze.
- **Winter Mode (Updraft):** Blades rotate clockwise, circulating warm air trapped near the ceiling.

Press the F/R button on the remote to switch between modes.



Image: A diagram illustrating the fan's reversible wind direction, showing downdraft for summer to disperse heat and updraft for winter to enhance air circulation.

7. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing regularly with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Tightness:** Periodically check that all blade screws are tight.
- **Light Kit:** The LED light kit is replaceable. Refer to the detailed instructions in the full manual for replacement.
- **No Lubrication:** The fan's motor is permanently lubricated and does not require oiling.

8. Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low/dead.	Check circuit breaker/fuse; Verify all wire connections are secure; Replace remote control batteries.
Light does not work	Loose wire connection to light kit; Faulty LED light kit; Remote control issue.	Check light kit wiring; Contact support for replacement LED kit; Test remote functions.
Fan wobbles	Loose blade screws; Unbalanced blades; Improper mounting.	Tighten all blade screws; Use balancing kit (not included) if needed; Re-check mounting bracket security.
Remote control not working	Batteries dead/incorrectly installed; Remote not paired with fan.	Replace batteries, ensure correct polarity; Refer to pairing instructions in the full manual.
Excessive noise	Loose screws; Motor issue.	Check and tighten all screws; If noise persists, contact customer support.

9. Specifications

Feature	Detail
Brand	Arecovas
Model Name	KBS-52K131
Product Dimensions	52"D x 52"W x 18.5"H
Color	Black and Lighter Wood Blades
Electric Fan Design	Ceiling Fan
Power Source	Quiet Copper DC Motor
Number of Blades	5
Air Flow Capacity	5060 Cubic Feet Per Minute
Noise Level	30 dB
Wattage	54 Microwatts
Voltage	120 Volts
Light Type	LED (3-color Dimmable)
Control Method	Remote

Feature	Detail
Mounting Options	Downrod & Flush Mount
Recommended Room Size	15x15 to 20x20 feet
Item Weight	12.27 pounds

10. Warranty & Support

Your Arecovas ceiling fan comes with a **1-Year Warranty** on the product and a **10-Year Warranty** on the DC motor.
For technical assistance, warranty claims, or replacement parts (e.g., LED light board, remote control), please contact Arecovas customer support. Our professional R&D team and strict quality control ensure reliable products and support.
Contact information can typically be found on the product packaging or the official Arecovas website.




Image: A graphic detailing the warranty information: 1-Year for the fan, 10-Year for the motor, and instructions to contact customer support for damaged or missing LED light boards or remote controls.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question