

Manuals.plus /

› TrustCell /

› TrustCell DR17AA Replacement Battery User Manual for SebaKMT 899003810 Digiflex COM

TrustCell CS-KLIC011

TrustCell DR17AA Replacement Battery User Manual

MODEL: CS-KLIC011 FOR SEBAKMT 899003810, DIGIFLEX COM

1. Introduction

Thank you for choosing the TrustCell DR17AA Replacement Battery. This manual provides essential information for the safe and effective use of your new battery. Please read these instructions carefully before installation and operation to ensure optimal performance and longevity.

2. Product Overview

The TrustCell DR17AA is a high-quality Ni-MH replacement battery designed for compatibility with specific devices, including SebaKMT 899003810 and Digiflex COM models. It offers reliable power with built-in safety features.

2.1. What's in the Box

- 1 x TrustCell DR17AA Replacement Battery (Model: CS-KLIC011)

2.2. Product Images





Image 2: Side view of the battery, highlighting the caution label with important safety warnings and manufacturer information.



Image 3: Angled view of the battery, displaying both the caution label and the electrical connectors at one end.



Image 4: Close-up view of the battery's label, clearly showing the 'Cameron Sino' brand, model number CS-KLIC011, part number, rating (7.2VDC, 2150mAh, 15.48Wh), and battery type (Nickel Metal Hydride).

3. Specifications

Feature	Specification
Battery Type	Ni-MH (Nickel Metal Hydride)
Capacity	2150mAh
Voltage	7.2V
Energy Rate	15.48Wh
Model Number	CS-KLIC011
Compatible Part No.	DR17AA, SebaKMT 899003810
Dimensions	143.71 x 35.31 x 17.57 mm (5.66 x 1.39 x 0.69 inches)
Weight	Approximately 335.0g (11.8 ounces)
Certifications	ISO9001, RoHS, CE, UN38.3, MSDS

4. Safety Information

Your safety is paramount. Please adhere to the following guidelines to prevent injury or damage to the battery and your device:

- **Do not disassemble:** Attempting to open or modify the battery can lead to hazards.
- **Do not dispose of in fire or water:** This can cause explosion or leakage.
- **Do not store above 60 °C (140 °F):** High temperatures can degrade battery performance and pose safety risks.
- **Avoid physical damage:** Do not crush, puncture, or short circuit external contacts.
- **Use designated chargers:** Only use chargers compatible with Ni-MH batteries and your device. Avoid low-quality third-party adapters, as they can shorten battery life.
- The battery is equipped with overcharge, over-discharge, over-voltage, and short-circuit protection for enhanced safety.

5. Setup

Follow these steps for initial setup:

1. **Compatibility Check:** Before installation, carefully verify that the model number of your device and the part number of your original battery match the specifications of this replacement battery (DR17AA, SebaKMT 899003810, Digiflex COM).
2. **Initial Charge:** A new battery will achieve its best performance after 2 or 3 complete charge and discharge cycles. Fully charge the battery before its first use.
3. **Installation:** When installing the battery, ensure the connector is properly and securely connected to your device. Refer to your device's original manual for specific installation instructions if needed.

6. Operating

Once installed and initially charged, the battery operates like your original device battery. Monitor your device's battery indicator for charge levels. For optimal performance, avoid completely draining the battery frequently.

7. Maintenance

Proper maintenance extends the life of your battery:

- **Storage:** If storing the battery for an extended period, keep it in a cool, dry place, away from direct sunlight and extreme temperatures. Store it with approximately 50% charge.
- **Cleaning:** Keep battery contacts clean and free of dust or debris. Use a dry, soft cloth to wipe them if necessary.
- **Regular Use:** For best results, use and recharge the battery regularly.

8. Troubleshooting

If you encounter issues with your battery, consider the following:

- **Battery Not Charging:** Ensure the battery is correctly installed and the charger is functioning properly and compatible with Ni-MH batteries. Check for any loose connections.
- **Short Battery Life:** Ensure the battery has completed 2-3 full charge/discharge cycles. Verify that you are using a suitable charger. Excessive use of power-intensive device features can also reduce operating time.
- **Device Not Powering On:** Confirm the battery is fully charged and correctly inserted. If the issue persists, the problem may lie with the device itself.

If troubleshooting steps do not resolve the issue, please contact customer support.

9. Warranty and Support

TrustCell stands behind the quality of its products:

- **Warranty:** We offer a 1-year refund or replacement policy from the date of purchase.
- **Customer Service:** Our dedicated customer service team is available 24/7 to assist you. If you have any questions, concerns, or require support, please do not hesitate to contact us via email. We aim to respond within 24 hours.

For contact information, please refer to your purchase documentation or the seller's platform.