

XKT32

# Monster XKT26 TWS Earphones User Manual

Model: XKT32

## INTRODUCTION

---

Thank you for choosing the Monster XKT26 TWS Earphones. This manual provides detailed instructions on how to set up, operate, and maintain your earphones to ensure optimal performance and longevity. These earphones are designed to deliver a superior audio experience with features such as intelligent noise reduction, HD call quality, strong battery endurance, and high-fidelity sound.

Please read this manual carefully before using the product and keep it for future reference.

## PACKAGE CONTENTS

---

Ensure all items listed below are present in your package:

- 1 x Pair of Earphones
- 1 x User Manual
- 1 x Charging Cable
- 1 x Charging Box

## SETUP

---

### Initial Charging

Before first use, fully charge the charging box and earphones. Connect the charging cable to the charging box and a suitable USB power source. The charging box typically takes approximately 1.5 hours to fully charge.



Image: The Monster XKT26 TWS Earphones, with one earbud placed outside the open charging case, illustrating the components for initial setup.

## Pairing with Your Device

1. Ensure the earphones are charged and inside the charging case.
2. Open the charging case. The earphones will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn on Bluetooth.
4. Search for available devices. You should see "Monster XKT26" or a similar name appear in the list.

5. Select "Monster XKT26" to connect. Once connected, a voice prompt will confirm successful pairing.
6. For subsequent uses, the earphones will automatically connect to the last paired device when removed from the charging case.

## OPERATING INSTRUCTIONS

---

### Basic Controls

The Monster XKT26 TWS Earphones feature touch controls for easy operation:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.

### Intelligent Noise Reduction

The earphones are equipped with advanced noise-cancelling technology. This feature helps to filter out ambient sounds, providing a clearer and more immersive audio experience. The noise reduction is active by default during audio playback and calls.



Image: The Monster XKT26 TWS Earphones in their charging case, with abstract sound waves in the background, symbolizing the high-fidelity sound and noise reduction capabilities.

## HD Call Quality

Enjoy seamless and clear conversations with the HD call quality feature. The built-in microphones are designed to pick up your voice clearly while minimizing background noise, ensuring effective communication.

## Gaming and Entertainment

With low latency and high-fidelity sound, these earphones are suitable for gaming and multimedia

consumption, providing an immersive audio experience.



Image: The Monster XKT26 TWS Earphones and their charging case positioned next to a smartphone displaying a video game, highlighting their use for gaming.

## MAINTENANCE

- **Cleaning:** Regularly clean the earphones and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.

- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage.
- **Battery Care:** To prolong battery life, avoid fully discharging the earphones frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** These earphones are not waterproof. Avoid exposure to water, sweat, or high humidity.

## TROUBLESHOOTING

| Problem                    | Possible Solution                                                                                                                                                                                                                                                                                           |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Earphones not pairing      | <ul style="list-style-type: none"><li>◦ Ensure earphones are charged.</li><li>◦ Turn off and on Bluetooth on your device.</li><li>◦ Forget "Monster XKT26" from your device's Bluetooth list and re-pair.</li><li>◦ Place earphones back in the case, close, wait a few seconds, then open again.</li></ul> |
| No sound from one earbud   | <ul style="list-style-type: none"><li>◦ Ensure both earbuds are charged.</li><li>◦ Try resetting the earphones (refer to manufacturer's specific reset instructions if available, otherwise re-pair).</li></ul>                                                                                             |
| Charging case not charging | <ul style="list-style-type: none"><li>◦ Check the charging cable and power adapter.</li><li>◦ Ensure the charging port is clean and free of debris.</li></ul>                                                                                                                                               |
| Poor sound quality         | <ul style="list-style-type: none"><li>◦ Ensure earphones are clean, especially the ear tips.</li><li>◦ Check the audio source quality.</li><li>◦ Move closer to your connected device to avoid interference.</li></ul>                                                                                      |

## SPECIFICATIONS

| Feature           | Detail                               |
|-------------------|--------------------------------------|
| Product Type      | True Wireless Stereo (TWS) Earphones |
| Model Number      | XKT32                                |
| Bluetooth Version | V5.4                                 |
| Driver Diameter   | 10mm                                 |
| Sensitivity       | 96 ±3.0dB                            |
| Impedance         | 32Ω; ±15%                            |



| Feature                      | Detail            |
|------------------------------|-------------------|
| Frequency Response Range     | 20Hz-20kHz        |
| Transmission Distance        | 10 meters         |
| Charging Time (Charging Box) | Approx. 1.5 hours |
| Playback Time (Earphone)     | Approx. 6 hours   |
| Color                        | Black             |
| Ear Placement                | In Ear            |
| Form Factor                  | In Ear            |
| Package Dimensions           | 16 x 10.5 x 4 cm  |
| Package Weight               | 185 g             |
| Country of Origin            | China             |

## WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your package or contact the seller/manufacturer directly.

For technical support, troubleshooting assistance, or any inquiries regarding your Monster XKT26 TWS Earphones, please contact the customer service of the retailer or the manufacturer, Generic. You may also visit the official website of the brand for updated information and support resources.