

[Manuals.plus](#) /

› [Reebok](#) /

› Reebok Active Pack Smartwatch and Headphones User Manual

## Reebok RBK-BDST-B

# Reebok Active Pack Smartwatch and Headphones User Manual

Model: RBK-BDST-B

## 1. PRODUCT OVERVIEW

The Reebok Active Pack is a comprehensive solution for your active lifestyle, combining a feature-rich smartwatch with high-quality true wireless headphones. This pack is designed to provide seamless connectivity and performance for both fitness tracking and audio enjoyment.



**Figure 1.1:** The Reebok Active Pack, featuring the blue smartwatch and its accompanying true wireless headphones in their charging case.

## 2. SETUP GUIDE

### 2.1 Charging the Devices

Before initial use, ensure both your smartwatch and headphones are fully charged.

- **Smartwatch:** Connect the provided charging cable to the charging points on the back of the smartwatch and to a USB power source. A full charge takes approximately 1 hour.
- **Headphones:** Place the headphones into their charging case. Connect the charging case to a USB power source using the provided cable. The case will indicate charging status.

### 2.2 Powering On/Off

- **Smartwatch:** Press and hold the side button to power on. To power off, navigate to the settings menu and select 'Power Off'.
- **Headphones:** The headphones automatically power on when removed from the charging case and power off when placed back into the case.

## 2.3 Pairing with Your Device

The Reebok Active Pack is compatible with both iOS and Android smartphones and tablets.

### 1. **Smartwatch:**

- Download the official Reebok Active Pack application from your device's app store.
- Enable Bluetooth on your smartphone/tablet.
- Open the application and follow the on-screen instructions to pair your smartwatch.

### 2. **Headphones:**

- Remove both headphones from the charging case. They will automatically enter pairing mode.
- Go to the Bluetooth settings on your smartphone/tablet and select 'Reebok Headphones' from the list of available devices.



Figure 2.1: Front view of the Reebok Smartwatch, displaying the time and activity metrics.

### 3. OPERATING INSTRUCTIONS

#### 3.1 Smartwatch Operation

The smartwatch features a responsive 1.83-inch OLED touchscreen for intuitive navigation.

- **Navigation:** Swipe left, right, up, or down to access different functions and menus. Tap to select an option.

- **Side Button:** Press the side button to return to the home screen or to access the app list.
- **Features:** Monitor your heart rate, track steps, view notifications, control music, and check weather updates directly from your wrist.



Figure 3.1: Rear view of the Reebok Smartwatch, showing the charging contacts and sensor area.

### 3.2 Headphones Operation

The true wireless headphones provide high-quality sound for an immersive audio experience.

- **Playback Control:** Use the touch-sensitive areas on the headphones to play/pause music, skip tracks, and answer/end calls. Refer to the detailed instructions in the full manual for specific gestures.
- **Call Management:** Tap to answer incoming calls, tap again to end calls.
- **Battery Life:** Enjoy up to 6 hours of continuous playback on a single charge. The charging case provides multiple additional charges.



**Figure 3.2:** The Reebok headphones in their open charging case, showing the digital battery indicator.

#### 4. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your Reebok Active Pack.

- **Cleaning:** Use a soft, dry cloth to wipe down both the smartwatch and headphones. Avoid using abrasive cleaners or solvents.
- **Water Resistance:** While the devices are designed for active use, avoid prolonged exposure to water or submersion unless specified otherwise in the product's full specifications.
- **Storage:** Store the devices in a cool, dry place when not in use. Keep the headphones in their charging case to protect them and keep them charged.
- **Battery Care:** To preserve battery health, avoid fully discharging the devices frequently. Charge them regularly, even if not in daily use.



**Figure 4.1:** Top view of the Reebok headphones charging case, displaying the Reebok logo and battery percentage.

## 5. TROUBLESHOOTING

If you encounter issues with your Reebok Active Pack, refer to the following common solutions:

- **Device Not Powering On:** Ensure the device is fully charged. Try connecting it to a different power source or cable.
- **Pairing Issues:**
  - Ensure Bluetooth is enabled on your smartphone/tablet.
  - Make sure the devices are within Bluetooth range (typically 10 meters).
  - Forget the device from your smartphone's Bluetooth settings and attempt to pair again.
  - Restart both your smartphone/tablet and the Reebok devices.
- **No Sound from Headphones:**
  - Check the volume level on your connected device.
  - Ensure the headphones are properly paired.
  - Clean any debris from the headphone's speaker mesh.
- **Smartwatch Screen Unresponsive:** Try restarting the smartwatch by holding down the side button (if applicable) or by performing a force restart as per the full manual.

For more detailed troubleshooting, please consult the full product manual or visit the Reebok support website.

## 6. SPECIFICATIONS

Key technical specifications for the Reebok Active Pack:

Feature	Specification
Brand	Reebok
Model Number	RBK-BDST-B
Memory Storage Capacity	128 MB
Operating System	Android Wear
Compatible Devices	Smartphone, Tablet
Special Features	Touchscreen
Screen Size	1.83 Inches
Display Type	OLED
Headphone Form Factor	True Wireless
Average Battery Life (Smartwatch)	6 Hours
Charging Time	1 Hour
Battery Capacity	150 Milliamp Hours
Wireless Connection Type	Bluetooth
Human Interface Input	Touchscreen
Material Type	Plastic
Product Dimensions	1.5 x 2 x 24 cm; 70 g
GPS	GPS via smartphone

## 7. WARRANTY AND SUPPORT

### 7.1 Return Policy

This product is eligible for a 30-day free return policy from the date of purchase. Please refer to your retailer's return policy for specific terms and conditions.

### 7.2 Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Reebok support website or contact their customer service. You can find more information at the [Reebok Brand Store on Amazon](#).

© 2024 Reebok. All rights reserved.