

[Manuals.plus](#) /

› [Raysfung](#) /

› Raysfung Hardtop Gazebo 12' x 14' Instruction Manual

Raysfung 12' x 14' Hardtop Gazebo

Raysfung Hardtop Gazebo 12' x 14' Instruction Manual

Model: 12x14 Hardtop Gazebo

INTRODUCTION

Thank you for choosing the Raysfung Hardtop Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your new 12' x 14' outdoor pavilion. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



Image: The Raysfung 12' x 14' Hardtop Gazebo, featuring a polycarbonate double roof and gray curtains, positioned next to a swimming pool with outdoor dining furniture underneath.

SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- **Assembly:** Always follow the assembly instructions carefully. Use appropriate tools and involve the recommended number of people (2-4 people recommended) to avoid injury.
- **Stability:** Secure the gazebo to a stable foundation to prevent tipping. If installing on wood floors, buyers need to purchase wood panel-specific expansion screws.
- **Curtains and Netting:** Keep curtains and netting away from heat sources and ensure they are properly secured to prevent accidental removal, especially in windy conditions.
- **Supervision:** Always supervise children when they are near the gazebo.
- **Weather Conditions:** While the gazebo is weather-resistant, extreme weather conditions (e.g., severe storms,

heavy snow loads beyond 1100lbs, winds exceeding 50mph) may require additional precautions or temporary disassembly.

PRODUCT FEATURES

Sturdy Steel Frame

The gazebo is constructed with a robust steel frame, finished with a powder coating to resist rust and corrosion, ensuring maximum durability. The pre-drilled base allows for enhanced stability and safety when secured to a foundation.



Image: Detail view highlighting the sturdy steel frame construction, including a triangular design for added support and a pre-drilled base for secure anchoring.

Polycarbonate Double Roof

The roof features polycarbonate panels designed to protect against rain, snow, and harmful UV rays, allowing for year-round outdoor enjoyment. Its sloping design facilitates efficient water drainage, preventing accumulation.

DOUBLE POLYCARBONATE ROOF



Waterproof



Withstand Wind



*Block Harmful
UV Rays*




Image: A detailed view of the double polycarbonate roof, illustrating its waterproof, wind-resistant, and UV-blocking properties with corresponding icons.




Image: Demonstrates the roof's resilience, showing it supporting up to 1100 lbs of snow and withstanding winds up to 50 mph.

Curtains & Netting System

The gazebo includes four privacy curtains and four breathable netting panels, providing versatility for privacy and ventilation. The fully enclosed double-track system allows for smooth sliding, and both curtains and netting are removable for cleaning.

Removable Curtains



Image: Illustrates the removable curtains, featuring a dual rail design for smooth operation, thick netting for insect protection, and a privacy curtain with a zipper for full enclosure.

Integrated J-Shape Hooks

Sturdy J-shaped hooks are integrated into the gazebo's structure, ideal for hanging lights, decorations, or other accessories to enhance your outdoor living space.

J-Shape Hook

Sturdy J-shaped hooks for gazebo! Ideal for hanging light and decor.




Image: A close-up view of the sturdy J-shape hooks located on the gazebo's ceiling, shown with decorative lights hanging from them.

SETUP AND ASSEMBLY

Detailed installation instructions are provided with your purchase. Please ensure all parts are present before beginning assembly. It is highly recommended that 2-4 people work together to complete the assembly, which typically takes 4-8 hours.

Your gazebo package contains 4 separate boxes. Please note that these boxes may arrive at different times. We appreciate your patience as you await the complete delivery.




Image: Visual representation of the gazebo's curtain system, demonstrating fully open, semi-open, and fully closed configurations, along with close-ups of the dual tracks, dual zipper, and Velcro straps for securing the curtains.



Image: A diagram showing the overall dimensions of the gazebo (14 ft x 12 ft x 9.02 ft height) and an illustration depicting the delivery process, indicating that the product ships in 4 separate boxes which may arrive at different times.

OPERATING INSTRUCTIONS

Using the Curtains and Netting

The gazebo is equipped with a dual-track system for its curtains and netting. This allows for flexible configuration:

- **Fully Open:** Slide both the curtains and netting completely to the sides and secure them with the provided ties to maximize open space.
- **Semi-Open:** Adjust the curtains and netting to partially cover the openings, providing partial shade or privacy while maintaining airflow.
- **Fully Closed:** Extend both the curtains and netting to fully enclose the gazebo. The privacy curtains feature zippers for complete closure, offering maximum privacy and protection from elements or insects.

Ensure curtains and netting are properly secured during windy conditions to prevent damage.

MAINTENANCE

Regular maintenance will extend the life of your gazebo:

- **Cleaning the Frame:** Wipe the steel frame with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Cleaning the Roof:** The polycarbonate roof can be cleaned with water and a soft brush or cloth. Do not use harsh chemicals that could damage the material.
- **Curtains and Netting:** The curtains and netting are removable for cleaning. Follow care instructions on the fabric tags, typically machine wash cold and air dry.
- **Hardware Check:** Periodically check all bolts and screws to ensure they are tight. Re-tighten as necessary.
- **Winter Care:** While the roof is designed to hold snow, it is advisable to clear excessive snow accumulation to prevent structural stress. Consider removing curtains and netting during harsh winter months for prolonged lifespan.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Parts do not align during assembly.	Incorrect orientation of parts; manufacturing tolerance variations.	Double-check part numbers and orientation against the assembly manual. Loosen all bolts slightly, align parts, then re-tighten. If issues persist, contact customer support.
Roof panels appear damaged or cracked.	Shipping damage; improper handling during assembly; excessive force.	Inspect panels upon arrival. If damaged, do not proceed with assembly. Contact customer support immediately for replacement parts.
Gazebo feels unstable after assembly.	Improper anchoring; loose connections.	Ensure all base plates are securely anchored to a solid foundation using appropriate expansion screws. Verify all frame connections are tightly fastened.

SPECIFICATIONS




Image: A detailed diagram illustrating the key dimensions of the gazebo, including its length (14 ft), width (12 ft), and height (9.02 ft).

Attribute	Detail
Brand	Raysfung
Model	12' x 14' Hardtop Gazebo
Product Dimensions	167.28"L x 143.76"W x 108.24"H (14' L x 12' W x 9.02' H)
Item Weight	199 Pounds
Frame Material	Alloy Steel (Powder-coated)
Roof Material	Polycarbonate
Water Resistance Level	Water Resistant
UV Protection	Yes

Attribute	Detail
Occupancy	8-10 People
Color	Gray
Assembly Required	Yes (2-4 people recommended, 4-8 hours)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact Raysfung customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, please visit the [Raysfung Store on Amazon](#).

© 2025 Raysfung. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question