

Hatteker HT-578

Hatteker Women's Electric Shaver HT-578 User Manual

Model: HT-578

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Hatteker Women's Electric Shaver, Model HT-578. Please read this manual thoroughly before first use and retain it for future reference.

SAFETY INFORMATION

Important Safety Precautions

- Do not immerse the charging base in water.
- Ensure the shaver is fully dry before charging.
- Keep out of reach of children.
- Do not use if the shaver or charging cable is damaged.
- For external use only.
- Disconnect from power source before cleaning.

PRODUCT OVERVIEW

Components

The Hatteker HT-578 electric shaver is a versatile 3-in-1 grooming tool designed for various body areas.



Image: Hatteker HT-578 Electric Shaver, including the main unit, three interchangeable shaving heads, two guide combs, a cleaning brush, a USB charging cable, and a storage pouch.



Image: Close-up of the Hattaker HT-578 shaver highlighting its key features: 3-in-1 design, IPX7 waterproof rating, LED display, illumination light, and charging base.

Shaving Heads

- **Wide Blade:** Ideal for larger body areas such as legs and arms.
- **Small Blade:** Suitable for narrower or more sensitive areas like underarms and bikini line.
- **Round Rotating Razor Head:** Designed for quick and gentle removal of facial hair on areas like lips, chin, and cheeks.



Image: Detailed view of the three interchangeable shaving heads: the long hair trimmer with guide combs, the body shaver, and the facial trimmer.

3 in 1 Multifunctional

Blades For Whole Body Shaving



Back

Legs


Arms

Armpits

Residues

Bikini Area

Efficiently removes the hair around your whole body



Curved Blade

(For Underarms and
Bikini area)

Middle Foil

(For Short hair and
Residues anywhere)

Straight Blade

(For Arm and Legs)

Image: Illustration of the multi-functional blades for whole body shaving, showing the curved blade for underarms and bikini area, the middle foil for short hair and residues, and the straight blade for arms and legs.

SETUP

Charging the Shaver

1. Connect the USB charging cable to the charging port on the shaver or its charging base.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
3. The LED display will show the battery percentage during charging.
4. A full charge takes approximately 1.5 hours.
5. Once fully charged, the shaver provides up to 90 minutes of cordless use.



Image: The Hattaker HT-578 shaver being charged via USB, illustrating the 1.5-hour charging time and 120-minute working time, powered by an 800mAh lithium battery.

Attaching/Detaching Shaving Heads

1. To attach a head, align the head with the main body and press firmly until it clicks into place.
2. To detach a head, gently pull it away from the main body.

OPERATING INSTRUCTIONS

General Use

1. Ensure the shaver is charged.
2. Select the appropriate shaving head for the desired body area.
3. Press the power button to turn on the shaver. The built-in LED light will illuminate for better visibility.
4. For optimal results, hold the shaver at a 90-degree angle to the skin and move it gently against the direction of hair growth.
5. The shaver can be used for both dry and wet shaving.
6. After use, press the power button to turn off the shaver.



Image: Demonstrates the Hattaker HT-578 shaver being used on various body parts: legs, armpit, face, and bikini area.

Specific Usage Tips

- **For Legs and Arms:** Use the wide blade for efficient coverage.
- **For Underarms and Bikini Area:** The small blade or curved blade is recommended for precision and comfort.
- **For Facial Hair:** Use the round rotating razor head for gentle removal on sensitive facial skin.
- **LED Light:** The integrated LED light helps illuminate fine hairs, ensuring a thorough shave.



LED Light for Blind Spots Illumination

***Reveals Even the Most Tiny Hair to Make
Sure Your Thorough Hair Removal
Experience***

Image: The Hatteker HT-578 shaver with its LED light activated, highlighting its function to illuminate blind spots and reveal tiny hairs for a thorough hair removal experience.

Wet & Dry Use

The shaver is IPX7 waterproof, allowing for safe use in the shower or bath. For wet shaving, apply shaving cream or gel for a smoother experience.

MAINTENANCE

Cleaning the Shaver

1. Turn off the shaver and detach the shaving head.
2. Rinse the shaving head under running water to remove hair clippings.
3. Use the included cleaning brush to remove any stubborn hair from the blades and inside the shaver body.
4. Allow all parts to air dry completely before reattaching the head or storing the shaver.
5. Do not use abrasive cleaners or harsh chemicals.

Storage

Store the shaver in a cool, dry place, away from direct sunlight and extreme temperatures. Use the provided storage pouch for protection when traveling.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery.	Charge the shaver for 1.5 hours.
Poor shaving performance.	Blades are dull or clogged with hair.	Clean the shaving head thoroughly. Consider replacing the head if performance does not improve.
Shaver stops during use.	Battery is depleted.	Recharge the shaver.
Skin irritation after shaving.	Improper technique or sensitive skin.	Ensure skin is clean and dry (for dry shave) or use shaving cream (for wet shave). Shave gently and avoid pressing too hard.

SPECIFICATIONS

Technical Data

Model: HT-578

Brand: Hatteker

Power Source: Battery Powered (Rechargeable)

Battery Type: Lithium Battery (800mAh)

Charging Time: Approximately 1.5 hours

Operating Time: Up to 90 minutes (cordless)

Waterproof Rating: IPX7 (suitable for wet & dry use)

Included Components: Main shaver unit, 3 interchangeable heads, cleaning brush, USB charging cable.

Dimensions: 7.87 x 5.51 x 2.72 inches (Package)

Weight: 12.63 ounces (Package)

WARRANTY AND SUPPORT

Manufacturer's Warranty

Please refer to the warranty card included in your product packaging for specific warranty terms and conditions.

Customer Support

For any questions, technical assistance, or support regarding your Hatteker Women's Electric Shaver, please contact Hatteker customer service through the contact information provided on the product packaging or the official Hatteker website.

