

[Manuals.plus](#) /

› [Aesfee](#) /

› Aesfee 5-in-1 Beard Trimmer and Clippers Set User Manual

Aesfee AF-8098

Aesfee 5-in-1 Beard Trimmer and Clippers Set User Manual

Model: AF-8098

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Aesfee 5-in-1 Beard Trimmer and Clippers Set. This versatile grooming kit is designed for men's beard trimming, hair clipping, body grooming, and nose/ear hair removal, offering precision and convenience for all your grooming needs.

SAFETY INFORMATION

- Always keep the trimmer away from water sources while charging or storing.
- Be cautious when using the trimmer near the face, neck, and other sensitive areas to avoid injury.
- Do not use the trimmer on infants or children.
- Always unplug the trimmer before cleaning or replacing parts.
- If the trimmer comes into contact with skin or eyes, rinse immediately with plenty of water and seek medical attention if necessary.
- Always follow the recommended cleaning and maintenance procedures to ensure the trimmer's safety and performance.

PACKAGE CONTENTS



Figure 1: Complete Aesfee 5-in-1 Grooming Kit with various attachments and charging dock.

Your Aesfee 5-in-1 Beard Trimmer Kit includes the following components:

- Main Trimmer Unit with Adjustable Dial
- Beard Trimming Head
- Hair Clipping Head
- Body Grooming Head
- Nose/Ear Hair Trimmer Head
- Triple Foils Shaver Head
- USB-C Charging Dock
- USB-C Cable
- Cleaning Brush
- User Manual

1. Charging the Device

Before first use, fully charge the trimmer. The device can be charged directly via the USB-C cable or by placing it on the charging dock. A full charge takes approximately 1.5 hours and provides up to 100 minutes of cordless use.



Nose & Ear Hair Trimmer

Safe & Efficient Curved Stainless Steel Blade Head

Figure 2: The Aesfee grooming kit placed on its USB-C charging dock.

2. Attaching and Detaching Heads

To attach a head, align it with the main unit and push gently until it clicks into place. To detach, firmly grasp the head and pull it away from the main unit. Ensure the device is turned off before changing heads.


3. Adjusting Trimming Length

The main trimmer unit features a precise dial with 20 adjustable length settings (1-20mm). Rotate the dial to select your desired trimming length. This allows for versatile styling from stubble to longer beard lengths or full haircuts.

Pro Beard Trimmer and Hair Clippers Kit

Sharp Stainless Steel Blade

Cuts Hair Precisely and Cleanly
without Any Pulling of Hair



Comb B: 11~21mm

Comb A: 1~10mm

The Rotating Cutting Length Adjuster

Allows Precise Trimming of Hair Lengths
From 1 to 20 mm with Only Two Guide Combs

Easy to Use and Easy to Store



Figure 3: The adjustable dial on the trimmer head for precise length control.

OPERATING INSTRUCTIONS

The Aesfee 5-in-1 grooming kit is designed for both wet and dry use, including in the shower. Always ensure the desired attachment is securely in place before turning on the device.

1. Beard Trimming and Hair Clipping

Attach the beard trimming or hair clipping head. Adjust the dial to your preferred length. For best results, move the trimmer against the direction of hair growth. The stainless steel blades ensure a clean, smooth cut without pulling.



Pro Hair Clippers & Beard Trimmer

Powerful & Precise for Barbers and Home Use

1 ~ 20mm Adjustable Trimming Length with Only 2 Guide Combs

Figure 4: Demonstrating beard trimming with the adjustable head.

Your browser does not support the video tag.

Video 1: An official demonstration of the 5-in-1 Beard Trimmer and Hair Clippers Set in use for various grooming tasks.

2. Triple Foils Shaver

For a close, smooth shave on stubble, bald heads, or fades, attach the triple foils shaver head. Move the shaver gently against the skin in short, circular motions.



Professional Triple Foils Shaver

A Close & Smooth Shaves for Face, Neck, Body, Bald Head, Fades

Figure 5: Using the professional triple foils shaver for a clean finish on a bald head.

3. Body Hair Trimming

The skin-friendly body hair trimmer head features circular toothed blades for comfortable trimming on areas like the abdomen, chest, back, and legs. Use gentle, even strokes.



Skin Friendly Body Hair Trimmer

Circular Toothed Blades Design for Comfort Trimming on the Abdomen, Chest, Back, Legs, Arms and Pubic Area

Figure 6: The body hair trimmer in action on an arm, highlighting its skin-friendly design.



Skin Friendly Body Hair Trimmer

Circular Toothed Blades Design for Comfort Trimming on the Abdomen, Chest, Back, Legs, Arms and Pubic Area

Figure 7: The body hair trimmer being used on the chest area for comfortable grooming.

4. Nose and Ear Hair Trimming

Attach the nose and ear hair trimmer head. Gently insert the trimmer tip into your nostril or ear canal and move it in a circular motion to trim unwanted hair. The curved stainless steel blade ensures safe and efficient removal.



IPX7 Waterproof and Washable

Wet/Dry Shaves Even in the Shower and Easy for Clean after Use

Figure 8: The nose and ear hair trimmer being used for safe and efficient hair removal.

MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Aesfee grooming kit.

1. Cleaning the Trimmer

The Aesfee grooming kit is IPX7 waterproof, allowing for easy cleaning under running water. After each use, detach the head and rinse it thoroughly under the tap. You can also rinse the main unit's blade area. Use the provided cleaning brush to remove any stubborn hair clippings.



Figure 9: Demonstrating the IPX7 waterproof feature by rinsing the trimmer head under water.

Your browser does not support the video tag.

Video 2: Official instructions on how to clean the shaver head of the Aesfee 5-in-1 Grooming Kit.

Ensure all parts are completely dry before reattaching and storing the trimmer. Do not use abrasive cleaners or harsh chemicals.

TROUBLESHOOTING

If you encounter any issues with your Aesfee grooming kit, please refer to the following common troubleshooting steps:

- **Device not turning on:** Ensure the battery is fully charged. If the device is new, it may require an initial charge.
- **Reduced performance/pulling hair:** Clean the blades and attachments thoroughly. Hair buildup can affect cutting efficiency. Ensure the blades are not damaged.
- **Battery not charging:** Verify that the USB-C cable and charging dock are properly connected to a power source. Try a different USB-C cable or power adapter if available.

- **Excessive noise or vibration:** Ensure all attachments are securely fastened. Clean any debris from the motor area.

If the problem persists after attempting these steps, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	AF-8098
Power Source	Battery Powered (1 CR5 battery included)
Charging Time	Approx. 1.5 hours
Operating Time	Up to 100 minutes
Waterproof Rating	IPX7 (100% waterproof and washable)
Adjustable Settings	20-level dial (1-20mm)
Blade Material	Stainless Steel
Color	Blue
Dimensions	8.19 x 6.46 x 3.23 inches
Weight	1.39 Pounds
Manufacturer	Aesfee Inc.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Aesfee customer service directly. Keep your purchase receipt as proof of purchase.

© 2025 Aesfee Inc. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question