

OHAYO X10 Max

OHAYO X10 MAX Bluetooth Speaker

INSTRUCTION MANUAL

Introduction

Thank you for choosing the OHAYO X10 MAX Bluetooth Speaker. This portable speaker is designed to deliver powerful, clear stereo sound with deep bass, vibrant colorful lights, and robust IPX7 waterproofing. It features Bluetooth 5.3 for stable connections, True Wireless Stereo (TWS) pairing for an immersive audio experience, and multiple input modes. This manual provides detailed instructions to help you set up, operate, and maintain your speaker for optimal performance.

What's in the Box

- 1 x X10 MAX Bluetooth Speaker
- 1 x USB-C Charging Cable (charging plug not contained)
- 1 x 3.5mm AUX Cable
- 1 x User Manual
- Lanyard

Product Features



The OHAYO X10 MAX Bluetooth Speaker, showcasing its sleek design and integrated colorful lighting.

IPX7 WATERPROOF

Highly sealed design, no fear of rain and flooding.



The speaker is IPX7 waterproof, allowing it to be submerged in water without damage, ideal for outdoor use.

25W DEEP BASS SOUND

Independent channel design provides more accurate audio performance, enhances your listening experience.



Equipped with a 2-way speaker system, including a 15W bass driver and a 10W silk diaphragm tweeter for rich, clear sound.

24H ULTRA-LONG BATTERY LIFE

Unleash the power of a 6600mAh battery with a handy indicator light - never worry about battery life again.



Features an exclusive long-life 6600 mAh battery, providing up to 24 hours of continuous music playback on a single charge.

4 INPUT MODES

BT, TF, AUX, USB-Audio to meet your diverse input needs



Supports versatile 4-way playback options: Bluetooth, USB audio, TF card, and AUX-IN.

TRUE WIRELESS STEREO

Bluetooth 5.3 guarantees a stable link between the two speakers, allowing you to enjoy 360-degree surround music.



Easily pair two X10 MAX speakers for True Wireless Stereo (TWS) sound, delivering 50W of powerful audio.

Additional Features:

- **Astonishing Premium Sound:** The X10 MAX delivers loud, clear, powerful sound with exceptional low and mid frequencies from its racetrack-shaped woofer, crisp highs from a separate tweeter, and deep bass from optimized dual passive radiators and Extra Bass technology.
- **Dazzling Lights Show:** Features pulsating and flashing lights that sync to the beat of the music, with five different lighting effects that can be switched or turned off freely.
- **One-Click Bluetooth Connection:** Bluetooth 5.3 chip ensures quick and stable pairing with devices up to 100 feet away.
- **Hands-Free Calling:** Built-in microphone allows for convenient hands-free calls.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C charging cable to the speaker's charging port and the other end to a USB power adapter (not included). The battery indicator lights will show charging status. A full charge takes approximately 3 hours.

2. Powering On/Off

Press and hold the Power button for a few seconds to turn the speaker on or off. You will hear an audible prompt.

3. Bluetooth Pairing

1. Turn on the X10 MAX speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing light.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "OHAYO X10 MAX" from the list of devices.

4. Once connected, you will hear a confirmation sound, and the light indicator will become solid.

4. True Wireless Stereo (TWS) Pairing

To pair two X10 MAX speakers for stereo sound:

1. Ensure both X10 MAX speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS button (often indicated by a chain link icon). The speaker will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. You will hear a confirmation tone once TWS pairing is successful.
4. Now, connect your device to the primary speaker via Bluetooth as described in step 3. Both speakers will play audio in stereo.

Operating Instructions

1. Basic Controls

- **Power Button:** Press and hold to turn on/off.
- **Play/Pause Button:** Press once to play or pause music.
- **Volume Up (+):** Press to increase volume. Press and hold to skip to the next track.
- **Volume Down (-):** Press to decrease volume. Press and hold to go to the previous track.
- **Bass Boost Button:** Press to activate or deactivate the Extra Bass mode.
- **Light Mode Button:** Press to cycle through different light effects. Press and hold to turn lights on/off.

2. Input Modes

The X10 MAX supports four input modes:

- **Bluetooth Mode:** Default mode after powering on. Connect wirelessly to your device.
- **AUX-IN Mode:** Connect an audio device using the provided 3.5mm AUX cable. The speaker will automatically switch to AUX mode.
- **TF Card Mode:** Insert a TF (microSD) card with audio files into the TF card slot. The speaker will automatically play music from the card.
- **USB Audio Mode:** Connect the speaker to a computer or other USB audio source using the USB-C cable. The speaker will function as an external audio output device. This mode also supports charging while in use.

3. Hands-Free Calling

When connected via Bluetooth, you can use the speaker for hands-free calls:

- **Answer/End Call:** Press the Play/Pause button once.
- **Reject Call:** Press and hold the Play/Pause button.
- **Redial Last Number:** Double-press the Play/Pause button.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

- **Waterproofing:** The speaker is IPX7 waterproof. Ensure the charging port cover is securely closed before exposing the speaker to water. Do not intentionally submerge the speaker for extended periods or in water deeper than 1 meter.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for a long period, charge the battery every 3 months to maintain its lifespan.
- **Battery Care:** Avoid fully draining the battery frequently. Charge the speaker when the low battery indicator appears.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery; Power button not pressed correctly	Charge the speaker; Press and hold the Power button for 3-5 seconds.
No sound	Volume too low; Device not connected; Incorrect input mode	Increase speaker and device volume; Re-pair Bluetooth; Check AUX/TF card connection.
Cannot pair via Bluetooth	Speaker not in pairing mode; Device Bluetooth off; Too far from device; Interference	Ensure speaker is in pairing mode; Turn on device Bluetooth; Move closer to speaker; Turn off other Bluetooth devices.
TWS pairing fails	Speakers already connected to other devices; Too far apart	Disconnect speakers from other devices; Ensure both speakers are X10 MAX models; Place speakers close together.
Lights not working	Lights turned off; Malfunction	Press the Light Mode button to cycle through effects or turn them on; If issue persists, contact support.

Specifications

Feature	Detail
Model Name	X10 MAX
Connectivity Technology	Bluetooth 5.3, Auxiliary, TF Card, USB Audio
Speaker Maximum Output Power	35 Watts (25W total system power)
Battery Capacity	6600 mAh (24.2 Amp Hours)
Playtime	Up to 24 Hours
Charging Time	3 Hours
Water Resistance Level	IPX7 (Waterproof)
Wireless Communication Range	Up to 100 Feet (30 meters)
Product Dimensions	2.95"D x 2.95"W x 7.28"H (7.5cm D x 7.5cm W x 18.5cm H)
Item Weight	15.9 ounces (450 Grams)
Material	Acrylonitrile Butadiene Styrene (ABS), Aluminum, Silicone



Feature	Detail
Signal-to-Noise Ratio	80 dB
Woofer Diameter	75 Millimeters
Tweeter Diameter	26 Millimeters
Included Components	Speaker, USB-C Cable, AUX Cable, User Manual, Lanyard

Warranty and Support

The OHAYO X10 MAX Bluetooth Speaker comes with an extended warranty. For specific warranty terms, duration, and to register your product, please refer to the warranty card included in your product packaging or visit the official OHAYO website. If you encounter any issues or have questions not covered in this manual, please contact OHAYO customer support through their official channels for assistance.

© 2025 OHAYO. All rights reserved.

Related Documents

	<p>OHAYO X3 Bluetooth Speaker Quick Start Guide</p> <p>Comprehensive quick start guide for the OHAYO X3 Bluetooth speaker, covering setup, TWS pairing, controls, charging, and technical specifications.</p>
	<p>OHAYO A7 Quick Start Guide</p> <p>A concise quick start guide for the OHAYO A7 wireless earbuds, covering powering on/off, pairing, music mode, call mode, factory reset, charging, specifications, and troubleshooting.</p>