

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hafele](#) /
- › [Hafele Magnechef Induction Cooktop User Manual](#)

Hafele 536.06.000

Hafele Magnechef Induction Cooktop User Manual

Model: 536.06.000

INTRODUCTION

Thank you for choosing the Hafele Magnechef Induction Cooktop. This appliance is designed for efficient and convenient cooking, featuring 2100W high power, a durable ceramic glass plate, auto cook menus, and intuitive touch controls. Please read this manual thoroughly before operating the cooktop to ensure safe and optimal performance. Keep this manual for future reference.



Image: The Hafele Magnechef Induction Cooktop, showcasing its sleek black design with a pan of rice placed on its surface, ready for cooking.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, injury to persons, or damage when using the appliance, follow basic safety precautions, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or cooktop in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.

- The cooktop requires a 16A plug. Ensure your electrical outlet can support this requirement.
- Use only induction-compatible cookware.
- Do not place metallic objects such as knives, forks, spoons, lids, keys, or coins on the cooktop surface as they can get hot.
- Ensure adequate ventilation around the cooktop during operation.

PRODUCT OVERVIEW

The Hafele Magnechef Induction Cooktop features a sleek design with intuitive controls for a seamless cooking experience.

Components:

- **Ceramic Glass Plate:** The main cooking surface, durable and easy to clean.
- **Control Panel:** Touch-sensitive buttons for various functions and settings.
- **Cooling Fan Vents:** Located on the underside and sides for heat dissipation.
- **Power Cord:** For connecting to an electrical outlet.



Intuitive Touch Control

Allows users
to easily navigate
cooking settings

Image: A close-up view of the Häfele Magnechef Induction Cooktop's intuitive touch control panel, highlighting the responsive buttons for easy navigation of cooking settings.

SETUP

- Unpacking:** Carefully remove the cooktop from its packaging. Retain packaging for future storage or transport.
- Placement:** Place the induction cooktop on a flat, stable, and heat-resistant surface. Ensure there is sufficient space around the unit for proper ventilation (at least 10 cm from walls or other appliances).
- Power Connection:** Plug the 16A power cord into a dedicated 16A electrical outlet. Do not use extension cords or adapters.
- Initial Cleaning:** Before first use, wipe the ceramic glass plate with a soft, damp cloth.

OPERATING INSTRUCTIONS

The Häfele Magnechef Induction Cooktop offers various functions for versatile cooking.

Basic Operation:

1. Place an induction-compatible pot or pan centrally on the ceramic glass plate.
2. Press the **On/Off** button to power on the cooktop. The display will illuminate.
3. Select your desired cooking mode or adjust power/temperature using the touch controls.
4. After cooking, press the **On/Off** button again to turn off the cooktop. The fan may continue to run for a short period to cool down the unit.

Key Features and Functions:

- **2100W High Power:** Provides rapid heating for quick cooking.
- **Auto Cook Menus:** Features 10 pre-programmed settings for popular Indian dishes. Simply select the desired menu, and the cooktop will adjust power and time automatically.



Image: The Hafele Magnechef Induction Cooktop displaying its Auto Cook Menu options, designed to optimize meal preparation with ease.

- **Intuitive Touch Control:** Responsive touch panel allows for easy navigation and adjustment of cooking settings.
- **Boost Mode:** Activates maximum power (2100W) for a short period, significantly reducing boiling and heating times. Ideal for quickly bringing water to a boil.

- **Simmer Mode:** Maintains precise low temperatures, perfect for slow cooking, simmering sauces, or keeping food warm without overcooking.
- **Smart Vessel Detection:** The cooktop uses sensors to detect the presence of a compatible vessel. Heating will only begin when a proper induction-compatible pot or pan is placed on the cooking zone, ensuring safety and energy efficiency.
- **Preset Timer:** Set accurate cooking times for consistent results. The cooktop will automatically turn off once the timer expires.
- **Keep Warm Function:** Maintains food at an ideal serving temperature without further cooking, preventing food from getting cold.
- **Lock Function:** Disables the control panel to prevent accidental changes to settings during cooking or cleaning. Press and hold the lock button to activate/deactivate.



Image: Visual representation of key features including Lock Function, Smart Vessel Detection, Preset Timer, Simmer Mode, and Boost Mode, illustrating the advanced capabilities of the cooktop.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Hafele Magnechef Induction

Cooktop.

- **Before Cleaning:** Always unplug the cooktop from the power outlet and allow it to cool completely before cleaning.
- **Ceramic Glass Plate:** Wipe the surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive ceramic cooktop cleaner. Do not use abrasive pads, harsh chemicals, or sharp objects.
- **Control Panel:** Wipe gently with a soft, dry or slightly damp cloth. Avoid excessive moisture.
- **Vents:** Ensure the cooling fan vents are free from dust and debris. Use a soft brush or vacuum cleaner to gently clear any blockages.
- **Storage:** If storing for an extended period, ensure the cooktop is clean and dry. Store in a cool, dry place, preferably in its original packaging.



Image: The Hafele Magnechef Induction Cooktop featuring its durable ceramic glass plate, effortlessly supporting heavy Indian utensils and designed for easy cleaning.

If you encounter issues with your induction cooktop, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; Power cord not properly plugged in; Circuit breaker tripped.	Check power outlet; Ensure cord is securely plugged in; Reset circuit breaker.
No heating or "E0" error.	Non-compatible cookware; No cookware on surface; Cookware not centered.	Use induction-compatible cookware; Place cookware on the cooking zone; Center the cookware.
Cooktop stops during operation.	Overheating protection activated; Cookware removed.	Allow cooktop to cool down; Ensure cookware remains on the surface.
Fan continues to run after turning off.	Normal cooling process.	This is normal. The fan will stop automatically once the unit has cooled sufficiently.
Controls are unresponsive.	Lock function is active.	Deactivate the Lock function by pressing and holding the lock button.

If the problem persists after trying these solutions, please contact Hafele customer support.

SPECIFICATIONS

Feature	Detail
Model Number	536.06.000
Brand	Hafele
Power	2100W
Power Source	Corded Electric
Voltage/Frequency	AC 220-240V, 50-60Hz
Heating Elements	1
Cooktop Material	Ceramic Glass
Color	Black
Item Weight	2 kg 350 g
Dimensions (LxWxH)	34.8 x 29 x 5.8 cm
Cord Length	1.35 m



Power
2100W



Frequency
50-60Hz



Cord Length
1.35 m



Image: A technical diagram illustrating the dimensions (length, width, height) and key electrical specifications (Power 2100W, Frequency 50-60Hz, Cord Length 1.35m) of the Hafele Magnechef Induction Cooktop.

WARRANTY AND CUSTOMER SUPPORT

Your Hafele Magnechef Induction Cooktop comes with a **2-Year Warranty** from the date of purchase, covering manufacturing defects under normal use.

Warranty Exclusions:







- Damage caused by improper use, negligence, or accident.
- Damage from unauthorized repairs or modifications.
- Normal wear and tear.
- Damage due to power fluctuations or incorrect voltage.

For Service and Support:

Please contact Hafele customer service for any warranty claims, technical assistance, or service requests. Have your model number and purchase receipt ready when contacting support.
Visit the official Hafele website for contact information and service center details:www.hafeleindia.com

© 2025 Hafele. All rights reserved.

Related Documents - 536.06.000

	<p>Hafele 2 Zones Induction Hob HC-I7325B User Manual</p> <p>Comprehensive user manual for the Hafele 2 Zones Induction Hob HC-I7325B, covering safety warnings, product overview, operation, special functions, troubleshooting, and installation instructions.</p>
	<p>Hafele HSI-21FW Single Induction Hob User Manual Features, Operation, Troubleshooting</p> <p>Comprehensive user manual for the Hafele HSI-21FW single induction hob. Learn about product features, safety notices, operation, troubleshooting, and technical specifications.</p>
	<p>Panduan Instalasi dan Penggunaan Kompor Induksi Tanam Berventilasi Häfele 538.49.523 SMART POP UP 2.0</p> <p>Temukan panduan lengkap instalasi dan penggunaan untuk Häfele SMART POP UP 2.0 Built-in Venting Induction Hob (538.49.523). Pelajari cara memasang, mengoperasikan, merawat, dan menyelesaikan masalah pada kompor induksi berventilasi Anda.</p>
	<p>Häfele Furniture Knob Safety Instructions and Usage Guide</p> <p>Essential safety precautions and usage guidelines for Häfele furniture knobs (model 10611073), including warnings about child safety and packaging.</p>
	<p>Häfele Product 10290140 Safety Instructions and Warnings</p> <p>Safety instructions and warnings for Häfele product 10290140, covering general usage, restrictions for children and individuals with reduced abilities, and suffocation risks from packaging. Includes manufacturer details.</p>
	<p>Häfele Connect App Short User Guide</p> <p>A concise user guide for the Häfele Connect App, explaining how to set up and control BLE-Boxes for smart lighting, including features like scenes, animations, timers, and network sharing.</p>

