

Aroepurt Cubot TAB 70

Aroepurt Cubot TAB 70 11.7-inch Tablet Case User Manual

Model: Cubot TAB 70 | Brand: Aroepurt

INTRODUCTION

This manual provides instructions for the proper use and care of your Aroepurt Tablet Case, designed for the Cubot TAB 70 11.7-inch tablet. This folio cover offers comprehensive protection, multiple viewing angles, and convenient features to enhance your tablet experience.

WHAT'S IN THE BOX

- 1 x Aroepurt Tablet Case (Black)

SETUP: INSTALLING YOUR TABLET

Follow these steps to securely install your Cubot TAB 70 tablet into the Aroepurt case:

- 1. Open the Case:** Lay the case flat on a clean surface and open it completely.
- 2. Align the Tablet:** Carefully align your Cubot TAB 70 tablet with the protective frame inside the case. Ensure the tablet's edges fit snugly into the frame.
- 3. Secure the Tablet:** Gently press the tablet into the frame until it is fully seated. The case is designed with thickened anti-drop corner protectors to hold the tablet securely.
- 4. Check Camera Alignment:** Verify that the tablet's rear camera aligns with the reserved camera opening on the back of the case. The case features multiple pre-cutouts to accommodate various camera positions.

COMPATIBLE WITH A LOT OF TABLET

Please kindly check your tablet size before purchase as shown



Image: Tablet insertion into the case, demonstrating compatibility and secure fit.

SUITABLE FOR DIFFERENT PLATES

The 3 pre-cutouts can be used by tablets with different camera positions




Image: Detail of the case's camera cutouts, designed to be suitable for tablets with different camera placements.

Note: This case does not support any tablet's auto-sleep/wake function.

OPERATING INSTRUCTIONS

Using the Stand Function

The Aroepurt case features a built-in stand with an anti-slip strip design, allowing for stable, multi-angle viewing.

1. **Convert to Stand:** Fold the front cover backward to form a triangular stand.
2. **Adjust Viewing Angle:** Position the tablet along the anti-slip strips on the inner cover to achieve your desired viewing angle. The 360-degree rotation feature allows for both portrait and landscape orientations.

MULTIPLE VIEWING

It turns into a convenient stand.
Frees your hands and gives you a
best viewing angle.



Image: The case configured as a stand, highlighting the anti-slip stripe for secure positioning.

ADJUSTABLE MULTIPLE ANGLES

Supports multiple viewing angles with 360° free rotate



Image: Demonstrating the adjustable multiple angles and 360-degree rotation capability of the stand.

Utilizing the Storage Pocket

The case includes a convenient storage pocket for carrying small items.

- **Access Pocket:** Locate the large welt pocket on the front cover of the case.
- **Store Items:** Use this pocket to store cards, documents, or cash.

STORAGE POCKET

The pocket is convenient for carrying cards, documents, and cash



Image: The integrated storage pocket, illustrating its capacity for cards, documents, and cash.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Aroepurt tablet case, follow these care guidelines:

- **Cleaning:** Wipe the PU leather surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- **Protection:** The case provides full body protection against scratches, shocks, fingerprints, and dust. While durable, avoid exposing it to extreme temperatures or sharp objects.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight.

ALL-OVER- PROTECTION

Goes into every side & corner,



Device ports, speakers, buttons all work fine



Slim & Lightweight



It can protect the plate very well

Image: Visual representation of the case's protective features, including corner protection and access to device ports.

TROUBLESHOOTING

- **Tablet Does Not Fit:** Ensure your tablet is the Cubot TAB 70 11.7-inch model. This case is specifically designed for this device.
- **Camera Obstruction:** The case has a reserved back camera opening. If your camera is partially obstructed, gently adjust the tablet's position within the frame. The case features multiple cutouts to accommodate various camera placements.
- **Stand Instability:** Ensure the case is placed on a flat, stable surface. The anti-slip strip is designed to provide stability; reposition the tablet along the strip if it slides.

SPECIFICATIONS

Feature	Detail
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces





Special Features	Card insertion, Storage pocket, Thickened anti-drop corner protector, Folding stand
Form Factor	Flip Case
Color	Black
Compatible Devices	Cubot TAB 70
Shell Type	Hybrid



WARRANTY AND SUPPORT

For any questions or support regarding your Aroepurt tablet case, please refer to the seller's contact information on the platform where the purchase was made. Specific warranty details may vary by retailer.

© 2024 Aroepurt. All rights reserved.

Related Documents - Cubot TAB 70

	<p>Neomounts FL15-750WH1 Tablet Stand: Installation and User Manual</p> <p>Comprehensive instruction manual for the Neomounts FL15-750WH1 tablet stand, detailing installation steps, parts, and safety precautions for universal tablet mounting. Supports various iPad and Samsung Galaxy Tab models.</p>
	<p>Lenovo Android Tablet Troubleshooting Guide</p> <p>Comprehensive troubleshooting guide for Lenovo Android tablets, covering common issues like lockups, boot failures, update problems, forgotten passwords, display issues, connectivity problems, and more.</p>
	<p>DreamerX Samsung Galaxy Tab S3 9.7 Case Installation Guide</p> <p>Step-by-step installation guide for the DreamerX Heavy Duty Rugged Silicone Case for Samsung Galaxy Tab S3 9.7 (Models T820, T825, T827), including shoulder strap attachment.</p>
	<p>Logitech Ultrathin Keyboard Folio S310 Setup Guide</p> <p>Comprehensive setup guide for the Logitech Ultrathin Keyboard Folio S310, detailing product features, Bluetooth pairing, app usage, troubleshooting, and battery information for Samsung Galaxy Tab 3 (10.1").</p>

	<p>Cubot P041-Tab Kingkong User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the CUBOT P041-Tab Kingkong tablet, guiding users through setup, operation, safety, and features.</p>
	<p>Logitech Keyboard Folio S Setup Guide for Samsung Galaxy Tablets</p> <p>This guide provides setup instructions, connection details, usage tips, and troubleshooting for the Logitech Keyboard Folio S, designed for Samsung Galaxy Note 10.1 and Galaxy Tab 2 10.1.</p>