

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aroepurt](#) /

› [Aroepurt Protective Case for Hannspree HannsNote2 10-Inch eReader User Manual](#)

Aroepurt Aroepurt Protective Case for HannsNote2 10-Inch eReader

Aroepurt Protective Case for Hannspree HannsNote2 10-Inch eReader User Manual

Model: Aroepurt Protective Case for HannsNote2 10-Inch eReader

1. INTRODUCTION

Thank you for choosing the Aroepurt Protective Case for your Hannspree HannsNote2 10-Inch eReader. This case is designed to provide comprehensive protection and enhanced functionality, including multiple viewing angles and a 360-degree rotating stand, all within a durable PU leather folio design. This manual provides instructions for proper installation, operation, and care of your new protective case.

2. PRODUCT FEATURES

- **Compatibility:** Specifically designed for the Hannspree HannsNote2 10-Inch eReader.
- **360-Degree Rotation:** Allows for versatile viewing in both portrait and landscape orientations.
- **Multi-Viewing Angles:** Integrated stand with anti-slip strips provides stable support at various angles for comfortable viewing and typing.
- **Comprehensive Protection:** Durable PU leather exterior and soft anti-slip interior protect against scratches, shocks, fingerprints, and dust. Features thickened anti-drop corner protectors.
- **Functional Design:** Includes a reserved back camera opening, card insertion slots, and a pocket for documents or cash.
- **Slim & Lightweight:** Designed to add minimal bulk while offering maximum protection.



Image: The Aroepurt Protective Case in brown, shown from the front closed and with a tablet inserted into its stand in two different orientations.

3. SETUP AND INSTALLATION

To install your Hannspree HannsNote2 10-Inch eReader into the protective case, follow these steps:

1. Open the folio cover of the case.
2. Align your HannsNote2 eReader with the internal frame of the case. Ensure the eReader's corners fit securely into the case's corner holders.
3. Gently press the eReader into place until it is firmly seated within the protective frame. Verify that all edges are covered and the eReader is stable.
4. Check that all ports, buttons, and the camera opening are accessible and unobstructed.

ALL-OVER-PROTECTION

Goes into every side & corner



Device ports, speakers, buttons all work fine



Slim & Lightweight



It can protect the plate very well

Image: A Hannspree HannsNote2 eReader securely placed within the Aroepurt protective case, highlighting the precise fit and access to device features.

4. OPERATING INSTRUCTIONS

4.1 Using the Multi-Viewing Stand

The case features an integrated stand with anti-slip strips to provide stable viewing angles:

1. Open the front cover of the case.
2. Fold the cover back to form a triangular stand.
3. Place the edge of your eReader into one of the anti-slip strips on the inside of the cover to achieve your desired viewing angle.

MULTIPLE VIEWING

It turns into a convenient stand. Frees your hands and gives you a best viewing angle.




Image: The Aroepurt case configured as a stand, showcasing the anti-slip stripe and the tablet positioned for optimal viewing.

4.2 360-Degree Rotation

The case allows for 360-degree rotation of your eReader:

1. While the eReader is secured in the case, gently rotate the eReader within its frame to switch between portrait and landscape orientations.
2. Ensure the eReader clicks into place securely after rotation to maintain stability.

ADJUSTABLE MULTIPLE ANGLES

Supports multiple viewing angles with 360° free rotate



Image: An illustration showing the 360-degree rotation capability of the tablet within the Aroepurt case, allowing for both portrait and landscape modes.

4.3 Accessing Camera and Ports

The case is designed with precise cutouts to ensure full access to your eReader's camera, ports, and buttons. The reserved back camera opening supports camera usage without removing the eReader from the case.

SUITABLE FOR DIFFERENT PLATES

The 3 pre-cutouts can be used by tablets with different camera positions



Image: The Aroepurt case highlighting its adaptable camera cutouts, designed to accommodate different tablet camera positions.

4.4 Using Storage Pockets

The case includes internal slots for cards and a larger pocket for documents or cash, providing convenient storage for essential items.

STORAGE POCKET

The pocket is convenient for carrying-cards, documents, and cash



Image: The Aroepurt case open, revealing a storage pocket suitable for carrying cards, documents, or cash.

5. MAINTENANCE

To ensure the longevity and appearance of your Aroepurt protective case, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior PU leather with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- **Stain Removal:** For minor stains, use a mild soap solution on a cloth and gently rub the affected area. Wipe clean with a damp cloth and allow to air dry.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Overfilling:** Do not overfill the card slots or storage pocket, as this can stretch the material or prevent the case from closing properly.

6. TROUBLESHOOTING

If you encounter any issues with your Aroepurt protective case, consider the following:

- **Tablet Does Not Fit:** Ensure your device is a Hannspree HannsNote2 10-Inch eReader. This case is specifically designed for this model.
- **Case Not Closing Properly:** Check if the storage pocket is overfilled or if the tablet is not seated correctly within the frame.
- **Stand Instability:** Ensure the tablet is placed firmly into one of the anti-slip strips. Adjust the angle as needed.

7. SPECIFICATIONS

Product Name	Aroepurt Protective Case for Hannspree HannsNote2 10-Inch eReader
Compatible Devices	Hannspree HannsNote2
Material	Premium PU Leather (Exterior), Soft Anti-slip Interior
Color	Brown (Color may vary by specific product variant)
Form Factor	Flip Case / Folio
Special Features	360-Degree Rotation, Multi-Viewing Stand, Card Insertion, Storage Pocket, Thickened Anti-Drop Corner Protector, Reserved Camera Opening
Product Dimensions	0.39 x 0.39 x 0.39 inches (approximate, when closed)
Item Weight	2.46 ounces
What's in the Box	1*Tablet Case

8. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available details. For warranty claims, technical support, or further assistance, please refer to the seller or manufacturer's contact information provided at the point of purchase.