

ROCAM FC1004

ROCAM Security Camera Indoor (Model FC1004) User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the ROCAM Indoor Security Camera. This device is designed to provide reliable home surveillance with features such as 360° pan/tilt, 2-way audio, and night vision. This manual will guide you through the installation, setup, and operation of your camera.

2. PACKAGE CONTENTS

Please check the package to ensure all items are present:

- ROCAM Wi-Fi Camera
- Power Adapter
- User Guide (this manual)
- Mounting Bracket and Screws (for ceiling mount)



Image: The ROCAM security camera, power adapter, user guide, and mounting accessories are shown neatly arranged next to the product box.

3. PRODUCT OVERVIEW

Familiarize yourself with the different parts of your ROCAM camera.



Figure 3.1: Front View. Shows the camera lens and

indicator light.



Figure 3.2: Top-Rear View. Highlights the reset button and MicroSD card slot.



Figure 3.3: Back View. Displays the speaker grille and DC 5V power input.

4. SETUP GUIDE

4.1. Physical Installation

1. **Choose a Location:** Select an indoor location with a stable 2.4GHz Wi-Fi signal. The camera can be placed on a flat surface or mounted to a ceiling.
2. **Power On:** Connect the power adapter to the camera's DC 5V port and plug it into a power outlet. The camera will power on and initiate its self-test.
3. **Indicator Light:** Wait for the indicator light to flash red, indicating it's ready for connection.

4.2. App Installation and Account Creation

1. **Download the App:** Search for the "ROCAM" app in your smartphone's app store (iOS App Store or Google Play Store) and download it.
2. **Register Account:** Open the app and follow the on-screen instructions to register a new account using your email address or phone number.

4.3. Camera Connection

1. **Add Device:** In the ROCAM app, tap the "+" icon to add a new device. Select "Smart Camera" or the appropriate camera type.
2. **Wi-Fi Configuration:** Ensure your phone is connected to a 2.4GHz Wi-Fi network. Enter your Wi-Fi password when prompted. *Note: 5GHz Wi-Fi networks are not supported.*
3. **Scan QR Code:** The app will generate a QR code. Hold your phone approximately 15-20 cm (6-8 inches) in front of the camera lens until you hear a prompt sound from the camera, indicating successful scanning.
4. **Connection Complete:** Once connected, the camera's indicator light will turn solid blue. You can now name your camera and begin using it.

5. OPERATING INSTRUCTIONS

5.1. Live View

Open the ROCAM app and tap on your camera's name to access the live video feed. You can view real-time footage from your camera.

5.2. Pan, Tilt, and Digital Zoom

On the live view screen, swipe your finger across the video feed to remotely control the camera's pan (horizontal) and tilt (vertical) movements. Pinch to zoom in or out digitally.

- **Pan Range:** 320° horizontal rotation.
- **Tilt Range:** 80° vertical rotation.
- **Digital Zoom:** 4X digital zoom.

5.3. Two-Way Audio

Tap the microphone icon in the app to speak through the camera's speaker. Tap the speaker icon to listen to audio from the camera's surroundings.

5.4. Motion Detection and Alerts

Enable motion detection in the camera settings within the app. When motion is detected, the camera will record a short video clip and send an alert notification to your smartphone.

5.5. Night Vision

The camera automatically switches to night vision mode in low-light conditions, providing clear black and white video up to 30 feet using its integrated IR system.

5.6. Video Recording and Storage

The camera supports two recording methods:

- **MicroSD Card Storage:** Insert a MicroSD card (up to 128GB, not included) into the camera's slot for local storage of recordings. Ensure the camera is powered off before inserting or removing the card.
- **Cloud Storage:** Subscribe to the optional cloud storage service through the ROCAM app for secure, off-site video storage.

6. MAINTENANCE

6.1. Cleaning

Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.

6.2. Firmware Updates

Periodically check the ROCAM app for available firmware updates. Keeping your camera's firmware up-to-date ensures optimal performance and security features.

6.3. Storage Management

If using a MicroSD card, regularly review and manage recorded footage. Old recordings may be overwritten automatically when the card is full, depending on your settings.

7. TROUBLESHOOTING

- **Camera not connecting to Wi-Fi:**
 - Ensure your Wi-Fi network is 2.4GHz. 5GHz is not supported.
 - Check Wi-Fi password for correctness.
 - Move the camera closer to your Wi-Fi router.
 - Reset the camera by pressing the reset button for 5 seconds until you hear a prompt.
- **No live video feed:**
 - Verify the camera is powered on and connected to Wi-Fi (solid blue indicator light).
 - Check your internet connection.
 - Restart the ROCAM app.
- **Motion alerts not received:**
 - Ensure motion detection is enabled in the app settings.
 - Check your phone's notification settings for the ROCAM app.
 - Adjust motion sensitivity if necessary.

8. SPECIFICATIONS

Feature	Detail
Model Number	FC1004
Indoor/Outdoor Usage	Indoor
Video Capture Resolution	1080p (Full-HD)
Connectivity Protocol	Wi-Fi (2.4GHz only)
Power Source	Corded Electric (DC 5V)
Pan/Tilt Range	320° Horizontal, 80° Vertical
Night Vision	Up to 30 ft (Infrared)
Audio	2-Way Audio (Built-in Mic & Speaker)
Storage Options	MicroSD Card (up to 128GB), Cloud Storage
Dimensions (L x W x H)	2.9 x 2.9 x 3.6 inches



9. WARRANTY AND SUPPORT




For warranty information and technical support, please refer to the ROCAM official website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Manufacturer: Shenzhen Yelow Technology Co.,Ltd

© 2024 ROCAM. All rights reserved.

Related Documents - FC1004

	<p>ROCAM CR1024 Calendar Alarm Clock with Time Projection User Manual</p> <p>Comprehensive user manual for the ROCAM CR1024 Calendar Alarm Clock, detailing its features including time projection, alarm settings, date configuration, DST function, brightness control, temperature/humidity monitoring, night light, and device charging capabilities.</p>
	<p>ROCAM CR1008i Digital LED Alarm Clock with Bed Shaker User Manual</p> <p>User manual for the ROCAM CR1008i Digital LED Alarm Clock with Bed Shaker. Learn how to set time, alarms, use the bed shaker, night light, and understand warranty information.</p>

 <p>The image shows the ROCAM CR1008 Digital LED Alarm Clock. It is a rectangular device with a large digital display showing '10:38'. Below the display are several buttons for setting the time, alarm, and other functions. The device has a USB port for charging and a small night light.</p>	<p>ROCAM CR1008 Digital LED Alarm Clock User Manual</p> <p>User manual for the ROCAM CR1008 Digital LED Alarm Clock. This guide provides instructions on setting up, operating features like time and alarm setting, dimmer, night light, DST, USB charging, and warranty information.</p>
 <p>The image shows the ROCAM CR1009Pro Emergency Alert Radio. It is a portable device with a large speaker, a digital display, and several buttons. It features a NOAA weather alert system and a solar crank for charging.</p>	<p>ROCAM CR1009Pro Emergency Alert Radio: User Manual and Features</p> <p>Comprehensive guide to the ROCAM CR1009Pro Emergency Alert Radio, covering its features, power supply modes, radio operation, and emergency functions like NOAA weather alerts and SOS.</p>
 <p>The image shows the ROCAM CR1001eM Alarm Clock with Vibrator. It is a rectangular device with a large digital display showing '12:08'. It has a USB port and a small night light.</p>	<p>ROCAM CR1001eM Alarm Clock with Vibrator User Manual</p> <p>User manual for the ROCAM CR1001eM Alarm Clock with Vibrator, detailing its features, setup, and operation for heavy sleepers.</p>
	<p>ROCAM CR1009 Emergency Alert Radio User Manual</p> <p>Comprehensive user manual for the ROCAM CR1009 Emergency Alert Radio, detailing its features, operation, power supply modes, radio functions, and specifications. Includes AM/FM/SW, NOAA weather alerts, solar crank, flashlight, and phone charging capabilities.</p>