

Faber HOOD COMET BLDC FL HC BK 60

Faber HOOD COMET BLDC FL HC BK 60 Wall Mounted Kitchen Chimney User Manual

This manual provides essential information for the safe and efficient use, installation, and maintenance of your Faber HOOD COMET BLDC FL HC BK 60 Kitchen Chimney.

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before installing or operating the appliance. Retain this manual for future reference.

- Ensure the power supply voltage matches the rating label on the chimney.
- Installation must be performed by a qualified technician in accordance with local regulations.
- Do not operate the chimney if the power cord is damaged. Contact service personnel immediately.
- Maintain adequate ventilation in the room when the chimney is in use, especially if other fuel-burning appliances are present.
- Clean the appliance regularly to prevent grease buildup, which can be a fire hazard.
- Do not flambé under the chimney.
- Keep children away from the appliance during operation and cleaning.

2. PRODUCT OVERVIEW

The Faber HOOD COMET BLDC FL HC BK 60 is a 60 cm wall-mounted kitchen chimney designed for efficient smoke and odor extraction. It features advanced filterless technology, a powerful BLDC motor, and multiple control options for user convenience.

Key Features:

- **BLDC Motor:** Provides high suction power (1500 m³/hr) with reduced noise and energy consumption.
- **Filterless Technology:** Eliminates the need for filters, simplifying maintenance.
- **Control Options:** Touch Control, Gesture Control, and Remote Control for versatile operation.
- **Heat Auto Clean:** Facilitates easy internal cleaning.

- **9-Speed Settings:** Allows precise control over suction intensity.
- **LED Lighting:** Illuminates the cooking area.



Figure 2.1: Front view of the Faber HOOD COMET BLDC FL HC BK 60 Kitchen Chimney, showcasing its sleek black finish and control panel.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all the following items are present:

- 1 x Faber HOOD COMET BLDC FL HC BK 60 Kitchen Chimney Unit
- 1 x User Manual (this document)
- 1 x Remote Control
- Installation accessories (screws, brackets, etc. - may vary)

If any components are missing or damaged, please contact Faber customer support immediately.

4. SETUP AND INSTALLATION

The Faber HOOD COMET BLDC FL HC BK 60 is a wall-mounted chimney. Proper installation is crucial for optimal performance and safety.

4.1 Pre-Installation Checklist:

- Ensure the wall is strong enough to support the chimney's weight (approximately 20 kg).
- Verify the availability of a suitable power outlet within reach of the chimney's power cord.
- Plan the ducting route for proper ventilation. This model is designed for ducted/vented operation.
- Maintain the recommended distance between the cooking surface and the chimney for effective suction.

4.2 Installation Procedure:

1. Mark the drilling points on the wall according to the provided template (if included) or measurements in the detailed installation guide.
2. Drill holes and insert wall plugs.
3. Secure the mounting bracket to the wall.
4. Carefully lift and mount the chimney unit onto the bracket.
5. Connect the ducting to the chimney outlet and route it to the exterior. Ensure airtight connections.
6. Connect the power supply.
7. Test the chimney's functions (lights, fan speeds).

Note: It is highly recommended to engage a professional technician for the installation of this appliance to ensure safety and proper functioning. Refer to the separate detailed installation guide for specific measurements and steps.



Cooking Simplified
Gesture, Touch & Remote Control
for easy accessibility



Figure 4.1: The Faber HOOD COMET BLDC FL HC BK 60 Kitchen Chimney shown installed above a cooking range, highlighting its integration into a modern kitchen setup and the use of its remote control.

5. OPERATING INSTRUCTIONS

Your Faber chimney offers multiple intuitive ways to control its functions.

5.1 Control Panel Overview:



Figure 5.1: A close-up view of the chimney's control panel, displaying touch-sensitive buttons and indicators for power, speed, light, and auto-clean functions, along with gesture control icons.

5.2 Touch Control:

The front panel features touch-sensitive buttons for direct control.

- **Power Button (ON/OFF):** Press to turn the chimney on or off.
- **Speed Adjustment (+/-):** Use these buttons to cycle through the 9 available fan speeds.
- **Light Button (Light Icon):** Press to turn the LED lights on or off.
- **Auto Clean Button (Heat Icon):** Press to activate the heat auto-clean function.

5.3 Gesture Control:

The chimney can be operated with simple hand gestures for convenience.

- **Wave Left to Right:** Typically turns the chimney ON or increases fan speed.
- **Wave Right to Left:** Typically turns the chimney OFF or decreases fan speed.


Refer to the specific gesture control section in the detailed manual for precise gesture recognition and functions.

5.4 Remote Control:

The included remote control provides convenient operation from a distance.

- **Power Button:** Turns the chimney on/off.
- **Speed Buttons:** Adjusts the fan speed up or down.
- **Light Button:** Controls the LED lighting.
- **Auto Clean Button:** Activates the auto-clean cycle.

FABER
FRANKE'S AIR EXPERT



Elevate performance with a **BLDC motor** for efficiency, reliability, and low maintenance.

Figure 5.2: A hand holding the remote control for the Faber chimney, demonstrating the ease of operation from a distance.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your chimney.

6.1 Filterless Technology:

This chimney features filterless technology, which means there are no mesh filters to clean or replace. The motor position and design create a clear path for smoke and air, directing grease into the oil collector.

6.2 Oil Collector Cleaning:

The chimney is equipped with a removable stainless steel oil collector. This collector accumulates grease and needs to be emptied and cleaned periodically.

1. Ensure the chimney is turned off and disconnected from the power supply.
2. Locate the oil collector, typically at the bottom or rear of the chimney.
3. Carefully remove the oil collector.
4. Empty the collected oil and wash the collector with warm, soapy water. Rinse thoroughly and dry completely.
5. Reinsert the clean oil collector securely.

FABER
FRANKE'S AIR EXPERT



Soft Noise Immersive Cooking Experience
10% less noise compared to other auto-clean models

Figure 6.1: The Faber Kitchen Chimney with an emphasis on the easily removable oil collector, designed for convenient cleaning.

6.3 Exterior Cleaning:

Wipe the exterior surfaces of the chimney with a soft cloth dampened with mild detergent. Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the matte black finish and glass.

6.4 Heat Auto Clean Function:

Activate the heat auto-clean function periodically to melt and collect internal grease buildup. Follow the instructions in the detailed manual for the duration and frequency of this cycle.

7. TROUBLESHOOTING

If you encounter issues with your chimney, refer to the following common problems and solutions before contacting customer service.

Problem	Possible Cause	Solution
Chimney does not turn on	No power supply; Power cord loose; Fuse blown	Check power outlet; Ensure cord is securely plugged in; Check household fuse/breaker.
Low suction power	Ducting obstructed; Oil collector full; Incorrect speed setting	Check ducting for blockages; Clean oil collector; Increase fan speed.
Unusual noise during operation	Loose components; Foreign object in fan; Improper installation	Ensure all parts are secure; Turn off and inspect for foreign objects (with power disconnected); Contact installer if noise persists.
Lights not working	LED bulb failure; Wiring issue	Contact customer service for bulb replacement or wiring inspection.
Gesture control not responding	Sensor obstructed; Incorrect gesture	Ensure sensor area is clean and clear; Review gesture instructions.

If the problem persists after attempting these solutions, please contact Faber customer support.

8. SPECIFICATIONS

Detailed technical specifications for the Faber HOOD COMET BLDC FL HC BK 60 Kitchen Chimney:

Feature	Specification
Model	HOOD COMET BLDC FL HC BK 60
Mounting Type	Wall Mount
Air Flow Capacity	1500 m³/hr (Cubic Meters Per Hour)
Material	Glass, Stainless Steel
Noise Level	56 Decibels
Controls Type	Touch Control, Motion Sensor (Gesture Control), Remote Control
Voltage	230 Volts
Number of Speeds	9
Item Weight	20 Kilograms
Light Source Type	LED

Feature	Specification
Ventilation Type	Ducted/Vented
Special Features	Heat Auto Clean, Filterless
Annual Energy Consumption	250 Kilowatt Hours Per Year
Product Dimensions (LxWxH)	34D x 65W x 85H Centimeters
Colour	Matte Black
Finish Type	Powder Coated
Manufacturer	Franke Faber India Pvt Ltd.

9. WARRANTY AND SUPPORT

Your Faber HOOD COMET BLDC FL HC BK 60 Kitchen Chimney comes with a**5-year warranty**. Please retain your purchase receipt as proof of purchase for warranty claims.

For technical assistance, service requests, or warranty inquiries, please contact Faber customer support. Contact details can typically be found on the Faber official website or on your warranty card.

Manufacturer: Franke Faber India Pvt Ltd.

© 2024 Faber. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question