

[manuals.plus](#) /

› [Inateck](#) /

› [Inateck NEO Magic Keyboard for iPad Air 11-inch \(M3/M2/5th/4th Gen\) and iPad Pro 11-inch \(4th/3rd/2nd/1st Gen\) - User Manual KB19117](#)

Inateck KB19117

Inateck NEO Magic Keyboard User Manual

Model: KB19117

1. PRODUCT OVERVIEW

The Inateck NEO Magic Keyboard is designed to enhance your iPad experience, offering a full-size keyboard, a precision touchpad, and a floating cantilever design. It connects directly to your iPad via a Smart Connector adapter, eliminating the need for Bluetooth pairing or separate charging.



Figure 1.1: Inateck NEO Magic Keyboard with an iPad in floating mode. The keyboard features a multi-color backlit layout and a large touchpad.

2. COMPATIBILITY

This keyboard is compatible with specific iPad models. Please verify your iPad's model number (Axxxx) on the back of your device before use.

- **iPad Air 11-inch:** M3 (2025), M2 (2024), 5th Gen (2022), 4th Gen (2020)
- **iPad Pro 11-inch:** 4th Gen (2022), 3rd Gen (2021), 2nd Gen (2020), 1st Gen (2018)

Note: Not compatible with iPad 10th Gen (2022) or iPad Pro 11-inch (2024).

Nur Kompatibel mit

iPad Air

iPad Air 6 (2024) | A2902, A2903, A2904

iPad Air 5 (2022) | A2588, A2589, A2591

iPad Air 4 (2020) | A2316, A2324, A2325, A2072




iPad Pro

iPad Pro 11" (2022) | A2435, A2761, A2762

iPad Pro 11" (2021) | A2377, A2459, A2301, A2460

iPad Pro 11" (2020) | A2228, A2068, A2230, A2231

iPad Pro 11" (2018) | A1980, A2013, A1934, A1979



! Nicht kompatibel : iPad Pro 11" (2024)

! Nicht kompatibel : iPad 10th (2022)



Figure 2.1: Visual guide detailing compatible iPad Air and iPad Pro 11-inch models, along with incompatible models.

3. SETUP

The Inateck NEO Magic Keyboard features a plug-and-play design for instant connection.

3.1 Connecting the Keyboard

1. Align your compatible iPad with the magnetic back cover of the keyboard case. The iPad will snap into place securely.

2. Locate the compact Inateck adapter (USB-C to Pogo Pin) provided with the keyboard.
3. Insert the Pogo Pin end of the adapter into the Smart Connector port on the keyboard case.
4. Insert the USB-C end of the adapter into the USB-C port on your iPad.

The keyboard will instantly connect and draw power directly from your iPad. No Bluetooth pairing is required.



Figure 3.1: Illustration of the plug-and-play connection using the Smart Connector adapter, highlighting the direct power and data transfer.

3.2 Power Supply

The keyboard is powered directly by your iPad through the Smart Connector adapter. It does not require an internal battery or separate charging.

Important: The keyboard cannot charge your iPad.

Kein Aufladen erforderlich

Die Tastatur wird direkt vom iPad mit Strom versorgt Vollständig



Hinweis: Die Tastatur kann das iPad nicht aufladen

Figure 3.2: Diagram showing the keyboard drawing power from the iPad when connected, and the iPad's USB-C port being used for power input to the keyboard.

4. OPERATING INSTRUCTIONS

4.1 Floating Design and Viewing Angles

The keyboard features a floating cantilever design with strong magnetic attachment, allowing for adjustable viewing angles from 75° to 130°.

1. Attach your iPad magnetically to the back panel of the keyboard case.
2. Adjust the iPad's angle by gently tilting it to your preferred viewing position. The magnetic hinges will hold it securely.



Schwebendes Design starke Magnetbefestigung

1:1 Passform, einrasten und sofort verwenden
Weitwinkeleinstellung

Figure 4.1: Illustration of the floating design, showing the magnetic attachment points and the adjustable viewing angles (75° to 130°).

4.2 Backlight Operation

The keyboard features a 3-zone mixed backlight with adjustable brightness levels for comfortable typing in various lighting conditions.

- **To turn on/off backlight:** Press the **Fn** key + **Light Bulb** key.
- **To adjust brightness:** Press the **Fn** key + **Up Arrow** or **Down Arrow** keys (or dedicated brightness keys if available) to cycle through three brightness levels.
- **To change backlight color (if applicable):** Press the **Fn** key + **Right Arrow** or **Left Arrow** keys to cycle through available color modes.

Tasten ausleuchten

Genießen Sie ein magisches Erlebnis
bei schlechten Lichtverhältnissen



Farbliche Hintergrundbeleuchtung



3–stufige Helligkeit



Figure 4.2: A user typing on the keyboard in a dimly lit environment, showcasing the multi-color backlit keys.

4.3 Precision Touchpad

The full-surface precision touchpad supports multi-touch gestures for seamless navigation and control of your iPad.

- **Single-finger tap:** Click/select.
- **Two-finger scroll:** Scroll up/down or left/right.
- **Pinch to zoom:** Zoom in/out on content.
- **Three-finger swipe up:** Access App Switcher.
- **Three-finger swipe left/right:** Switch between open apps.

For a complete list of iPadOS gestures, refer to your iPad's user guide or settings.

AG Glas-Fläche Vollflächige Berührung

Nahtloses Touch-Erlebnis



Figure 4.3: Exploded view of the touchpad, illustrating its glass surface and internal components for precise and smooth touch interaction.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Inateck NEO Magic Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the keyboard and touchpad surfaces. Avoid harsh chemicals or abrasive materials.

- **Storage:** When not in use, keep the keyboard closed to protect the screen of your iPad and the keyboard keys. Store in a dry, cool place away from direct sunlight.
- **Handling:** Avoid dropping the keyboard or exposing it to excessive force, which could damage internal components or the magnetic connection.

6. TROUBLESHOOTING

If you encounter issues with your Inateck NEO Magic Keyboard, refer to the following common troubleshooting steps:

- **Keyboard not responding:**
 - Ensure the Smart Connector adapter is securely plugged into both the keyboard and the iPad's USB-C port.
 - Remove and reattach the iPad to the keyboard case to re-establish the connection.
 - Restart your iPad.
- **Intermittent connection/disconnection:**
 - Check for any debris or obstructions on the Smart Connector pins on the keyboard and the USB-C port on the iPad. Clean gently if necessary.
 - Ensure the iPad is firmly seated in the magnetic case.
 - Avoid excessive movement or bending of the adapter cable during use.
- **Backlight not working:**
 - Ensure the keyboard is properly connected and receiving power from the iPad.
 - Press **Fn + Light Bulb** key to toggle the backlight.
 - Press **Fn + Up/Down Arrow** keys to adjust brightness.
- **Touchpad not responding or inaccurate:**
 - Ensure the touchpad surface is clean and free of moisture or debris.
 - Check iPad settings for touchpad sensitivity and gesture preferences.
 - Disconnect and reconnect the keyboard.
- **Keyboard drains iPad battery quickly:**
 - The keyboard draws power from the iPad. Prolonged use, especially with high backlight brightness, may affect iPad battery life.
 - Reduce backlight brightness or turn it off when not needed.
 - Disconnect the keyboard when not in active use to conserve iPad battery.
- **USB-C port on adapter only charges, no data/display output:**
 - The USB-C port on the adapter is designed primarily for power passthrough to the keyboard and does not support data transfer or external display output.
 - For data transfer or external display, connect accessories directly to the iPad's USB-C port (after detaching the keyboard if necessary).
- **Keyboard only works after iPad lock screen:**
 - This is expected behavior for some iPadOS configurations. You may need to manually unlock your iPad before the keyboard becomes fully active.

7. SPECIFICATIONS

Feature	Specification
Brand	Inateck
Model Number	KB19117-BK-DE
Dimensions	25.22 x 19.43 x 1.78 cm
Weight	689 g
Connectivity Technology	Smart Connector (via adapter)
Power Type	USB (powered by iPad)
Backlight	3-zone mixed backlight, RGB color support
Special Feature	Floating Stand
Material	Plastic
Keyboard Layout	QWERTZ (German)

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Inateck website or contact their customer service directly. Keep your purchase receipt as proof of purchase.




Inateck Official Website: www.inateck.com



© 2025 Inateck. All rights reserved.

Related Documents - KB19117

	<p>Inateck KB02011 Bluetooth Keyboard Case User Manual</p> <p>User manual for the Inateck KB02011 Bluetooth Keyboard Case, detailing setup, pairing, functions, specifications, and troubleshooting for iPad users. Includes contact information for service centers.</p>
	<p>Inateck BCST-47 Barcode Scanner User Guide</p> <p>Comprehensive user guide for the Inateck BCST-47 Barcode Scanner, covering setup, operation, specifications, and safety precautions.</p>
	<p>Inateck PR2003 Thermal Printer User Manual and Specifications</p> <p>Comprehensive user manual for the Inateck PR2003 thermal printer, covering setup, operation, specifications, and regulatory information.</p>

	<p>Inateck BK2007-RGB Keyboard: User Manual and Setup Guide</p> <p>Comprehensive instructions and specifications for the Inateck BK2007-RGB Bluetooth keyboard, including pairing, backlight control, troubleshooting, and battery management.</p>
	<p>Inateck BS04001 Barcode Scanner User Guide and Charging Base Instructions</p> <p>This guide provides instructions for the Inateck BS04001 barcode scanner and its charging base, covering installation, LED indicators, product specifications, and package contents. It includes safety precautions and contact information for service centers in Europe, North America, and Japan.</p>
	<p>Inateck HPF 3.5-inch HDD Protection Box Instruction Manual</p> <p>This document provides instructions for using the Inateck HPF 3.5-inch HDD Protection Box, including assembly, usage, and compliance information.</p>