UBeesize UB-1FZJ13BK

UBeesize LED Video Light Kit UB-1FZJ13BK Instruction Manual

Model: UB-1FZJ13BK

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your UBeesize LED Video Light Kit. Please read this manual thoroughly before operating the device and retain it for future reference. Proper understanding of these instructions will ensure optimal performance and longevity of your product.

2. SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the product or injury to yourself:

- Do not expose the light to water or excessive humidity.
- Avoid direct eye exposure to the LED light source.
- Ensure the power adapter is compatible with your local voltage before use.
- Do not disassemble or modify the product. Repairs should only be performed by authorized personnel.
- Place the tripod on a stable, level surface to prevent tipping.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x UBeesize LED Video Light Panel (13-inch)
- 1 x Adjustable Tripod Stand (up to 65-inch)
- 1 x Phone Holder

- 1 x Bluetooth Remote Shutter
- 1 x Power Adapter
- 1 x Carrying Bag

Image 3.1: All components included in the UBeesize LED Video Light Kit.

4. PRODUCT OVERVIEW

4.1. Components

- **LED Video Light Panel:** A 13-inch panel with 300 LED beads, providing 20W of power and up to 2000 lumens. Features side-emitting technology for soft, even illumination.

- **Tripod Stand:** A 3-section adjustable stand that extends up to 65 inches (165 cm) for flexible positioning.
- **Phone Holder:** Mounts to the tripod stand, compatible with most smartphones (2.5-4 inches wide).
- **Bluetooth Remote Shutter:** For wireless control of your smartphone's camera.
- **Power Adapter:** Provides power to the LED light panel via USB connectivity.

Image 4.1: The LED video light panel provides natural, bright illumination.

4.2. Controls

The LED video light panel features two control knobs on the rear:

- **Brightness Knob:** Adjusts the light intensity from 0% to 100%.
- **Color Temperature Knob:** Adjusts the color temperature from 3000K (warm light) to 6500K (cool daylight).

The light panel also has a 1/4-inch threaded hole for mounting and a power input port.

Image 4.2: Rear controls for brightness and color temperature, and 180° rotation.

5. SETUP

1. **Assemble the Tripod Stand:** Extend the tripod legs to a stable position. Adjust the height of the central pole

by loosening the locking clips, extending the sections, and then securing the clips. The tripod can extend up to 65 inches.

Image 5.1: Ensure the tripod legs are fully extended for stability.

2. **Attach the LED Video Light Panel:** Mount the LED light panel onto the 1/4-inch screw thread at the top of the tripod stand. Rotate clockwise until securely fastened.

Image 5.2: The 1/4-inch universal thread for secure mounting.

3. **Attach the Phone Holder (Optional):** If using a smartphone, attach the phone holder to the tripod stand or directly to the light panel's accessory mount. Insert your smartphone into the holder.

Universal Phone Holder

Fit for 2.5- 4"Phones

Image 5.3: Universal phone holder for smartphones.

4. **Connect Power:** Plug the power adapter into the light panel's power input port, then connect the adapter to a power outlet.

5. **Bluetooth Remote Shutter:** The remote shutter requires 1 A battery (included). To pair, activate Bluetooth on your smartphone and select the remote from the available devices.

6. OPERATING INSTRUCTIONS

1. **Power On/Off:** Locate the power switch on the light panel and toggle it to the 'ON' position to turn on the light. Toggle to 'OFF' to power down.

2. **Adjust Brightness:** Rotate the 'Brightness' knob on the back of the light panel to increase or decrease the light intensity from 0% to 100%.

Image 6.1: Stepless dimming for precise brightness control.

3. **Adjust Color Temperature:** Rotate the 'Color Temperature' knob to change the light's warmth or coolness, ranging from 3000K (warm) to 6500K (cool).

Image 6.2: Adjusting brightness and color temperature for desired lighting effects.

4. **Adjust Light Panel Angle:** The light panel can be rotated 180° on its mount. Loosen the adjustment knob on the mount, position the light as desired, and then tighten the knob to secure it.

5. **Using the Bluetooth Remote Shutter:** Once paired with your smartphone, press the appropriate button (iOS or Android) on the remote to trigger your phone's camera for photos or video recording.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the light panel and tripod. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the kit in its carrying bag in a cool, dry place, away from direct sunlight and moisture.

- **Battery Replacement (Remote):** If the Bluetooth remote shutter stops responding, replace the A battery. Refer to the remote's compartment for correct polarity.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power connection. Faulty power adapter.	Ensure power adapter is securely plugged into both the light and the outlet. Try a different outlet.
Light is too dim or too bright.	Brightness knob setting.	Adjust the 'Brightness' knob to the desired level.
Color temperature is incorrect.	Color temperature knob setting.	Adjust the 'Color Temperature' knob to achieve the desired warmth or coolness.
Bluetooth remote not connecting.	Remote battery low/dead. Not paired correctly.	Replace the A battery in the remote. Re-pair the remote via your smartphone's Bluetooth settings.
Tripod is unstable.	Legs not fully extended or locked. Uneven surface.	Ensure all tripod legs are fully extended and locking clips are secured. Place on a flat, stable surface.

9. SPECIFICATIONS

Feature	Detail
Model Number	UB-1FZJ13BK
Light Panel Size	13 inches
Power Output	20W
LED Beads	300
Color Temperature	3000K - 6500K (Stepless)
Brightness Adjustment	0% - 100% (Stepless)
Tripod Max Height	65 inches (165 cm)
Tripod Folded Height	17 inches (43 cm)
Product Dimensions (assembled)	3"L x 15"W x 75"H (approximate, depending on extension)
Item Weight	4.16 pounds (approximate)
Connectivity	USB (power), Bluetooth 4.0 (remote)
Remote Battery Type	1 x A battery (included)

Image 9.1: Dimensions of the video light panel and tripod stand.

10. WARRANTY AND SUPPORT

UBeesize products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the contact information provided with your purchase or visit the official UBeesize website. Please have your model number (UB-1FZJ13BK) available when contacting support.

For further assistance, you may also refer to the UBeesize brand store:UBeesize Store on Amazon

Related Documents - UB-1FZJ13BK

	[UBeesize 62-inch Selfie Stick Tripod with Bluetooth Remote - User Guide](#) Learn how to set up and use your UBeesize 62-inch selfie stick tripod with Bluetooth remote for capturing photos and videos. Includes setup instructions, pairing guide, and feature descriptions.
	[UBeesize 10" Ring Light with Tripod TR50 Operating Instructions](#) Comprehensive operating instructions and user guide for the UBeesize 10-inch Ring Light with Tripod TR50. Learn how to set up, use, and attach accessories for photography, vlogging, and live streaming.
	[UBeesize 67-inch Selfie Stick Tripod with Bluetooth Remote - Features and Setup Guide](#) Discover the UBeesize 67-inch Selfie Stick Tripod with Bluetooth Remote. This guide details its setup, features like adjustable height, phone holder compatibility, and tripod stability, making it ideal for photography and videography.
	[UBeesize TR67 Professional Video Tripod User Manual](#) User manual for the UBeesize TR67 Professional Video Tripod, including assembly instructions, features, and warnings.
	[UBeesize TR50 Professional Tripod Operating Instructions](#) This document provides operating instructions for the UBeesize TR50 Professional Tripod, detailing setup, adjustments, and features for cameras and smartphones.