Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > NIMO /
- > NIMO 15.6-inch FHD Laptop User Manual

NIMO Nimo

NIMO 15.6-inch FHD Laptop User Manual

Model: Nimo

INTRODUCTION

Welcome to the NIMO 15.6-inch FHD Laptop user manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new laptop. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW

Familiarize yourself with the components of your NIMO laptop.



Figure 1: NIMO 15.6-inch FHD Laptop, showcasing its sleek design and the Intel 12th Gen Processors branding.



Figure 2: Rear view of the NIMO laptop, highlighting its dark blue finish and minimalist design.

SETUP

1. Initial Charging

Before first use, fully charge your NIMO laptop. Use the provided 65W PD fast-charging adapter and Type-C data cable.




Figure 3: The included 65W PD Type-C charger, designed for rapid charging and compatibility with various Type-C devices.

2. Power On and Windows Setup

Press the power button located on the keyboard. Follow the on-screen instructions to complete the Windows 11 Home setup. This includes connecting to Wi-Fi, setting up user accounts, and configuring privacy settings. For a visual guide on the unboxing and initial setup, refer to the video below:

Your browser does not support the video tag.

Video 1: Official NIMO video demonstrating the unboxing and initial setup of the 15.6-inch FHD Laptop, highlighting its features for students and home use.

OPERATING INSTRUCTIONS

Power On/Off and Sleep Mode

- Power On: Press the power button located on the top right of the keyboard.
- Shut Down: Click the Windows icon in the taskbar, then select Power > Shut down.
- Sleep Mode: Close the laptop lid or click the Windows icon, then select Power > Sleep.

Using the Touchpad

The integrated touchpad supports multi-touch gestures for navigation. Tap to click, use two fingers to scroll, and pinch to zoom.

Keyboard Shortcuts

Utilize function keys (Fn) for quick access to system controls:

- Fn + F1-F12: Access various functions like volume control, screen brightness, and Wi-Fi toggle.
- Fn + Spacebar: Toggle keyboard backlight.

KEY FEATURES

High-Performance Processor

Your NIMO laptop is equipped with the 12th Gen Intel Alder Lake-N100 processor, featuring 4 cores and 4 threads, capable of reaching up to 3.4GHz. This ensures smooth multitasking and efficient performance for various applications.



Figure 4: Visual representation of the Intel 12th Gen Alder-Lake N100 processor, highlighting its performance improvements. See the Intel 12th Gen N100 processor in action:

Your browser does not support the video tag.

Video 2: Official NIMO video showcasing the performance of the 15.6-inch FHD Laptop with the Intel 12th Gen Processor N100.

Stunning Full HD Display

Experience vibrant visuals on the 15.6-inch Full HD (1080P) display. With an 85% screen-to-body ratio and sleek bezels, it offers exceptional clarity and reduced eye strain.



Figure 5: The laptop's display features, including FHD 1920x1080 resolution, IPS technology, Bright View, and Eye Protection.

Backlit Keyboard and Fingerprint Sensor

The backlit keyboard allows for comfortable typing in low-light conditions. The integrated fingerprint sensor provides secure and quick access to your device.



Figure 6: Close-up of the backlit keyboard, webcam shield, fingerprint sensor, and numeric keypad.




Figure 7: Detailed view of the seamless security integration with the fingerprint scanner and the privacy-focused 2.0M webcam with its physical shield.

Versatile Connectivity Ports

The NIMO laptop offers a variety of ports for all your peripheral needs, including USB 3.0, full-function Type-C, HDMI, Micro SD, and a headphone combo jack.



Figure 8: Diagram illustrating the various ports available on the NIMO laptop, including Kensington lock, Headphone combo, USB 3.0, USB 2.0, Micro SD, HDMI, and Type-C (Multifunction/Charge only).

MAINTENANCE

Cleaning Your Laptop

- Use a soft, lint-free cloth to clean the screen and exterior.
- For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.
- Avoid harsh chemicals, abrasives, or solvents.

Battery Care

- To prolong battery life, avoid extreme temperatures.
- It is recommended to occasionally discharge the battery below 20% and then fully recharge it.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Laptop does not power on	Low battery; Power adapter issue	Connect the power adapter and ensure it's plugged into a working outlet. Allow it to charge for at least 30 minutes before attempting to power on again.
Screen is blank or black	Sleep mode; Display settings; Hardware issue	Press any key or move the touchpad to wake from sleep. Check display settings (Fn + F keys). If the issue persists, perform a hard reset by holding the power button for 10 seconds.
Wi-Fi connection issues	Wi-Fi adapter off; Router issue; Driver issue	Ensure Wi-Fi is enabled (Fn + Wi-Fi key). Restart your router. Update Wi-Fi drivers through Device Manager.
Keyboard backlight not working	Backlight off; Driver issue	Press Fn + Spacebar to toggle the keyboard backlight. Ensure keyboard drivers are up to date.

SPECIFICATIONS

Feature	Detail
Display Size	15.6 Inches
Screen Resolution	1920 x 1080 pixels (Full HD)
Processor	Intel Pentium Quad-Core N100 (Up to 3.4GHz)
RAM	16 GB DDR4 (3200 MHz)
Hard Drive	256 GB SSD (PCIE x 2 interface)
Graphics Coprocessor	Intel UHD Graphics (Integrated)
Operating System	Windows 11 Home
Wireless Type	WiFi 6, Bluetooth 5.2
USB Ports	1x USB 2.0, 2x USB 3.0, Full-function Type-C
Other Ports	HDMI, Micro SD, Headphone Combo
Webcam	2 MP with Privacy Camera
Special Features	Backlit Keyboard, Fingerprint Reader, Numeric Keypad, HD Audio
Battery Life	Approx. 5 Hours (38 Watt-hour)
Item Weight	3.7 pounds
Dimensions (LxWxH)	14.05 x 8.95 x 0.73 inches
Color	Royal Blue

WARRANTY AND SUPPORT

Your NIMO laptop comes with a **2-year manufacturer's warranty**. Additionally, NIMO offers a **90-day risk-free return policy** and **24/7 customer support** to address any concerns you may have.

For support, please visit the official NIMO store on Amazon or contact their customer service directly.

• NIMO Store: Visit the NIMO Store

A short video highlighting NIMO's commitment to service:

Your browser does not support the video tag.

Video 3: Official NIMO video emphasizing their commitment to customer service and support for the laptop.

WHAT'S IN THE BOX

- 15.6 inch laptop
- 65W PD fast-charging adaptor
- Windows 11 Home (Pre-installed)
- 2 Years Warranty, 90 Days Return (Documentation)