

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LEGO](#) /
- › [LEGO Wicked Emerald City Wall Art Building Set 75685 Instruction Manual](#)

## LEGO 75685

# LEGO Wicked Emerald City Wall Art Building Set 75685 Instruction Manual

**Brand:** LEGO

**Model:** 75685

## 1. INTRODUCTION AND OVERVIEW

This manual provides comprehensive instructions for assembling and displaying your LEGO Wicked Emerald City Wall Art Building Set (Model 75685). Designed for adults aged 18 and up, this 1,518-piece set allows you to construct a vibrant, three-dimensional representation of the iconic Emerald City from the Wicked movies. The finished artwork serves as a unique decorative piece, featuring key landmarks, hidden details, and beloved characters.

The set incorporates the film's signature colors: pink for Glinda, green for Elphaba, and yellow for the Yellow Brick Road, creating a visually striking display. Discover fantastical locations such as Shiz University, Munchkinland, and the Emerald City train, along with a secret compartment housing minifigures of Dorothy Gale, Cowardly Lion, Scarecrow, and Tin Man.

## 2. WHAT'S INCLUDED

Your LEGO Wicked Emerald City Wall Art set contains 1,518 LEGO building elements. These elements are organized into numbered bags to facilitate a structured building experience. The set also includes several minifigures and a microfigure:

- Elphaba minifigure
- Glinda minifigure
- Dorothy Gale minifigure
- Cowardly Lion minifigure
- Scarecrow minifigure
- Tin Man minifigure
- Toto microfigure

A detailed, step-by-step instruction booklet is provided to guide you through the assembly process. You can also access digital instructions via the official LEGO Building Instructions app.



Video: An unboxing of the LEGO Wicked Emerald City Wall Art set, showcasing the various numbered bags of LEGO elements and the instruction manual included in the box. This video is provided by a seller and is 34 seconds long.

### 3. ASSEMBLY INSTRUCTIONS (SETUP)

Follow the numbered steps in the instruction booklet carefully. Each bag of LEGO elements corresponds to a specific section of the build, ensuring a smooth and organized construction process.

1. **Preparation:** Clear a spacious and well-lit area for building. Open the numbered bags one at a time as indicated in the instructions.
2. **Base Construction:** Begin by assembling the base structure of the wall art, which provides stability for the entire model.
3. **Layered Details:** The set features a layered design to create a three-dimensional effect. Pay close attention to the placement of each brick to ensure the intricate details of the Emerald City, Shiz University, and Munchkinland are accurately represented.
4. **Hidden Compartment:** During assembly, you will construct a secret compartment designed to house four of the included minifigures: Dorothy Gale, Cowardly Lion, Scarecrow, and Tin Man. Ensure this compartment functions correctly before proceeding.
5. **Character Placement:** Place the Elphaba minifigure in the designated upper section and the Glinda minifigure in her bubble on the lower left side, as shown in the instructions.
6. **Final Touches:** Attach all remaining decorative elements, such as the hot-air balloon, rainbow, and clouds, to complete the artwork.

# Construct a detailed artwork with 1,518 pieces



Image: A builder meticulously placing LEGO bricks to construct the Emerald City wall art, highlighting the engaging and detailed assembly process.



## 3D features bring the diorama to life



Image: Detailed shots of the 3D elements that bring the LEGO Emerald City diorama to life, including textured surfaces and small architectural features.

### 4. DISPLAY OPTIONS (OPERATING)

The LEGO Wicked Emerald City Wall Art is designed for versatile display, allowing it to be either hung on a wall or placed freestanding on a shelf or desk.

- **Wall Mounting:** The set includes integrated hanging points on the back for secure wall mounting. Ensure you use appropriate wall anchors and screws for the weight of the assembled model.
- **Shelf Display:** The robust base of the artwork allows it to stand independently on any flat surface. Position it to showcase its three-dimensional depth and vibrant colors.
- **Minifigure Compartment:** Before finalizing your display, ensure the secret compartment housing Dorothy, Cowardly Lion, Scarecrow, and Tin Man is properly closed or opened to your preference.

# Mount on a wall or display on a shelf



Image: The completed LEGO Emerald City Wall Art shown in two display configurations: hanging on a wall and standing on a shelf, demonstrating its versatility as home decor.



## Secret compartment used to store 4 minifigures

Image: A close-up of the secret compartment within the LEGO Emerald City Wall Art, revealing the minifigures of Dorothy, Scarecrow, Tin Man, and Cowardly Lion stored inside.



## Comes with 7 characters from the *Wicked* movies

Image: The full collection of minifigures included with the set: Glinda, Elphaba, Dorothy, Scarecrow, Tin Man, Cowardly Lion, and Toto.

### 5. CARE AND MAINTENANCE

To ensure the longevity and appearance of your LEGO Wicked Emerald City Wall Art, follow these care guidelines:

- **Cleaning:** Dust regularly with a soft, dry cloth or a soft-bristled brush. For deeper cleaning, gently wipe with a damp cloth using mild soap and water. Avoid harsh chemicals or abrasive materials.
- **Storage:** If disassembling for storage, keep all LEGO elements organized in sealed containers to prevent loss and damage. Store in a cool, dry place away from direct sunlight to prevent color fading.
- **Handling:** Handle the assembled model with care, especially when moving or adjusting its position, to prevent pieces from detaching.

### 6. TROUBLESHOOTING

If you encounter any issues during assembly or with your completed model, consider the following:

- **Missing Pieces:** In the rare event of a missing piece, please visit the official LEGO Customer Service website

to request replacement parts.

- **Difficulty Assembling:** Double-check the instruction manual to ensure all steps are followed correctly. Sometimes a small misplacement can affect subsequent steps. The LEGO Building Instructions app offers 3D views that can help identify errors.
- **Loose Connections:** Ensure all bricks are firmly pressed together. LEGO elements are designed to connect securely.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	75685
Manufacturer Part Number	6526329
Number of Pieces	1,518
Dimensions (H x W x D)	12.5 in. (32 cm) x 10 in. (25 cm) x 3 in. (8 cm)
Age Range	18+
Material	Plastic
Included Components	LEGO Building Elements

## 8. WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. If you experience any issues with your set, such as missing or defective parts, please contact LEGO Customer Service.

For further assistance, replacement parts, or to view digital building instructions, please visit the official LEGO website:

[LEGO Customer Service](#)