

Incase ANB-00001

Incase Wired Keyboard 600 User Manual

Model: ANB-00001

INTRODUCTION

This manual provides comprehensive instructions for the Incase Wired Keyboard 600, designed by Microsoft. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. This keyboard is engineered for efficiency, featuring quiet-touch keys, quick access media controls, and a full number pad.

KEY FEATURES

- **Efficient Media Controls:** Integrated Media Center with four hot keys for play/pause, volume up, volume down, and mute functions.
- **Quiet and Responsive Keys:** Enjoy a comfortable typing experience with quiet, thin-profile keys that offer both responsiveness and efficiency.
- **Convenient Shortcuts:** Dedicated shortcut keys for common tasks, including a calculator hot key and a Windows start screen key.
- **Spill-Resistant Design:** Engineered to protect the keyboard from accidental liquid spills, enhancing durability.
- **Plug-and-Play Simplicity:** No software installation required; simply connect the keyboard to your PC via USB and begin use. Includes a full number pad for efficient data entry.

Wired Keyboard 600

Designed by Microsoft™



incase

Image: Overview of the Incase Wired Keyboard 600, pointing out its key features such as 4 function hotkeys, quiet-touch keys, spill-resistant design, and plug-and-play functionality.

SETUP INSTRUCTIONS

The Incase Wired Keyboard 600 is designed for simple plug-and-play operation. No drivers or software installation are required for basic functionality.

1. **Unpack the Keyboard:** Carefully remove the keyboard from its packaging.
2. **Identify the USB Connector:** Locate the USB-A connector attached to the keyboard cable.
3. **Connect to Your Computer:** Plug the USB-A connector into an available USB port on your desktop, laptop, or PC.
4. **System Recognition:** Your operating system (Windows, macOS, Linux) should automatically detect and configure the keyboard within a few seconds.
5. **Begin Use:** The keyboard is now ready for immediate use.



Image: Top-down view of the Incase Wired Keyboard 600, showing the full layout and the integrated USB cable extending from the top.

OPERATING THE KEYBOARD

The Incase Wired Keyboard 600 offers a standard QWERTY layout with additional function keys and a numeric keypad for enhanced productivity.

Standard Keys

All standard alphanumeric keys, punctuation, and modifier keys (Shift, Ctrl, Alt) function as expected in your operating system.

Function Hotkeys (F1-F12)

The keyboard includes a row of function keys (F1-F12) that may have secondary functions depending on your operating system or specific applications. Additionally, dedicated media control hotkeys are located above the function row:

- **Play/Pause:** Controls media playback.
- **Volume Up:** Increases audio output volume.
- **Volume Down:** Decreases audio output volume.
- **Mute:** Toggles audio mute on/off.

Dedicated Shortcut Keys

- **Calculator Hot Key:** Provides quick access to the system's calculator application.
- **Windows Start Key:** Opens the Windows Start menu or Start screen.

Numeric Keypad

A full numeric keypad is included on the right side of the keyboard for efficient data entry and calculations. Ensure the "Num Lock" indicator light is on for numeric input.

MAINTENANCE AND CARE

Proper care will extend the life and maintain the performance of your Incase Wired Keyboard 600.

- **Cleaning:**

- Disconnect the keyboard from your computer before cleaning.
 - Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution.
 - Avoid spraying liquids directly onto the keyboard.
 - For dust and debris between keys, use compressed air.
- **Spill-Resistant Design:** While the keyboard is designed to be spill-resistant, it is not waterproof. In case of a spill:
 - Immediately disconnect the keyboard from your computer.
 - Invert the keyboard to allow liquid to drain.
 - Wipe down the surface with a clean, dry cloth.
 - Allow the keyboard to air dry completely before reconnecting it.
 - **Storage:** Store the keyboard in a clean, dry environment away from extreme temperatures and direct sunlight.



Image: Side profile view of the Incase Wired Keyboard 600, illustrating its ergonomic curve and key height.

TROUBLESHOOTING

If you encounter issues with your Incase Wired Keyboard 600, refer to the following common solutions:

- **Keyboard is not responding:**
 - Ensure the USB cable is securely plugged into a working USB port on your computer.
 - Try plugging the keyboard into a different USB port.
 - Restart your computer.
 - Test the keyboard on another computer to determine if the issue is with the keyboard or the computer.
- **Keys are not typing correctly or are sticky:**
 - Clean the keyboard as described in the Maintenance section, paying close attention to the affected keys.
 - Ensure no debris is lodged under the keys.
- **Media hotkeys or shortcut keys are not working:**
 - Verify that your operating system and applications are up to date.
 - Some applications may override or not support these functions. Test in a different application or environment.
- **Numeric keypad is not working:**
 - Press the "Num Lock" key to activate the numeric keypad. The "Num Lock" indicator light should illuminate.

SPECIFICATIONS

Model Name	Incase Wired Keyboard 600
------------	---------------------------

Model Number	ANB-00001
Brand	Incase
Connectivity Technology	USB-A, Wired
Keyboard Description	Membrane
Compatible Devices	Desktop, Laptop, PC
Special Features	Number Pad, Quiet Touch Keys, Spill Resistant
Color	Black
Product Dimensions	18"L x 6.25"W x 1"H (45.72 cm L x 15.88 cm W x 2.54 cm H)
Item Weight	2.14 pounds (0.97 kg)
Included Components	Keyboard

Wired Keyboard 600

Designed by Microsoft™



Image: Top-down and side view of the Incase Wired Keyboard 600, illustrating its dimensions: 18.0 inches length, 6.3 inches width,

and 1.1 inches height.

WARRANTY INFORMATION

This Incase product is covered by a limited warranty. Please refer to the official Incase website or your purchase documentation for specific warranty terms and conditions, including duration and coverage details. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT







For further assistance, technical support, or to inquire about warranty services, please visit the official Incase support website or contact their customer service department. Contact information can typically be found on the manufacturer's website or in your product packaging.

You can visit the [Incase Store on Amazon](#) for more product information.



© 2025 Incase. All rights reserved.

Related Documents - ANB-00001

<div></div> <div></div>	<div>Incase Sculpt Ergonomic Mouse Quick Start Guide</div> <div>A concise guide to setting up and using your Incase Sculpt Ergonomic Mouse, including connection instructions and ergonomic tips.</div>
<div></div> <div></div>	<div>Incase Wireless Desktop 900: Quick Start Guide for Wireless Keyboard and Mouse</div> <div>Setup and connection guide for the Incase Wireless Desktop 900, featuring a wireless keyboard and mouse. Learn how to install batteries, connect the USB receiver, and start using your devices.</div>
<div></div> <div></div>	<div>Incase Bluetooth Keyboard Quick Start Guide</div> <div>A quick start guide for the Incase Bluetooth Keyboard, detailing setup and pairing instructions.</div>

